

Submit 1 Copy To Appropriate District Office	State of New Mexico Energy, Minerals and Natural Resources			Form C-103 Revised August 1, 2011			
<u>District I</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	Energy, miner	als and roat		WELL API		7	
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSE	RVATION	DIVISION	30-015-24011			
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410		1220 South St. Francis Dr.		5. Indicate Type of Lease STATE X FEE			
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505	Santa	a Fe, NM 87	505	6. State Oil V-184	& Gas Lease No.		
(DO NOT USE THIS FORM FOR PROP		DEEPEN OR PLU	JG BACK TO A		me or Unit Agreemen	t Name	
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.) 1. Type of Well: Oil Well X Gas Well Other					CHOCTAW STATE 8. Well Number		
2. Name of Operator					001 9. OGRID Number		
COG OPERATING LLC 3. Address of Operator 600 W. ILLINOIS AVE., MIDLAND, TEXAS 79701					229137 10. Pool name or Wildcat GRAYBURG-JACKSON;QN-GB-SA		
4. Well Location							
Unit Letter; A ;	990 feet from the	NORTH I	ine and 990 fee	et from the	EAST line		
Section 16	Townsh		Range 33E	NM	IPM EDDY Co	unty	
	11. Elevation (Show				AND RAME		
		3,860.7'	- GR		Statistics and statistics.	Land A.	
12. Check	Appropriate Box to	Indicate N	ature of Notice, I	Report or O	ther Data		
NOTICE OF I	INTENTION TO:		SUBS	SEQUENT	REPORT OF:		
PERFORM REMEDIAL WORK		ON X	REMEDIAL WORK			sing 🗌	
TEMPORARILY ABANDON			COMMENCE DRIL		P AND A		
PULL OR ALTER CASING			CASING/CEMENT	JOB			
	-						
OTHER:			OTHER:				
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.							
1) SET 5-1/2" CIBP @ 3,30							
2) PUMP 80 SXS. CMT. @							
 PUMP 40 SXS. CMT. @ 735'-475' (8-5/8" CSG.SHOE, T/SALT, T/ANHY.); WOC X TAG CMT. PLUG. MIX X CIRC. TO SURF. 25 SXS. CMT. @ 150'-3'. 							
5) DIG OUT X CUT OFF V			TEEL PLATE TO C	CSGS. X INS	TALL DRY HOLE M	ARKER.	
DURING THIS PROCEDURE W TO THE REQUIRED DISPOSAL			OP SYSTEM W/ A	STEEL TAN	IK AND HAUL CON	TENETS	
CONDITIONS OF APPROVAL ATTACK	HED	Approved	for plugging of well bore	only.	RECEIVE	57	
Approval Granted providing work	k is	Larc.103 (nder bond is retained per Subsequent Report of Wi be found at OCD Web I	ell Plugging)	NOV 07 2013	ł	
Completed by	R	ig Release Da	be found at OCD Web I Committee at the state of the state	i.			
<u>Nov 20, 20</u>	019				NMOCD ARTES		
I hereby certify that the information	n above is true and com	plete to the be	est of my knowledge	and belief.			
SIGNATURE Curr	A. El	TITLE: AGE	NT		DATE: 11/05/13		
Type or print name: DAVID A. E For State Use Only	YLER E-mail	address: DEY	LER@MILAGRO	RES.COM	PHONE: 432.687.3	033	
APPROVED BY: APPROVED BY:	tde T	ITLE DIST	E Superni	50	DATE 11 20/2	013	
≯ See AttAC	hed COA's						

COG Operating LLC



COG Operating LLC



C:\Users\david\AppData\Local\Microsoft\Windows\Temporary Internet Files\Content.Outlook\EYXHIDAE\Choctaw 10/29/2013 State #1Wellbore diagram.xls

11/04/13

NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

CONDITIONS OF APPROVAL FOR PLUGGING & ABANDONMENT

Operator: COG Operating		
Well Name & Number: <u>CHOCTAW</u>	State	#001
api #: <u>30-015-24011</u>		

- 1. Produced water <u>will not</u> be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- 3. Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- 6. If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.
- 8. Cement Retainers may not be used.

9. Squeeze pressures are not to exceed 500 PSI, unless approval is given by NMOCD.
10. Plugs may be combined after consulting with and getting approval from NMOCD.
11. Minimum WOC time for tag plugs will be 4 Hrs.

DATE:

APPROVED BY:

and and a second se

.

GUIDELINES FOR PLUGGING AND ABANDONMENT

DISTRICT II / ARTESIA

- All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater.
- Mud laden fluids must be placed between all cement plugs.
- Mud laden fluids must be mixed at 25 sacks of gel per 100 bbls of water.
- A cement plug is required to be set 50' below and 50' above all casing shoes and casing stub plugs. These plugs must be tagged.
- A CIBP with 35' of cement on top may be set in lieu of 100' cement plug.
- A plug as indicated above must be placed within 100' of top perforation. This plug must be tagged.
- Plugs set below and above salt zones must be tagged.
- No more than 2000' is to be allowed between cement plugs in open hole and no more than 3000' in cased hole.
- DV tools are required to have a 100' cement plug set 50' above and below the tool and must be tagged.
- Formations to be isolated with plugs placed at the top of each formation are:
 - o Fusselman
 - o Devonian
 - o Morrow
 - o Wolfcamp
 - o Bone Spring
 - o Delaware
 - o Any Salt Section (Plug at top and bottom)
 - o Abo
 - o Glorieta
 - Yates (this plus is usually at base of salt section)
- If cement does not exist behind casing strings at recommended formation depths, the casing must be cut and pulled with plugs set at these depths or casing must be perforated and cement squeezed behind casing at the formation depths.
- In the R-111-P area (Potash Mine area) a solid cement plug must be set across the salt section.
 Fluid used to mix the cement shall be saturated with the salts common to the section penetrated and in suitable proportions, but not more than a 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible (50' below and 50' above).