	Form C-103
Office District I – (575) 393-616 RECEIVENERS, Minerals and Natural Resources	Revised July 18, 2013
Office District I – (575) 393-6161 RECEIVED Minerals and Natural Resources 1625 N. French Dr., Hobbs, NM 88240 EIVED	WELL API NO.
District II - (575) 748-1289 811 S. First St., Artesia, NM 88210 AN 17 20 QIL CONSERVATION DIVISION	30-015-29345
District III – (505) 334-6178 1220 South St. Francis Dr.	5. Indicate Type of Lease
1000 Rio Brazos Rd., Azteca NM 87410	STATE FEE
1000 Rio Brazos Rd., Azicca M 87400 ARTESIA Santa Fe, NM 87505. 1220 S. St. Francis Dr., Santa Fe, NM 87505	6. State Oil & Gas Lease No.
SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	Cotton Draw Unit
PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other	8. Well Number
1. Type of well. Off well	81
2. Name of Operator	9. OGRID Number
Devon Energy Production Company, LP 405-228-7203	6137
3. Address of Operator	10. Pool name or Wildcat
333 West. Sheridan Avenue	SWD; Delaware
Oklahoma City, OK 73102-5015 405-228-7203	
4. Well Location	
Unit Letter L : _1650 feet from the SOUTH line and 660	feet from the WEST line
Section 2 Township 25S Range 31E	NMPM Eddy County
11. Elevation (Show whether DR, RKB, RT, GR, etc.	
3437' GL	
3437 GE	
12. Check Appropriate Box to Indicate Nature of Notice	, Report or Other Data
NOTICE OF INTENTION TO: SUE	RSECUENT DEDORT OF
	BSEQUENT REPORT OF:
	_
	RILLING OPNS. P AND A
PULL OR ALTER CASING	NI JOB
DOWNHOLE COMMINGLE	
CLOSED-LOOP SYSTEM	
OTHER: Conversion to micro-seismic well	Ц
13. Describe proposed or completed operations. (Clearly state all pertinent details, a	nd give pertinent dates, including estimated date
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Co	
proposed completion or recompletion.	ompletions. Attach wendore diagram of
Devon Energy Production Company, L.P. respectfully requests permission to convert the	
Devoir Energy Froduction Company, E.i. respectionly requests permission to convert the	Cotton Draw 91 SWD into a migro coigmic
	Cotton Draw 81 SWD into a micro-seismic
listening well.	Cotton Draw 81 SWD into a micro-seismic
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring.	
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze	
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement.	off Cherry Canyon perfs (5,332'-5,360') with
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement.
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement.
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi.
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. 500psi.
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. o 500psi. o 500psi.
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 1.	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. o 500psi. o 500psi.
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill cement.	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. o 500psi. o 500psi. ent and CIBP at 8,650'. TOH LD collars, sub,
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill cement bit.	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. 500psi. o 500psi. ent and CIBP at 8,650'. TOH LD collars, sub, f Bone Spring perfs (8,725'-9,445') with 260 sx
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill cement and bit. 9. RIH, set composite bridge plug at 9,460', and 7" cement retainer at 8,710'. Squeeze of	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. 500psi. o 500psi. ent and CIBP at 8,650'. TOH LD collars, sub, f Bone Spring perfs (8,725'-9,445') with 260 sx
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill cement and bit. 9. RIH, set composite bridge plug at 9,460', and 7" cement retainer at 8,710'. Squeeze of of Class H cement.	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. o 500psi. o 500psi. ent and CIBP at 8,650'. TOH LD collars, sub,
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill ceme and bit. 9. RIH, set composite bridge plug at 9,460', and 7" cement retainer at 8,710'. Squeeze of of Class H cement. 10. RIH 6" bit, sub and collars drill retainer, cement, and retainer to 11,000'. TOH.	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. 500psi. 500psi. ent and CIBP at 8,650'. TOH LD collars, sub, f Bone Spring perfs (8,725'-9,445') with 260 sx
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill ceme and bit. 9. RIH, set composite bridge plug at 9,460', and 7" cement retainer at 8,710'. Squeeze of of Class H cement. 10. RIH 6" bit, sub and collars drill retainer, cement, and retainer to 11,000'. TOH. 11. RIH micro-seismic array on wireline to 10,900'. I hereby certify that the information above is true and complete to the best of my knowled.	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. 500psi. 500psi. ent and CIBP at 8,650'. TOH LD collars, sub, f Bone Spring perfs (8,725'-9,445') with 260 sx family square Shut-iv, (ZA) ge and belief.
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill ceme and bit. 9. RIH, set composite bridge plug at 9,460', and 7" cement retainer at 8,710'. Squeeze of of Class H cement. 10. RIH 6" bit, sub and collars drill retainer, cement, and retainer to 11,000'. TOH. 11. RIH micro-seismic array on wireline to 10,900'.	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. 500psi. 500psi. ent and CIBP at 8,650'. TOH LD collars, sub, f Bone Spring perfs (8,725'-9,445') with 260 sx family square Shut-iv, (ZA) ge and belief.
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill ceme and bit. 9. RIH, set composite bridge plug at 9,460', and 7" cement retainer at 8,710'. Squeeze of of Class H cement. 10. RIH 6" bit, sub and collars drill retainer, cement, and retainer to 11,000'. TOH. 11. RIH micro-seismic array on wireline to 10,900'. I hereby certify that the information above is true and complete to the best of my knowled SIGNATURE Title: Regulatory Amount of Trina C. Couch E-mail address: trina.couch@dvn.com	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. 500psi. 500psi. ent and CIBP at 8,650'. TOH LD collars, sub, f Bone Spring perfs (8,725'-9,445') with 260 sx family contains the square of the state of the square of the
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill ceme and bit. 9. RIH, set composite bridge plug at 9,460', and 7" cement retainer at 8,710'. Squeeze of of Class H cement. 10. RIH 6" bit, sub and collars drill retainer, cement, and retainer to 11,000'. TOH. 11. RIH micro-seismic array on wireline to 10,900'. I hereby certify that the information above is true and complete to the best of my knowled SIGNATURE Title: Regulatory A. TITLE: Regulatory A. R	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. 500psi. o 500psi. ent and CIBP at 8,650'. TOH LD collars, sub, f Bone Spring perfs (8,725'-9,445') with 260 sx (ZA) ge and belief. Associate DATE 1/16/2014 PHONE: 405-228-7203
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill ceme and bit. 9. RIH, set composite bridge plug at 9,460', and 7" cement retainer at 8,710'. Squeeze of of Class H cement. 10. RIH 6" bit, sub and collars drill retainer, cement, and retainer to 11,000'. TOH. 11. RIH micro-seismic array on wireline to 10,900'. I hereby certify that the information above is true and complete to the best of my knowled SIGNATURE Title: Regulatory A. TITLE: Regulatory A. R	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. 500psi. o 500psi. ent and CIBP at 8,650'. TOH LD collars, sub, f Bone Spring perfs (8,725'-9,445') with 260 sx (ZA) ge and belief. Associate DATE 1/16/2014 PHONE: 405-228-7203
listening well. 1.TOH existing 3-1/2" injection string and packer. PU 2-7/8" workstring. 2. RIH, set 7" Composite bridge plug at 5,380', PU set cement retainer at 5,312'. Squeeze min 10 sx of Class H cement. 3. RIH, set 7" cement retainer at 4,919'. Squeeze off Bell Canyon perfs (4,969'-5,246') w 4. RIH, set 7" cement retainer at 4,506'. Squeeze off Bell Canyon perfs (4,556'-4,744') w 5. PU 6" rock bit, sub and collars. RIH and drill retainer and cement to 5,365'. Pressure te 6. Drill through remaining cement, retainer, and cement to 5,250'. Pressure test squeeze to 7. Drill through remaining cement, retainer, and cement to 4,750'. Pressure test squeeze to 8. RIH, tag PBTD at +/-5,428', drill through cement and retainer. RIH to 8,615' drill ceme and bit. 9. RIH, set composite bridge plug at 9,460', and 7" cement retainer at 8,710'. Squeeze of of Class H cement. 10. RIH 6" bit, sub and collars drill retainer, cement, and retainer to 11,000'. TOH. 11. RIH micro-seismic array on wireline to 10,900'. I hereby certify that the information above is true and complete to the best of my knowled SIGNATURE Title: Regulatory A. TITLE: Regulatory A. R	off Cherry Canyon perfs (5,332'-5,360') with ith 120 sx of Class H cement. ith 75 sx of Class H cement. st squeeze to 500 psi. o 500psi. o 500psi. ent and CIBP at 8,650'. TOH LD collars, sub, f Bone Spring perfs (8,725'-9,445') with 260 sx Therefore Shut-iv. (ZA) ge and belief. Associate DATE 1/16/2014