

Submit 1 Copy To Appropriate District VOffice 1	State of New M	exico		Form C-103	
District I - (575) 393-6161	Energy, Minerals and Nat	ural Resources	WELL ABOVE	Revised July 18, 2013	
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283			WELL API NO. 30-005-61024		
811 S. First St., Artesia, NM 88210	OIL CONSERVATION		5. Indicate Type of L	ease	
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Fra		STATE	FEE 🛛	
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, NM 8	3/303	6. State Oil & Gas Le	ease No.	
87505					
	TICES AND REPORTS ON WELL OSALS TO DRILL OR TO DEEPEN OR PI		7. Lease Name or Un	it Agreement Name	
DIFFERENT RESERVOIR. USE "APPL	ICATION FOR PERMIT" (FORM C-101) F		Snell QZ 8. Well Number		
PROPOSALS.) 1. Type of Well: Oil Well	Gas Well 🛛 Other		1		
2. Name of Operator	Gus Well 🖂 Culei		9. OGRID Number		
Yates Petroleum Corporation			025575		
3. Address of Operator 105 South Fourth Street, Artesia,	NIM 00210		10. Pool name or Wil Pecos Slope; Abo	dcat	
4. Well Location	NIVI 66210		recos stope, Aud		
Unit Letter C:	660 feet from the Nort	th line and	1980 feet from the	West line	
Section 31		ange 25E	NMPM Chaves	County	
	11. Elevation (Show whether DI	R, RKB, RT, GR, etc.)			
	3,878	.2' GR		Washington Holling Co.	
10 01 1			D		
12. Check	Appropriate Box to Indicate N	Nature of Notice,	Report or Other Dat	ta	
NOTICE OF II	NTENTION TO:	SUB	SEQUENT REPO	RT OF:	
PERFORM REMEDIAL WORK □		REMEDIAL WOR		TERING CASING 🔲	
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DRI		ND A	
PULL OR ALTER CASING	-	CASING/CEMENT	TJOB ∐		
DOWNHOLE COMMINGLE CLOSED-LOOP SYSTEM					
OTHER:	'	OTHER:			
13. Describe proposed or com	pleted operations. (Clearly state all	pertinent details, and			
	vork). SEE RULE 19.15.7.14 NMA	C. For Multiple Cor	npletions: Attach wellb	ore diagram of	
proposed completion or re	completion.				
Yates Petroleum Corporation plans	to plug and abandon this well as fo	llows:			
	as needed. No casing recovery will				
	nd cap if with 35' cement. This put			wass tha Intarmadiata	
3. Perforate at 1,650' and spot a 45 sx Class "C" cement plug from 1,350' – 1,650'. This puts a 300' plug across the Intermediate Casing Shoe and top of Glorieta, inside and outside the casing. WOC and tag plug.					
	a 25 sx Class "C" cement plug from			he Surface Casing	
	he casing. WOC and tag plug.	·		_	
	ate a 15 sx Class "C" cement plug f ment, weld dry hole marker and clea			the casing.	
o. Remove an surface equipi	ment, weld dry note marker and clea	in location as per reg	uiations.		
Schematics attached			_		
CONDITIONS OF APPROVAL ATTACK	Approved for plugging of we Liability under bond is retain	ell bore only.	RECEIV	/ED	
	of C 103 (Subsequent Repor	rt of Well Plugging)		!	
Approval Granted providing work	which may be found at OCF Rig Release Forms, www.canrd.state.nm	ale Page under	MAY 05	2014	
Completed by 5 - 12 - 2015		, us/ocu.	MMOCD AF	RTESIA	
			The second secon	7.0.14.3 [
I hereby certify that the information	n above is true and complete to the l	best of my knowledge	e and belief.		
.	1 1				
SIGNATURE Dunca	Watts TITLE Rep	gulatory Reporting Te	echnician DATE <u>N</u>	May 1, 2014	
			DUONE	575 740 4070	
Type or print name Laura V For State Use Only	Vatts E-mail address:	laura@yatespetroleur	m.com PHONE: _	575-748-4272	
100 State Color	1		_	-1 1	
APPROVED BY:	UV TITLE WS	TA Offer 18	↑ DATE	5/12/14	
Conditions of Approval (if any):	•			/ / /	

* See Attached COA'S





NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

CONDITIONS OF APPROVAL FOR PLUGGING & ABANDONMENT

Operator: Vate	۵	
Well Name & Nun	iber: Snell	02 #1
API #: 30	005-6	Y 5 OI

- 1. Produced water <u>will not</u> be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- 3. Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- **6.** If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.
- 8. Cement Retainers may not be used.

- 9. Squeeze pressures are not to exceed 500 PSI, unless approval is given by NMOCD.
- 10. Plugs may be combined after consulting with and getting approval from NMOCD.
- 11. Minimum WOC time for tag plugs will be 4 Hrs.

DATE: 5/12/14

APPROVED BY: 80

GUIDELINES FOR PLUGGING AND ABANDONMENT

DISTRICT II / ARTESIA

- All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement,
 whichever is greater.
- Mud laden fluids must be placed between all cement plugs.
- Mud laden fluids must be mixed at 25 sacks of gel per 100 bbls of water.
- A cement plug is required to be set 50' below and 50' above all casing shoes and casing stub plugs. These plugs must be tagged.
- A CIBP with 35' of cement on top may be set in lieu of 100' cement plug.
- A plug as indicated above must be placed within 100' of top perforation. This plug must be tagged.
- Plugs set below and above salt zones must be tagged.
- No more than 2000' is to be allowed between cement plugs in open hole and no more than 3000' in cased hole.
- DV tools are required to have a 100' cement plug set 50' above and below the tool and must be tagged.
- Formations to be isolated with plugs placed at the top of each formation are:
 - o Fusselman
 - o Devonian
 - o Morrow
 - o Wolfcamp
 - o Bone Spring
 - o Delaware
 - o Any Salt Section (Plug at top and bottom)
 - o Abo
 - o Glorieta
 - Yates (this plus is usually at base of salt section)
- If cement does not exist behind casing strings at recommended formation depths, the casing must be cut and pulled with plugs set at these depths or casing must be perforated and cement squeezed behind casing at the formation depths.
- In the R-111-P area (Potash Mine area) a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts common to the section penetrated and in suitable proportions, but not more than a 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible (50' below and 50' above).