Form 3160-5 (August 2007)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

OCD Artesia

FORM APPROVED OMB NO. 1004-0135 Expires: July 31, 2010

Expires: July
Lease Serial No.
NMLC054280

יא זאטאטכ	TIMES WAD REPORTS ON METES
Do not use this	form for proposals to drill or to re-enter an
abandoned well.	Use form 3160-3 (APD) for such proposals

Do not use abandoned	. [6. If Indian, Allottee or Tribe Name				
SUBMIT IN		7. If Unit or CA/Agreement, Name and/or No. 8. Well Name and No. MCINTYRE A EAST 15 9. API Well No.				
1. Type of Well 2 Oil Well Gas Well						
Name of Operator COG OPERATING LLC						
3a. Address	E-Mail: kcastillo@concho	Phone No. (include area code	30-015-31854-00-S1 code)			
ONE CONCHO CENTER MIDLAND, TX 79701		432-685-4332		LOCO HILLS		
4. Location of Well (Footage, Sec	c., T., R., M., or Survey Description)			County or Parish	, and State	
Sec 20 T17S R30E SESE	330FSL 990FEL			EDDY COUNT	Y, NM	
12. CHECK A	PPROPRIATE BOX(ES) TO IND	ICATE NATURE OF	NOTICE, REI	PORT, OR OTHE	ER DATA	
TYPE OF SUBMISSION		ТҮРЕ О	F ACTION			
■ Notice of Intent	☐ Acidize	□ Deepen	☐ Productio	n (Start/Resume)	■ Water Shut	-Off
_	☐ Alter Casing	☐ Fracture Treat	Reclamati	on	☐ Well Integr	rity
☐ Subsequent Report	☐ Casing Repair	■ New Construction	Recomple	te	Other	
☐ Final Abandonment Notice	☐ Change Plans	☐ Plug and Abandon	□ Temporar	ily Abandon		
	☐ Convert to Injection	Plug Back	■ Water Dis	posal	•	
have our PBTD @ 4511?. \ 200?-300? of rathole below tubing from getting stuck wi	at 4551? (50? above the YESO p We plan to have our bottom perfs f our bottom perfs to give our botto th sand. In addition to having des lorietta/Yeso formation at later time	rom 4023?-4202?. Idea m hole assembly room ired rathole space, this e.	ally, we like to l andipreventi	PITIONS O	F APPRO	VATIO
		NMOCD			ARTESIA DISTR	ME.
	Electronic Submission #289918	FING LLC. sent to the Ca	arlsbad ı 01/29/2015 (15		RECEIVE	D
Signature (Electroni	c Submission)	Date 01/29/20	015	APPRU)VED	
	THIS SPACE FOR FE	DERAL OR STATE	OFFICE USE	V /IAN 2 C	2015	//
				1/1/1/1/1/	1/	Ten 1
	hed. Approval of this notice does not war equitable title to those rights in the subject duct operations thereon.			BUREAU OF LAND CARLSBAD FIE	MACHENIENT LD OFFICE	
itle 18 U.S.C. Section 1001 and Title 4 States any false, fictitious or frauduler	43 U.S.C. Section 1212, make it a crime for a statements or representations as to any n	or any person knowingly and natter within its jurisdiction.	willfully to make	to any department or	agency of the Unite	:d
** BLM RE	VISED ** BLM REVISED ** BI	_M REVISED ** BLM	REVISED *	* BLM REVISEI	D **	
	·					

Additional data for EC transaction #289918 that would not fit on the form

32. Additional remarks, continued

- ? Unset pump and POOH with rod ? Tag for fill with tubing and POOH and bail if needed ? PU scraper and scrape down to 4600? ? POOH with tubing LD

- ? RU Wireline ? Set CIBP @ 4551? ? Wireline truck dump 40? Class C cement of top of CIBP
- ? Tag cement plug to verify depth of 4511? ? Pull up 4? to circulate hole clean with fresh water, and displace w/ 2% KCL and 1% packer corrosion inhibitor.
- ? Test Casing to 4,200 psi (max pressure for frac) and report back to engineering if the pressure
- ? Secure wellbore
- ? RDMO WSU

Tentative Recompletion Procedure

- ? NU frac valve, and test casing to 4200 psi ? Rig up wireline. ? RIH w/ perforating guns and perforate San Andres Zone from 3366?-4202?, w/ 3 spf, 60? phasing, ? Acidize w/ 1500 gals of 15% HCl. ? Frac zone w/ 440,000 # of sand. ? Record ISIP and FG, Get 5, 10, 15 min SIP

- ? Rig up Wireline
 ? Clean out fill to new PBTD @ 4511?
 ? RIH with production tubing and locate intake at 4250?.
 ? Set TAC @ 3300?
 ? RIH WO rig.

- ? RDMO rig.

McIntyre A East #15

We are going to set a CIBP at 4551' (50' above the YESO perfs) w/ 40' of CMT on top of the plug to have our PBTD @ 4511'. We plan to have our bottom perfs from 4023'-4202'. Ideally, we like to have 200'-300' of rathole below our bottom perfs to give our bottom hole assembly room and prevent tubing from getting stuck with sand. In addition to having desired rathole space, this gives COG the option to reenter the Glorietta/Yeso formation at later time.

Equipment Pull Procedure


- MIRU WSU, NU BOP
- Unset pump and POOH with rod
- Tag for fill with tubing and POOH and bail if needed
- PU scraper and scrape down to 4600'
- POOH with tubing LD
- RU Wireline
- Set CIBP @ 4551'
- Wireline truck dump 40' Class C cement of top of CIBP
- Tag cement plug to verify depth of 4511
- Pull up 4' to circulate hole clean with fresh water, and displace w/ 2% KCL and 1% packer corrosion inhibitor.
- Test Casing to 4,200 psi (max pressure for frac) and report back to engineering if the pressure holds.
- Secure wellbore
- RDMO WSU

Tentative Recompletion Procedure

- NU frac valve, and test casing to 4200 psi
- Rig up wireline.
- RIH w/ perforating guns and perforate San Andres Zone from 3366'-4202', w/ 3 spf, 60° phasing, 54 holes.
- Acidize w/ 1500 gals of 15% HCl.
- Frac zone w/ 440,000 # of sand.
- Record ISIP and FG, Get 5, 10, 15 min SIP
- Rig up Wireline
- Clean out fill to new PBTD @ 4511/
- RIH with production tubing and locate intake at 4250%.
- Set TAC @ 3300'
- RIH w/ rods and pump.
- RDMO rig.

COG Operating LLC

Lease & Well # McIntyre A East #15



COG Operating LLC

Lease & Well # McIntyre A East #15

Spud: 8/1/01 Elevation - 3623' KB -13 3/8" 48# h-40 STC csg @ 425', 450 sx. Circ 28 SX. 8 5/8" 32# 8rd J-55 STC @ 1230', 625 sx, circ. 117 sx Complete zones with 440,000# of proppant, 3366'-3558' 4500 gallons of 15% HCL 3729'-3909' 4023'-4202' DV tool -4017' CIBP @ 4551', with 40' of CMT above to PBTD of 4511 4601 Yeso 4601 - 4718.5', 1 spf 34 holes Marker jt @ 4606' Acidize 2000 gal 32,000gals 20% Acid htd, 54,000gals 40#gel htd, 5,000gals 15% cool down acid 4718.5 1st stage: 200 sx 50/50, circulated 50 sx. PBTD - 5022' 2nd stage: 850 sx, circulated 45 sx.

5 1/2" 17# J-55 LT&C csg @ 5033'.

Mcintyre A East 15 30-015-31854 COG Operating, LLC. January 29, 2015 Conditions of Approval

Notify BLM at 575-361-2822 a minimum of 24 hours prior to commencing work.

Work to be completed by April 29, 2015.

1. Operator shall set a CIBP at 4,551' and place 40' Class C cement on top. Tag required.

Note: At a later date, the Glorieta formation and the DV tool must be abandoned properly.

- 2. Must conduct a casing integrity test before perforating and fracturing. Submit results to BLM. The CIT is to be performed on the production casing to max treating pressure. Notify BLM if test fails.
- 3. Submit formation tops on a subsequent report as they are not in the file.
- 4. Before casing or a liner is added or replaced, prior BLM approval of the design is required. Use notice of intent Form 3160-5.
- 5. Surface disturbance beyond the originally approved pad must have prior approval.
- 6. Closed loop system required.
- 7. All waste (i.e. drilling fluids, trash, salts, chemicals, sewage, gray water, etc.) created as a result of work over operations shall be safely contained and disposed of properly at a waste disposal facility. No waste material or fluid shall be disposed of on the well location or surrounding area. Porto-johns and trash containers will be on-location during fracturing operations or any other crew-intensive operations.
- 8. Operator to have H2S monitoring equipment on location.
- 9. A minimum of a **2000** (**2M**) BOP to be used. All blowout preventer (BOP) and related equipment (BOPE) shall comply with reasonable well control requirements. A two ram system with a blind ram and a pipe ram designed for the size of the work string shall be adequate. Tapered work strings will require an additional pipe ram. The manifold shall comply with Onshore Oil and Gas Order #2 Attachment I (2M Diagrams of Choke Manifold Equipment). The accumulator system shall have an immediately available power source to close the rams and retain 200 psi above pre-charge. The pre-charge test shall follow requirements in Onshore Order #2.

- 10. Subsequent sundry required detailing work done and completion report for the new formations. Operator to include well bore schematic of current well condition when work is complete.
- 11. See attached for general requirements.

JAM 012915

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

General Requirements for Plug Backs

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from this approval.

If you are unable to plug back the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged back. Failure to do so will result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plug back operations. For wells in Eddy County, call 575-361-2822.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. Before pumping cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either **Neat Class** "C", for up to 7,500 feet of depth or **Neat Class** "H", for deeper than 7,500 feet plugs.

- 6. <u>Subsequent Plug back Reporting:</u> Within 30 days after plug back work is completed, file one original and three copies of the Subsequent Report, Form 3160-5 to BLM. The report should give in detail the manner in which the plug back work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. <u>Show date work was completed.</u>
- 7. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.