

| Submit 1 Copy To Appropriate District State of New Mexico | Form C-103 |
|--|---|
| District I – (575) 393-6161 1625 N. French Dr., Haim MissooNSERVATION | Revised July 18, 2013 WELL API NO. |
| District II - (5/5) /48-1283 ARTESIA DISTRICTUL CONSERVATION DIVISION | 30-015-27027 |
| District III – (505) 334-6178 MAY 0 1 2015 1220 South St. Francis Dr. | 5. Indicate Type of Lease STATE FEE |
| 1000 Rio Brazos Rd., Aztec, NM 87410 District IV ~ (505) 476-3460 Santa Fe, NM 87505 | 6. State Oil & Gas Lease No. |
| 1220 S. St. Francis Dr., Santa Fe, NECEIVED | |
| SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH | 7. Lease Name or Unit Agreement Name John AGU |
| PROPOSALS.) | 8. Well Number |
| 1. Type of Well: Oil Well Gas Well Other 2. Name of Operator | 9. OGRID Number |
| Yates Petroleum Corporation | 025575 |
| 3. Address of Operator 105 South Fourth Street, Artesia, NM 88210 | 10. Pool name or Wildcat Cemetary; Wolfcamp, Gas |
| 4. Well Location | Centerary, woncamp, Gas |
| Unit Letter B : 710 feet from the North line and 1980 feet from the East line | |
| Section 14 Township 20S Range 24E | NMPM Eddy County |
| 11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3616'GR | |
| | |
| 12. Check Appropriate Box to Indicate Nature of Notice, | Report or Other Data |
| NOTICE OF INTENTION TO: SUB | SEQUENT REPORT OF: |
| PERFORM REMEDIAL WORK 🗌 PLUG AND ABANDON 🛛 🛛 REMEDIAL WOR | K 🗌 ALTERING CASING 🗌 |
| TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PAND A DULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT JOB | |
| PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMEN DOWNHOLE COMMINGLE I | |
| | _ |
| OTHER: OTHER: OTHER: | d give pertinent dates including estimated date |
| of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. | |
| Yates Petroleum Corporation plans to plug and abandon this well as follows: | |
| 1. MIRU all safety equipment as needed. NU BOP. | |
| RIH and tag existing CIBP at 6840' and dump 35' Class "H" cement on top. RIH with GR/JB and set a CIBP at 6614' and dump 25 sx Class "H" cement on top. This will cover Wolfcamp perfs. | |
| 4. Spot a 30 sx Class "C" cement plug from 5688'-5538'. WOC and tag. This will cover DV tool. | |
| Spot a 35 sx Class "C" cement plug from 5328'-5128'. This will cover top of Abo. Spot a 25 sx Class "C" cement plug from 2128'-1988'. This will cover top of Glorieta. | |
| Spot a 25 sx Class "C" cement plug from 1125'-1015'. WOC and tag. This will cover " | |
| 8. Spot a 35 sx Class "C" cement plug from 175' up to surface. | Approved for plugging of well bore only. |
| Cut off wellhead, install dry hole marker and clean location. Wellbore schematics attached | Liability under bond is retained pending receipt of C-103 (Subsequent Report of Well Plugging) which may be found at OCD Web Page under |
| Spud Date: Rig Release Date: | Forms, www.cmnrd.state.nm.us/ocd. |
| well Bore must be Alussed by 5/7/2016 | |
| I hereby certify that the information above is true and complete to the best of my knowledge and belief. | |
| SIGNATURE Charles TITLE Regulatory Reporting Supervisor DATE April 29, 2015 | |
| Type or print name Tina Huerta E-mail address: tinah@yatespetroleum.com PHONE: 575-748-4168 For State Use Only O I I I I I | |
| APPROVED BY: TITLE AST TO POWLSD DATE 5/7/15 Conditions of Approval (if any): | |
| ★ See Attended COA's | |





NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

CONDITIONS OF APPROVAL FOR PLUGGING & ABANDONMENT

Operator: Yates fet Well Name & Number: John Abu & 6 30-015-27/27 API #:

- 1. Produced water <u>will not</u> be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- 3. Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- 6. If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.
- 8. Cement Retainers may not be used.
- 9. Squeeze pressures are not to exceed 500 PSI, unless approval is given by NMOCD.

10. Plugs may be combined after consulting with and getting approval from NMOCD. 11. Minimum WOC time for tag plugs will be 4 Hrs.

DATE: 5-/7/15

APPROVED BY:

GUIDELINES FOR PLUGGING AND ABANDONMENT

DISTRICT II / ARTESIA

- All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater.
- Mud laden fluids must be placed between all cement plugs.
- Mud laden fluids must be mixed at 25 sacks of gel per 100 bbls of water.
- A cement plug is required to be set 50' below and 50' above all casing shoes and casing stub plugs. These plugs must be tagged.
- A CIBP with 35' of cement on top may be set in lieu of 100' cement plug.
- A plug as indicated above must be placed within 100' of top perforation. This plug must be tagged.
- Plugs set below and above salt zones must be tagged.
- No more than 2000' is to be allowed between cement plugs in open hole and no more than 3000' in cased hole.
- DV tools are required to have a 100' cement plug set 50' above and below the tool and must be tagged.
- Formations to be isolated with plugs placed at the top of each formation are:
 - o Fusselman
 - o Devonian
 - o Morrow
 - o Wolfcamp
 - o Bone Spring
 - o Delaware
 - Any Salt Section (Plug at top and bottom)
 - o Abo
 - o Glorieta
 - Yates (this plus is usually at base of salt section)
- If cement does not exist behind casing strings at recommended formation depths, the casing must be cut and pulled with plugs set at these depths or casing must be perforated and cement squeezed behind casing at the formation depths.
- In the R-111-P area (Potash Mine area) a solid cement plug must be set across the salt section.
 Fluid used to mix the cement shall be saturated with the salts common to the section penetrated and in suitable proportions, but not more than a 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible (50' below and 50' above).