
Submit I Copy To Appropriate District Office	State of New Mexico		Form C-103	
<u>District</u> 1 - (575) 393-6161	Energy, Minerals and Natural Reso	urces	Revised July 18, 2013	
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283	OH CONGERNATION PINAG	WELL API NO	30-005-64158	
811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVIS	5. Indicate Typ	e of Lease	
<u>District</u> <u>III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.	STATE	X FEE	
District IV – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505	Santa Fe, NM 87505	6. State Oil & 0 VO - 92		
	CES AND REPORTS ON WELLS		or Unit Agreement Name	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)		DAWC	DAWG	
1. Type of Well: Oil Well X Gas Well Other		8. Well Number	"-	
2. Name of Operator JALAPENO CORPORATION			9. OGRID Number 26307	
3. Address of Operator PO BOX 1608 ALBUQUERQUE, NM 87103			10. Pool name or Wildcat WILDCAT; SAN ANDRES	
4. Well Location	5ERQOE, 1414 07 103			
Unit Letter H	2225 feet from the NORTH lin	e and 704 feet f	rom the <u>EAST</u> line	
Section 21	Township 9S Range	27E NMPM	County Chaves	
	11. Elevation (Show whether DR, RKB, RX	T, GR, etc.)		
The state of the s			all all	
12. Check A	ppropriate Box to Indicate Nature of	Notice, Report or Othe	er Data	
NOTICE OF IN	TENTION TO:	SUBSEQUENT R	FPORT OF:	
PERFORM REMEDIAL WORK	ı	DIAL WORK	ALTERING CASING	
TEMPORARILY ABANDON	_	ENCE DRILLING OPNS.	P AND A	
PULL OR ALTER CASING DOWNHOLE COMMINGLE	MULTIPLE COMPL CASING	G/CEMENT JOB		
CLOSED-LOOP SYSTEM				
OTHER:	☐ OTHER			
	eted operations. (Clearly state all pertinent k). SEE RULE 19.15.7.14 NMAC. For Mompletion.			
PBTD OF THE WELL IS 2081'.	WE PROPOSE TO			
1. SET A CEMENT PLU	G FROM PBTD TO 50FT ABOVE TOP PERFOR			
 PULL PACKER OUT OF THE HOLE AND THEN SHOOT OFF 5 1/2' CASING AT 1544' IN ORDER TO SALVAGE CASING. WE WILL THEN WAIT ON CEMENT TO DRY AND GO TAG TOP AT 1985'. 				
	D FROM 1594' TO 1985'.			
5. FILL HOLE WITH MU	NT PLUG FROM 1494' TO 1594' - TAG. D FROM 100' TO 1494'.			
6. CEMENT 100' TO SU 7. WAIT FOR CEMENT		agging of well bore only.		
8. SET DRY HOLE MAR	KER Liability under b	ond is retained pending receipt quent Report of Well Plugging)	NM OIL CONSERVATION ARTESIA DISTRICT	
	which may be fo	und at OCD Web Page under		
	Forms, www.cmr	ird.state.nm.us/ocd.	JUN 2 2 2015	
			DECEIVED.	
Spud Date: 6/3/2013	Rig Release Date:	2/10/2014	RECEIVED	
well must be Plus				
	boye is true and complete to the best of my	knowledge and belief.		
	, , , , , , , , , , , , , , , , , , ,	J. T.		
SIGNATURE A	TITLE_Vice Presid	lent ı	DATE_ 6/18/2015	
Type or print name H. Emmons Yates III E-mail address:			PHONE: <u>505-242-205</u> 0	
For State Use Only				
APPROVED BY:	OL TITLE DISTATE	JOHNSO 1	DATE 6/23/2015	
Conditions of Approval (if any):			300	
See Attach	ed COAS			
_				


SCHEMATIC PRIOR TO PLUG AND ABANDON

JALAPENO CORPORATION DAWG #1 CHAVES COUNTY, NEW MEXICO API NO. 30-005-64158



SCHEMATIC AFTER PLUG AND ABANDON JALAPENO CORPORATION DAWG #1 CHAVES COUNTY, NEW MEXICO

API NO. 30-005-64158



Jalapeño Corporation

P.O. Box 1608 Albuquerque, NM 87103-1608

Phone: (505) 242-2050 Fax: (505) 242-8501

June 18, 2015 Sent Certified Mail #7010 0780 0000 6199 9607

Oil Conservation Division District II 811 South First Street Artesia, NM 88210

NM OIL CONSERVATION

ARTESIA DISTRICT

JUN 22 2015

RECEIVED

RE: Dawg #1

Well API No. 30-005-64158

Sec. 21, T-9S, R-27E Chaves County, NM

Dear Sir or Madam:

Enclosed please find the OCD Form C-103 regarding the plugging and abandonment for the Dawg #1 well.

If you have any questions or need further information, you can contact Emmons Yates at eyates@jalapenocorp.com or at the numbers listed above.

Sincerely,

Jun Barrack

Jalapeño Corporation

Oil and Gas Operations Associate

NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

CONDITIONS OF APPROVAL FOR PLUGGING & ABANDONMENT

Operator: Jalapeno Corp	
Well Name & Number: Daw9 #1	
API#: 30 · 005 - 64158	

- 1. Produced water <u>will not</u> be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- 3. Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- **6.** If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.
- 8. Cement Retainers may not be used.
- 9. Squeeze pressures are not to exceed 500 PSI, unless approval is given by NMOCD.
- 10. Plugs may be combined after consulting with and getting approval from NMOCD.
- 11. Minimum WOC time for tag plugs will be 4 Hrs.

AD 6/23/2015

GUIDELINES FOR PLUGGING AND ABANDONMENT

DISTRICT II / ARTESIA

- All cement plugs will be a minimum of 100 in length or a minimum of 25 sacks of cement, whichever is greater.
- Mud laden fluids must be placed between all cement plugs.
- Mud laden fluids must be mixed at 25 sacks of gel per 100 bbls of water.
- A cement plug is required to be set 50' below and 50' above all casing shoes and casing stub plugs. These plugs must be tagged.
- A CIBP with 35' of cement on top may be set in lieu of 100' cement plug.
- A plug as indicated above must be placed within 100' of top perforation. This plug must be tagged.
- Plugs set below and above salt zones must be tagged.
- No more than 2000' is to be allowed between cement plugs in open hole and no more than 3000' in cased hole.
- DV tools are required to have a 100' cement plug set 50' above and below the tool and must be tagged.
- Formations to be isolated with plugs placed at the top of each formation are:
 - o Fusselman
 - o **Devonian**
 - o Morrow
 - o Wolfcamp
 - o Bone Spring
 - o Delaware
 - Any Salt Section (Plug at top and bottom)
 - o Abo
 - o Glorieta
 - Yates (this plus is usually at base of salt section)
- If cement does not exist behind casing strings at recommended formation depths, the casing must be cut and pulled with plugs set at these depths or casing must be perforated and cement squeezed behind casing at the formation depths.
- In the R-111-P area (Potash Mine area) a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts common to the section penetrated and in suitable proportions, but not more than a 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible (50' below and 50' above).