tes To Appropriate District		New Mexico	Form C-103
<u> 41</u>	Energy, Minerals a	and Natural Resources	May 27, 2004 WELL API NO.
25 N. French Dr., Hobbs, NM 88240 District II			30-005-63745
1301 W. Grand Ave., Artesia, NM 88210		ATION DIVISION	5. Indicate Type of Lease
District III	1220 South	St. Francis Dr.	STATE FEE
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe	, NM 87505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505			
SUNDRY NOTICES AND REPORTS ON WELLS			7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH			
PROPOSALS.)		Sonar BGO State Com 8. Well Number	
1. Type of Well: Oil Well	Gas Well 🛛 Other	RECEIVED	8. Well Number
2. Name of Operator		FER 1 3 2006	9. OGRID Number
	on		025575
3. Address of Operator		OOD-WILL INCO	10. Pool name or Wildcat
105 S. 4 th Street, Artesia, 1	√M 88210		Wildcat Wolfcamp
4. Well Location			
Unit Letter G:	1980 feet from the	North line and	1980 feet from the East line
Section 36	Township 1	1S Range 26E	NMPM Chaves County
3728'GR			
Pit or Below-grade Tank Application □ or Closure □			
Pit type Depth to Groundwater Distance from nearest fresh water well Distance from nearest surface water			
Pit Liner Thickness: mil Below-Grade Tank: Volume bbls; Construction Material			
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data			
NOTICE OF IN	ITENTION TO:	SU	BSEQUENT REPORT OF:
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING			
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDON			
PULL OR ALTER CASING	MULTIPLE COMPL		
			_
of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion			
or recompletion.			
1/21/06 – Tested production casing	to 1000 psi for 30 min.		
1/23/06 – Perforate Silurian 6180'-6184' (20) and 6188'-6198' (44). Acidize with 250g 20% IC acid.			
1/26/06 – Re-acidize Silurian with 1000g 20%.			
2/3/06 – Set a CIBP at 6133' capped with 35' cement. Perforate Wolfcamp 5172'-5182' (11), 5188'-5200' (13), 5208'-5212' (5), 5216'-5220' (5), 5228', 5252' (25) and 5260', 5282' (22) for a total of 82 billion. Set a classic set 5122' A 1000 - 1500' (13), 5208' - 5212' (5), 5216'-			
3220 (3), 3220 -3232 (23) and 3200 -3202 (23) for a total of 62 notes. Set packer at 3123°. Acidize with 4000g 15% IC acid.			
	Perforator Perforation Perforate P		