Form 3160-5 (August 2007)

UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED
OMB NO. 1004-0135
Expires: July 31, 2010

SUNDRY Do not use thi abandoned we	NMNM0399448 If Indian, Allottee or Tribe Name						
SUBMIT IN TRI	7. If Unit or CA/Agreement, Name and/or No. NMNM85354						
Type of Well Oil Well	8. Well Name and No. MALONE ASA FED COM 1						
Name of Operator YATES PETROLEUM CORPO	9. API Well No. 30-015-30088-00-S1						
3a. Address 105 SOUTH FOURTH STREE ARTESIA, NM 88210	3b. Phone No. (include area code) Ph: 575-748-4168 Fx: 575-748-4585			10. Field and Pool, or Exploratory INDIAN BASIN			
4. Location of Well (Footage, Sec., T	, R., M., or Survey Description	1)			11. County or Parish	i, and State	
Sec 12 T22S R23E SWNE 18			·	EDDY COUNT	Y, NM		
12. CHECK APPI	ROPRIATE BOX(ES) TO	O INDICATE N	ATURE OF N	NOTICE, RE	PORT, OR OTHI	ER DATA	
TYPE OF SUBMISSION			FACTION				
Notice of Intent	☐ Acidize	☐ Deepe	n	☐ Production	on (Start/Resume)	□ Water Si	nut-Off
	☐ Alter Casing	☐ Fractu	re Treat	☐ Reclamat	tion	☐ Well Into	egrity
☐ Subsequent Report	□ Casing Repair	□ New C	Construction	☐ Recompl	ete	Other	
☐ Final Abandonment Notice	Change Plans	🛛 Plug a:	nd Abandon	☐ Tempora	rily Abandon		
	☐ Convert to Injection ☐ Plug Back ☐ Water Dispo				sposal		
If the proposal is to deepen directions Attach the Bond under which the wor following completion of the involved testing has been completed. Final At determined that the site is ready for fix Yates Petroleum Corporation 1. MIRU all safety equipment is production equipment if any expenses.	k will be performed or provide operations. If the operation re- candonment Notices shall be fil- inal inspection.) plans to plug and abando as needed. NU BOP. No	the Bond No. on fi sults in a multiple c led only after all req on this well as fo o casing recover	ile with BLM/BIA completion or reco juirements, includ follows: ry will be attern	a. Required subsompletion in a neiling reclamation,	equent reports shall be we interval, a Form 31 have been completed	e filed within 30 (160-4 shall be filed), and the operator	days d once r has
production equipment if any example 2. Run a GR and set a CIBP a over the open Canyon perfs. 3. Spot a 170 ft Class H ceme	t 7512 ft and cap it with j nt plug from 6688 ft - 685	25 sx Class H ce 58 ft. This will le	ement. This w eave a plug ac	ill place a plu ross the	g Min. K(A)	ARTESIA DIS	TRICT
Wolfcamp top. 4. Spot a 170 ft Class C ceme 5. We do not know where the	nt plug from 4518 ft - 468 TOC is, a CBL was pulled	38 ft. This is ius	t a spacer pluc	· a.		MAY 09	2016
cement, so the TOC is above 6. Perforate at 2780 ft. Pressi	a 170 ft	SEE ATT/	4 C NEDER	JAP .			
RECL		£	ONS OF A				
14. I hereby certify that the foregoing is Com Name (Printed/Typed) TINA HUE	# Electronic Submission For YATES PETR Imitted to AFMSS for proc	OLEUM CORPOR essing by PRISC	RÁTION, sent to CILLA PEREZ o	o the Carlsbac n 03/07/2016 (eq tor rec	
Signature (Electronic S	Submission)	1	Date 03/04/2	016	, cep	ed 10CD	
	THIS SPACE FO	OR FEDERAL	OR STATE	OFFICE US	E	1.	
Approved By M. Jublu			Title Eng			Date -	5/2/16
Conditions of approval, if any, are attached certify that the applicant holds legal or equivalent to condu- which would entitle the applicant to condu-	itable title to those rights in the	e subject lease	Office CFC)			
Fitle 18 H.S.C. Section 1001 and Title 43	U.S.C. Section 1212 make it a	crime for any nerse	on knowingly and	willfully to mak	e to any denartment	or agency of the I	Inited

Additional data for EC transaction #332880 that would not fit on the form

22. Additional remarks, continued plug inside the casing from 2610 ft - 2780 ft. WOC and tag plug, reset if necessary. This will leave a plug across the Bone Spring top.

7. Perforate at 2390 ft. Pressure test the perfs to 500 psi, if they hold pressure spot a 320 ft plug inside the casing, if not spot a 320 ft plug inside and outside the casing from 2070 ft - 2390 ft. WOC and tag plug, reset if necessary. This will leave a plug across the Glorieta top and the casing shoe. casing shoe.

8. Perforate at 400 ft. Pressure test the perfs to 500 psi, if they hold pressure spot a 400 ft plug inside the casing, if not spot a 400 ft plug inside and outside the casing from 0 - 400 ft.

WOC and tag plug, reset if necessary. This will leave a plug across the casing shoe and form a surface plug.

9. Remove all surface equipment and weld dry hole marker per regulations.

Wellbore schematics attached

VELL NAME: Malone ASA Fe		FIELD:	Indian Basin					
-	FNL & 1650' FEL, S12-T22S-R23E			Eddy County NM				
GL: <u>3986'</u> ZERO:	KB:4,000'	CASING PROGRAM						
	OMPLETION DATE:	<u>5-26-98</u>	13-3/8" 48#		350'			
COMMENTS: Lost circulation of								
cement on the long string and bumped plug 20 bbls early API No. 30-015-30088			9-5/8" 36# J55 ST&C		2,340'			
711 110. 00 010 00000			-		 			
C I A Commission	Perf @	100' spot a 400' plug to 400'; across CSG	Surface 7° 26# J55 374.	70'				
\\	shoe and	to form a surface	7" 23# J55 4887.64'					
7-1/2" Hole	plug.		7" 26# J55 1985.4 7" 26# N80 772.5					
			Bottom	, , , , , , , , , , , , , , , , , , ,	8,010'			
		'8" @ 350'						
		600 sx, 1" ed to ce w/ 60 sx(circ)			After			
	/ surre	ce w/ oo sx(circ)		Format	ion Tops			
12 1/4" Hole				San Andres	735'			
) \				Glorieta Bone Sprin	2174' gs 2730'			
				Wolfcamp	6808'			
(/			•	Canyon	7549'			
)\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \\ \				<u> </u>				
		001						
9-5/8" @ 2,340"	Peri (@ 2,3	90 spot a 320 ping from	n -2,070' to 2,390'; across	OL top & CSG s	noe.			
w/ 900 sx, 1"ed to surface w/ 650 sx	Perf @ 2,78	0' spot a 170' plug from	2,610' to 2,780'; across F	3S top.				
Est. TOC = ?'	**************************************	plug from 4,518' to 4,6	88°; spacer plug.					
Only ran CBL/CCL/GR log								
III P P P TO TO SOUTH	Spot a 170	plug from 6,688' to 6,85	8'; across WC top.	•				
8-3/4" Hole	- \ (
0-0/4 10/0	(/)	45						
	CIDE O 15	12' W\ 25 sx cmt.						
		12 W(23 SX CIN.	•					
	7,562' - 7,6	664' (39)						
	7748' 77	98' (15) squeezed						
$\langle \cdot \rangle$) / / D		0210					
\ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \ \		7,867' W\ full open 2-7/	6 I.D.					
	7,947' - 7,9	53. (8)						
	\)							
•	7" @ 8,010' w	\ 950 sx			Not to Scale			
TD 8,0					1/13/16 JMH			
PBID	C\$.00¢, 1							
	7,988.93'				ЈМН			

FIELD: WELL NAME: Malone ASA Fed Com #1 Indian Basin LOCATION: 1800' FNL & 1650' FEL, S12-T22S-R23E Eddy County NM GL: 3986' ZERO:__ **KB**: 4,000' **CASING PROGRAM** SPUD DATE: 2-28-98 COMPLETION DATE: 5-26-98 13-3/8" 48# 350' COMMENTS: Lost circulation displacing with nitrified mud ahead of cement on the long string and bumped plug 20 bbls early 9-5/8" 36# J55 ST&C 2,340' API No. 30-015-30088 Surface 7" 26# J55 374.70' 7" 23# J55 4887.64' 7" 26# J55 1985.47' 17-1/2" Hole 7" 26# N80, 772.51' 8,010' Bottom 13-3/8" @ 350" Before w/ 600 sx, 1" ed to surface w/ 60 sx(circ) Formation Tops San Andres 735' 12 1/4" Hole Glorieta 2174' Bone Springs 2730' Wolfcamp 6808' Canyon 7549 9-5/8" @ 2,340" w/ 900 sx, 1"ed to surface w/ 650 sx (circ) Est. TOC = ?' Only ran CBL/CCL/GR log from PBTD to 6000' 8-3/4" Hole 7,562' - 7,664' (39) 7,748' - 7,798' (15) squeezed Parted RBP @ 7,867' W\ full open 2-7/8" I.D. 7,947' - 7,963' (9) 7" @ 8,010' w\ 950 sx Not to Scale 1/13/16 TD 8,010' JMH PBTD 7,988.93'

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. Dry Hole Marker: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**
- 8. <u>Trash</u>: All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation objectives.



United States Department of the Interior

BUREAU OF LAND MANAGEMENT

Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

Reclamation Objectives and Procedures

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its predisturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, redistribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

- The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of
 Operations must include adequate measures for stabilization and reclamation of disturbed lands.
 Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD
 process as per Onshore Oil and Gas Order No. 1.
- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.

- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.
- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos Supervisory Petroleum Engineering Tech 575-234-5909, 575-361-2648 (Cell)

Arthur Arias Environmental Protection Specialist 575-234-6230

Linda Denniston Environmental Protection Specialist 575-234-5974

Henryetta Price Environmental Protection Specialist 575-234-5951

Dara Glass
Environmental Protection Specialist
575-234-5924

Shelly Tucker Environmental Protection Specialist 575-234-5979