

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
March 4, 2004

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. 30-015-04949
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name North Square Lake Unit
8. Well Number 127
9. OGRID Number 216852
10. Pool name or Wildcat Square Lake GB SA

SUNDRY NOTICES AND REPORTS ON WELLS  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  
PROPOSALS.)

1. Type of Well:  
Oil Well ☐ Gas Well ☐ Other Water Injection

2. Name of Operator  
CBS Operating Corp.

3. Address of Operator  
P O Box 2236, Midland TX 79702

4. Well Location

Unit Letter H : 3300 feet from the south line and 675 feet from the east line

Section 31 Township 16S Range 31E NMPM Eddy County NM

11. Elevation (Show whether DR, RKB, RT, GR, etc.)  
3852' GR

Pit or Below-grade Tank Application (For pit or below-grade tank closures, a form C-144 must be attached)

Pit Location: UL      Sect      Twp      Rng      Pit type      Depth to Groundwater      Distance from nearest fresh water well       
Distance from nearest surface water      Below-grade Tank Location UL      Sect      Twp      Rng      ;  
     feet from the      line and      feet from the      line

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐ CHANGE PLANS ☐

PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

See attached

**Notify OCD 24 hrs. prior  
To any work done.**

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE M. A. Sirgo TITLE Engineer DATE 3-22-06

Type or print name M. A. Sirgo, III E-mail address: mastres@aol.com Telephone No. 432/685-0878

(This space for State use)

APPROVED BY [Signature] TITLE Field Sup DATE 3/30/06

Conditions of approval, if any:

**If earthen pits are used in  
association with this work a  
pit permit is required prior  
to construction.**

**CBS OPERATING CORP.**  
**PLUGGING PROCEDURE FOR NORTH SQUARE LAKE UNIT WELL NO. 127**

1. Rig up pulling unit.
2. Install and test BOP.
3. TOH with tubing and packer.
4. Set CIBP within 100' of the top perf (see attached well bore diagram).
5. RIH with packer and establish where the casing leak is. Note: holes in casing should be shallow (300' to 600') based on other wells in this area that had leaks. Set packer 50' below casing leak and pressure up tubing and casing to 500# for 15' to check casing integrity. TOH with packer.
6. RIH with tubing open ended and spot 50' of cement on top of CIBP. Spot sufficient volume of gel mud to cover 5-1/2" shoe. Spot 100'+ cement, sufficient to bring plug 50'+ above top of liner and 50'+ below 5-1/2" casing shoe. TOH with tubing.
7. RIH with packer and squeeze holes in casing with enough cement to bring the cement top behind the casing up to the top of the salt. WOC. Test casing to 500# for 15 minutes. TOH with packer.
8. RIH with tubing open ended and tag plug set across 5-1/2" shoe. Pick up and circulate hole with plugging mud. Pick up and pump 100'+ cement plug across 8-5/8" shoe, sufficient to bring plug 50'+ above top of shoe and 50'+ below 8-5/8" casing shoe. PU and WOC.
9. Tag plug set across 8-5/8" shoe. PU and set surface plug.
10. Cut off casing and set dry hole marker.
11. Clean and remediate location.

Note: The BLM and NMOCD will be notified at least 24 hours before starting work on well.

CBS OPERATING CORP.

North Square Lake Unit 127

GRIER FEDERAL #7-Y  
3300' FSL & 675' FEL  
SEC 31, T16S, R31E  
EDDY COUNTY, NEW MEXICO

TD. 3373'

