
	Form C-103		
<u>District I</u> – (575) 393-6161 MM OIL IGONG BUNNERICand Natural Resources	Revised July 18, 201		
1625 N. French Dr., Hobbs, NM 88240 ARTESIA DISTRICT	WELL API NO.		
District II – (575) 748-1283 811 S. First St. Artesia, NM 88210 AFQLD CONSERVATION DIVISION	30-015-36197		
811 S. First St., Artesia, NM 88210Applie Collignment of the col	5. Indicate Type of Lease		
	STATE 🛛 FEE 🗌		
District IV – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	6. State Oil & Gas Lease No.		
87505 SUNDRY NOTICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name		
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A			
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	COTTON DRAW		
PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other	8. Well Number		
	111 111		
2. Name of Operator	9. OGRID Number 6137		
Devon Energy Production Company, LP 3. Address of Operator	10. Pool name or Wildcat		
333 W. Sheridan Avenue, Oklahoma City, OK 73102	COTTON DRAW;BRUSHY CANYON		
4. Well Location			
	fact from the West line		
Unit Letter C : 660_feet from theNorth line and1980	feet from theVestline		
Section 36 Township 24S Range 31E	NMPM Eddy County, NM		
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3517' KB; 3503' GL; 14' KB to GL			
12. Check Appropriate Box to Indicate Nature of Notice, I	Report or Other Data		
•••••	-		
NOTICE OF INTENTION TO: SUBS	SEQUENT REPORT OF:		
PERFORM REMEDIAL WORK 🔲 PLUG AND ABANDON 🛛 🛛 REMEDIAL WORK	K 🛛 🗌 ALTERING CASING 🗌		
TEMPORARILY ABANDON 🔲 CHANGE PLANS 🔲 COMMENCE DRIL	LLING OPNS. 🔲 PAND A		
PULL OR ALTER CASING I MULTIPLE COMPL CASING/CEMENT	ЈОВ 🗌		
CLOSED-LOOP SYSTEM			
OTHER: OTHER:			
12 Decombe proposed or commisted anomations II leaves state all mentionent details and			
13. Describe proposed or completed operations. (Clearly state all pertinent details, and			
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Con			
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Con proposed completion or recompletion.			
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Con proposed completion or recompletion.1. MIRU for P&A.			
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Conproposed completion or recompletion. 1. MIRU for P&A. 2. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. 2. State 1/2" CUPP @ (202). The black of the state of 100 mm assembly from 100 mm. 	npletions: Attach wellbore diagram of		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. 1. MIRU for P&A. 2. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. 3. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. 4. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC 	npletions: Attach wellbore diagram of		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Conproposed completion or recompletion. 1. MIRU for P&A. 2. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. 3. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. 4. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J-TAC 5. Spot 25 sx (250') Cl C @ 4,490' - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 	npletions: Attach wellbore diagram of 4490^{\prime} ag shoe @ 4,372')		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. 1. MIRU for P&A. 2. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. 3. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. 4. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J-TAC 5. Spot 25 sx (250') Cl C @ 4,490' - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 	npletions: Attach wellbore diagram of 4490^{\prime} ag shoe @ 4,372')		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. 1. MIRU for P&A. 2. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. 3. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. 4. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J-TAC 5. Spot 25 sx (250') Cl C @ 4,490' - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casing % 1,180'. 6. Perf 5-1/2" casing @ 1,180'. 7. Pump 120 sx (500') Cl C in/out @ 1,180'. 	npletions: Attach wellbore diagram of 4490^{7} ng shoe @ 4,372') D'; B.Salt @ 1080'; T.Salt @ 979')		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC I TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 6. Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180' Perf 5-1/2" casing @ 140'. Pump 35 sx Cl C in/out to surface. 	npletions: Attach wellbore diagram of -4480' ng shoe @ 4,372') D'; B.Salt @ 1080'; T.Salt @ 979') RF @ $735' - 5R - WOCH T$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. 1. MIRU for P&A. 2. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. 3. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. 4. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J-TAC 5. Spot 25 sx (250') Cl C @ 4,490' - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casing % 1,180'. 7. Pump 120 sx (500') Cl C in/out @ 1,180' - 690'. Tag TOC (3000' spacer @ 1180') 	npletions: Attach wellbore diagram of -4480^{\prime} ng shoe @ 4,372') D'; B.Salt @ 1080'; T.Salt @ 979') RF @ 735^{\prime} - SQ - WOCH T		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 6. Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180'	npletions: Attach wellbore diagram of 4480' ng shoe @ 4,372') 2'; B.Salt @ 1080'; T.Salt @ 979') $2F @ 735' - 5Q - WOCD T 2000^{10}$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180' - 590'. Tag TOC (3000' spacer @ 1180'). Perf 5-1/2" casing @ 140'. Pump 35 sx Cl C in/out to surface. PERF SUL Cut wellhead off, 3' BGL. Set dry hole marker. 	npletions: Attach wellbore diagram of 4480' ng shoe @ 4,372') 2'; B.Salt @ 1080'; T.Salt @ 979') $2F @ 735' - 5Q - WOCD T 2000^{10}$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC Spot 25 sx (250') Cl C @ 4,490' - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180' - 590'. Tag TOC (3000' spacer @ 1180'). Perf 5-1/2" casing @ 140'. Pump 35 sx Cl C In/out to surface. PLAF SUL Cut wellhead off, 3' BGL. Set dry hole marker. 	npletions: Attach wellbore diagram of 4480' ng shoe @ 4,372') 2'; B.Salt @ 1080'; T.Salt @ 979') $2F @ 735' - 5Q - WOCD T 2^{ORNY}; receipt$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180' - 590'. Tag TOC (3000' spacer @ 1180'). Perf 5-1/2" casing @ 140'. Pump 35 sx Cl C in/out to surface. PERF SUL Cut wellhead off, 3' BGL. Set dry hole marker. 	npletions: Attach wellbore diagram of 4480' ng shoe @ 4,372') 2735' - 5Q - WOCOTA $435' + 5Q - WOCOTA$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180' - 690'. Tag TOC (3000' spacer @ 1180'. Perf 5-1/2" casing @ 140'. Pump 35 sx Cl C in/out to surface. PERF SUL Cut wellhead off, 3' BGL. Set dry hole marker. 	npletions: Attach wellbore diagram of 4480' ng shoe @ 4,372') 2'; B.Salt @ 1080'; T.Salt @ 979') $2F @ 735' - 5Q - WOCD T 2^{ORNY}; receipt$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 6. Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180'	npletions: Attach wellbore diagram of 4480' ng shoe @ 4,372') 2'; B.Salt @ 1080'; T.Salt @ 979') $2F @ 735' - 5Q - WOCD T 2^{ORNY}; receipt$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 6. Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180'	npletions: Attach wellbore diagram of 4480' ng shoe @ 4,372') 2735' - 5Q - WOCOTA $435' + 5Q - WOCOTA$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 6. Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180'	npletions: Attach wellbore diagram of 4480' ng shoe @ 4,372') 2735' - 5Q - WOCOTA $435' + 5Q - WOCOTA$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180' - 690'. Tag TOC (3000' spacer @ 1180'. Perf 5-1/2" casing @ 140'. Pump 35 sx Cl C in/out to surface. PERF SUL Cut wellhead off, 3' BGL. Set dry hole marker. 	npletions: Attach wellbore diagram of 4480' ng shoe @ 4,372') 2'; B.Salt @ 1080'; T.Salt @ 979') $2F @ 735' - 5Q - WOCD T 2^{ORNY}; receipt$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC J TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 6. Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180'	npletions: Attach wellbore diagram of 4480' ng shoe @ 4,372') 2735' - 5Q - WOCOTA $435' + 5Q - WOCOTA$		
 of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Comproposed completion or recompletion. MIRU for P&A. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. Spot 25 sx (250') Cl C @ 6,600' - 6,350' WOC 1-TAC Spot 25 sx (250') Cl C @ 4,490 - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 6. Perf 5-1/2" casing @ 1,180'. Pump 120 sx (500') Cl C in/out @ 1,180' Perf 5-1/2" casing @ 140'. Pump 35 sx Cl C in/out to surface. 	hpletions: Attach wellbore diagram of 44480' 1000', $1000'$, $1000'$		
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Con proposed completion or recompletion. 1. MIRU for P&A. 2. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. 3. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. 4. Spot 25 sx (250') CI C @ 6,600' - 6,350'. — WOC I THO 5. Spot 25 sx (250') CI C @ 4,490' - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 6. Perf 5-1/2" casing @ 1,180'. 7. Pump 120 sx (500') CI C in/out @ 1,180' 275 6. Perf 5-1/2" casing @ 140'. Pump 35 sx CI C in/out to surface. 7. Pump 120 sx (500') CI C in/out @ 1,180' 280'. Tag TOC (3000' spacer @ 1180'. 8. Perf 5-1/2" casing @ 140'. Pump 35 sx CI C in/out to surface. 7. Pump 120 sx (500') CI C in/out @ 1,180' 280'. Tag TOC (3000' spacer @ 1180'. 8. Perf 5-1/2" casing @ 140'. Pump 35 sx CI C in/out to surface. 7. Pump 120 sx (500') M Sole. Set dry hole marker. 8. Spud Date: 8. Rig Release Date: 8. Rig Release Date: 8. Rig Release Date: 8. SignATURE Romit Sher PLURGEN BY 4/7/18 9. Intereby certify that the information above is true and complete to the best of my knowledge 8. SIGNATURE Romit Slack E-mail address: Ronnie.Slack@dvn.com PHI 6. For State Use Only	npletions: Attach wellbore diagram of 44480' ng shoe @ 4,372') D'; B.Salt @ 1080'; T.Salt @ 979') 2' = 735' - 50 - W000' 735' - 50 - W000' 735' - 50 - W000' 1000' = 000'' = 00'' = 000'' = 00'' = 00'' = 00'' = 00''''''''		
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Con proposed completion or recompletion. 1. MIRU for P&A. 2. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. 3. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. 4. Spot 25 sx (250') C1 C @ 6,600' - 6,350'. — WOC I THO 15. Spece 25 sx (250') C1 C @ 4,490' - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 7. Pump 120 sx (500') C1 C in/out @ 1,180' 275 7. Pump 120 sx (500') C1 C in/out @ 1,180' 275 275 279 279 279 279 279 279 279 279 279 279	npletions: Attach wellbore diagram of 44480' ng shoe @ 4,372') D'; B.Salt @ 1080'; T.Salt @ 979') 2735' - 50 - WOCH $735' - 50 - WOCH 735' - 50 - WOCH 1000000000000000000000000000000000000$		
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Con proposed completion or recompletion. 1. MIRU for P&A. 2. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. 3. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. 4. Spot 25 sx (250') CI C @ 6,600' - 6,350' WOC ATAC. 15. Spece 25 sx (250') CI C @ 4,490' - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 76. Perf 5-1/2" casing @ 1,180'. 77. Pump 120 sx (500') CI C in/out @ 1,180'. 77. Pump 120 sx (500') CI C in/out @ 1,180'. 78. Perf 5-1/2" casing @ 140'. Pump 35 sx CI C in/out to surface. 79. Cut wellhead off, 3' BGL. Set dry hole marker. Spud Date: 79. Cut wellhead off, 3' BGL. Set dry hole marker. Spud Date: 70. Rig Release Date: 71. Rig Release Date: 72. Rig Release Date: 73. Rig Release Date: 74. Production Technologist 74. Start Use Only 75. Support of the information above is true and complete to the best of my knowledge 75. SIGNATURE Romine Slack E-mail address: Ronnie.Slack@dvn.com PHE 75. State Use Only 75. Romine Slack Market Romine Slack Complete to the best of my knowledge 75. State Use Only 75. Romine Slack Complete Romine Slack Complete Romine Slack@dvn.com PHE 75. State Use Only 75. Romine Slack Complete Romine Slack Complete Romine Slack@dvn.com PHE 75. State Use Only 75. Romine Slack Complete Romine Slack Complete Romine Slack@dvn.com PHE 75. State Use Only 75. S	npletions: Attach wellbore diagram of 44480' ng shoe @ 4,372') D'; B.Salt @ 1080'; T.Salt @ 979') 2' = 735' - 50 - W000' 735' - 50 - W000' 735' - 50 - W000' 1000' = 000'' = 00'' = 000'' = 00'' = 00'' = 00'' = 00''''''''		
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Con proposed completion or recompletion. 1. MIRU for P&A. 2. Retrieve 2-7/8" production tubing and rod pump assembly from 8,345'. 3. Set 5-1/2" CIBP @ 6,600'. Tag plug. Circulate w/10# mud. 4. Spot 25 sx (250') CI C @ 6,600' - 6,350'. — WOC I THO 5. Spot 25 sx (250') CI C @ 4,490' - 4,180'. Tag TOC. (T.Delaware @ 4,427'; Casin 6. Perf 5-1/2" casing @ 1,180'. 7. Pump 120 sx (500') CI C in/out @ 1,180' 275 6. Perf 5-1/2" casing @ 140'. Pump 35 sx CI C in/out to surface. 7. Pump 120 sx (500') CI C in/out @ 1,180' 280'. Tag TOC (3000' spacer @ 1180'. 8. Perf 5-1/2" casing @ 140'. Pump 35 sx CI C in/out to surface. 7. Pump 120 sx (500') CI C in/out @ 1,180' 280'. Tag TOC (3000' spacer @ 1180'. 8. Perf 5-1/2" casing @ 140'. Pump 35 sx CI C in/out to surface. 7. Pump 120 sx (500') M Sole. Set dry hole marker. 8. Spud Date: 8. Rig Release Date: 8. Rig Release Date: 8. Rig Release Date: 8. SignATURE Romit Sher PLURGEN BY 4/7/18 9. Intereby certify that the information above is true and complete to the best of my knowledge 8. SIGNATURE Romit Slack E-mail address: Ronnie.Slack@dvn.com PHI 6. For State Use Only	hpletions: Attach wellbore diagram of 44480' 1000', $1000'$, $1000'$		



、

DEVON ENERGY PRODUCTION COMPANY LP							
Well Name: COTTON DRAW UNIT 111		Field: PADU					
Location: 660' FNL & 1980' FWL; SEC 36-T245-R	31E	County: EDD		State: NM			
Elevation: 3517' KB; 3503' GL; 14' KB to GL		Spud Date: 4		Compl Date	B:		
API#: 30-015-36197 Prepared by: Ronnie Slack		Date: 4/3/17	<u>7</u>	Rev:			
CURRENT WELLBORE 17-1/2" Hole <u>13-3/8", 48#, H40, STC, @ 735'</u> Cmt'd w/700 sx to surface TOC @ 2,478'-CBL (6/4/08)					Rustler 710' T.Salt 979' B.Salt 1080' Lamar 4390' Bell Canyon 4427' Cherry Canyon 5310' Brushy Canyon 6670'		
11" Hole <u>8-5/8", 32#, J55, @ 4,372'</u> Cmt'd w/ 1115 sx to surface <u>DELAWARE</u> 6,640' - 6,652' (9/9/08)		編集 西部門道伊美 時間 東京日子 に建たって新学・11月 水江 キ がり そいがく ほうか 新学・11月 れい	256 Jts2-7	/8", 6.5#, J55 pı	rod tubing (2/9/09)		
6,640 - 6,652 (9/9/08) 7,287' - 7,295' (9/2/08) →		9 ນໍາ **					
7,480' - 7,485' (8/28/08) - 7,490' - 7,493' (8/28/08) - 7,497' - 7,502' (8/28/08) -		19 5 6 20					
8,058' - 8,080' (8/19/08) -			TAC @ 8,11	7' (2/9/09)			
8,174' - 8,180' (6/4/08) 8,224' - 8,228' (6/4/08) 8,300' - 8,303' (6/4/08)			7 Jts2-7/8" SN @ 8,345'	', 6.5#, J55 proc	d tubing (2/9/09) s; 1-1/2" X 25' rod pump		
7-7/8" Hole <u>5-1/2", 17#, N80 & J55, LTC, @ 9,735'</u> Cmt'd w/1500 sx		35' TD			:		

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 7. Produced water will not be used during any part of the plugging operation.
- 8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 9. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 10. Class 'C' cement will be used above 7500 feet.
- 11. Class 'H' cement will be used below 7500 feet.
- 12. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 13. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing
- 14. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 15. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.

- 16. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 17. No more than **3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
- 18. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 19. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)