
Submit 1 Copy To Appropriate District Office	State of frew friends	
<u>District 1</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	Energy, Minerals and Natural F	Resources Revised July 18, 2013 WELL API NO. 30-015-27254
<u>District II</u> ~ (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIV	5 Indicate Type of Lease
District III – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 8741	1220 South St. Francis Santa Fe, NM 87505	Dr. STATE FEE
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505	Santa 1 6, 1411 675 65	303271
SUNDRY NO (DO NOT USE THIS FORM FOR PRO DIFFERENT RESERVOIR. USE "AF	OTICES AND REPORTS ON WELLS OPOSALS TO DRILL OR TO DEEPEN OR PLUG BAPPLICATION FOR PERMIT" (FORM C-101) FOR SU	
PROPOSALS.) 1. Type of Well: Oil Well	,	8. Well Number ₀₁₁
2. Name of Operator RKI EXPLORATION & PRODUCTION, LLC		ON, LLC 9. OGRID Number 246289
3. Address of Operator _{3500 ON}	E WILLIAMS CENTER MD 35 DK 74172	10. Pool name or Wildcat HERRADURA BEND;DELAWARE, EAST
4. Well Location Unit Letter	990 feet from the	line and 400 feet from the W line
	Township 22S Range	28E NMPM EDDY County
	11. Elevation (Show whether DR, RKE	B, RT, GR, etc.)
	3,094' GR	
12. Chec	k Appropriate Box to Indicate Natur	e of Notice, Report or Other Data
NOTICE OF INTENTION TO: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING COMMENCE DRILLING OPNS. P AND A DOWNHOLE COMMINGLE CASING/CEMENT JOB CASING/		
CLOSED-LOOP SYSTEM OTHER:	О	HER:
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.		
RKI EXPLORATION AND PRODUCTION, LLC REQUESTS APPROVAL TO PLUG AND ABANDON THIS VELL.		
VBD'S AND PLAN ARE A	TTACHED	only. acipe
ADD O VIND I EVIN VIVE V	ATTACHED. Approved for Plumetry Approved fo	Wof well bore only receipt Wof well bore only receipt Is revained pending receipt Is revained pending receipt AM OIL CONSERVATION ARTESIA DISTRICT JUN 07 2017
	Approved under bed	Wof well bold pending with Plustander ARTESIA DISTRICT ARTESIA DISTRICT JUN 07 2017 RECEIVED
	Forms, WWW.can	RECEIVED
12/22/10		
Spud Date: 12/22/19	ı	02/06/1993
WELL MUST BE PLUCED BY 6/7/2018 I hereby certify that the information above is true and complete to the best of my knowledge and belief.		
•		my knowledge and belief.
SIGNATURE WWW O	TITLE	Technician II06/02/2017
Type or print name Caitlin O'Hair E-mail address: caitlin.o'hair@wpxenergy.com PHONE: 539-573-3527		
APPROVED BY: fue with Dyne TITLE Compriance of Files DATE 6/7/2017 Conditions of Approval (if any):		
SEE A	TTACHED COA-S	

PROCEDURE:

- 1) Test safety anchors and replace as necessary. Set 1 clean frac tank and fill with 480 BFW.
- 2) MIRU Service Unit. Deliver, unload and tally 5,600'- 2-3/8" 4.7# J-55 EUE work string.
- 3) ND WH, NU 3K# BOP.
- 4) POOH rods & tbg. & Lay Dn.
- 5) MI RU wireline unit. Run 5 1/2" GR/JB to 5,600'.
- 6) RIH w- 5 1/2" tbg. conveyed CIBP & set @ 5,600 PU 1 jt. Pump 135 bbls. heavy mud. Spot 25sx Class C Cement (14.8 ppg, 6.3 gps, 1.32 cfs yield) 5,600' 5,400' flush with heavy mud. TOOH w- tbg. WOE & THE
- 7) PU & LD tbg. to 4,600' Spot 30 sxs cmt from 4,600' 4,350'. WVC * TAC
- 8) PU & LD tbg. to 2,400' Spot 30 sxs. cmt from 2,400' 2,200'. 2900' TO COVER TOPOF DELAWARE

 9) RU WL & Perforate 4 holes @ 602'. RD MO wireline. ADD 14 PLUE PERF & SQ C 1415' to
- 9) RU WL & Perforate 4 holes @ 602'. RD MO wireline. AND AVLUE PEAF & SOF SALT WUE & THE
- 10) RIH w- Pkr & tbg. set Pkr Attempt to establish pump rate. Squeeze 60 sx Class C Cement (14.8 ppg, 6.3 gps, 1.32 cfs yield) from 602' to 450'.
- 11) WOC & Tag @ 450'.
- 12) RU WL Perf @ 200' -Attempt to circulate 60 sxs. cmt. to surface if unable to circulate, Spot 30 sxs. from 200' to surface.
- 13) RDMO Service Unit. RDMO Cementers.
- 14) MIRU Welder. Cut-off casing head. WO cap with well name and number, operator name, and date.
- 15) Pull safety anchors, dress, and reclaim surface location if necessary.

Pinnacle State #11 Proposed Plugged WB Les Peeler 05-24-17 30-015-27254 Proposed WBD Sctn 36, 22S, 28E Eddy Co., New Mexico Herradura Bend, East Delaware Field Spud: 12/22/92 Lease # V-3479 Completed: 12/31/92 Perf @200' Sqz. 60 sxs. from to surface if unable to sqz. spot 30 sxs.from 200' to surf. 8 5/8" 24 # (12 1/4" Hole) Csg. to 552' Cmt'd w-425 sxs to surface ADD A PLUE. PEAR & SQ @ 1415' TO COVER TOP OF SALT - WUE & TAG Perf @ 602' sqz 60 sxs. to 450' WOC & Tag PERF + SQUELZE @ 2900'TO WOC ATTHE COVER TOP OF Spot 30 Sxs. from 2400 - 2200 DEL AWARE 5 1/2" 15.5# (7 7/8" Hole) to 6373' Cmt'd w- 805 sxs. Spot 30 sxs. cmt. from 4600' - 4350' DV Tool 4,500' WOCS THE e weer the Set CIBP @ 5600' & Spot 25 sxs cmt. on top Delaware 5686'-5716', 5725-56', 5,807'-26', Brushy Canyon 5966' -6000' 6063' -72', 6086'-98', 6104'-20' Lower Brushy Canyon 6144'-58' PBTD - 6,280' 6188' -6214' TD @ 6,373'



CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 7. Produced water will not be used during any part of the plugging operation.
- 8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 9. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 10. Class 'C' cement will be used above 7500 feet.
- 11. Class 'H' cement will be used below 7500 feet.
- 12. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 13. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing
- 14. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 15. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.

- 16. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 17. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 18. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 19. **If cement does not exist behind casing strings at recommended formation depths,** the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)