Submit 1 Copy To Appropriate District	State of New Mexico		Form C-103		
Office Energy District I - (575) 393-6161 Energy	5) 393-6161 Energy, Minerals and Natural Resources		Revised July 18, 2013		
1625 N. French Dr., Hobbs, NM 88240 District II – (575) 748-1283	1625 N. French Dr., Hobbs, NM 88240		WELL API NO.		
811 S. First St., Artesia, NM 88210 OIL	CONSERVATION	DIVISION	5 Indicate Type of Lease		
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd. Aztec. NM 87410	1220 South St. Fran	cis Dr.	STATE FEE		
District IV – (505) 476-3460	Santa Fe, NM 87	505	6. State Oil & Gas Lease No.		
1220 S. St. Francis Dr., Santa Fc, NM 87505			B-8096		
SUNDRY NOTICES AND REPORTS ON WELLS			7. Lease Name or Unit Agreement Name		
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH			0		
PROPOSALS.)			8 Well Number 005		
1. Type of Well: Oil Well 🔯 Gas Well 🗋 Other					
Breitburn Operating LP			370080		
3. Address of Operator			10. Pool name or Wildcat		
1111 Bagby Street, Suite 1600 Houston, Texas 77002			Millman; Yates-SR-QN-GB-SA East (46555)		
4. Well Location					
Unit Letter: <u>F</u> 2180 feet from the]	North line and <u>1740</u> fe	et from the <u>West</u> lin	ne		
Section 7	Township 198	Range 29E	NMPM Eddy County		
11. Eleva	tion (Show whether DR, R	KKB, R1, GR, etc.)			
5511 3	**************************************	·····			
12. Check Appropria	te Box to Indicate N	ature of Notice.	Report or Other Data		
NOTICE OF INTENTIO	NOTICE OF INTENTION TO: SUB				
PULL OR ALTER CASING MULTIPL		CASING/CEMENT			
	_		_		
OTHER: 13 Describe proposed or completed operation	tions (Clearly state all r	OTHER:	d aive pertinent dates including estimated date		
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of					
proposed completion or recompletion.					
Breitburn Operating LP proposes to plug and abandon this well in August/September 2017. Procedure as follows:					
Notify NMOCD 24 hours in advance of beginning P&A					
MIRÚ PU. ND WH, NU BOP.					
Unseat packer and TOH with tubing TIH with CIBP and set at 1900' duran 20 sy Class C cement plug, mixed @ 14.8 ppg, 1.32 yield on top, WOC and tag					
Load hole with plug mud.					
Pull up and spot 30 sx Class C cement mixed @ 14.8 ppg, 1.32 yield from 1146' - 712' to isolate 7 Rivers and Yates Zones.					
Perf @ 421'. Set 20 sx Class C cement mixed @ 14.8 ppg, 1.32 yield from $420^{\circ} - 132^{\circ}$ to isolate sait Zone. WOC and tag.					
required, recalculate volume to cover required footage) WOED 1746					
Pert (0) 60°, circulate cement to surface. Cut off all cses and weld on 1/2° steel plate.					
Erect dead well marker			Il bore ending lugarter		
(See attached wellbore diagram)			Not welled to Well all all all all all all all all all		
02/02/1982		[plusting record web cd.		
Spud Date:	Rig Release Date:		ndier heuuent och inn.us		
I hereby certify that the information above is true and complete to the best of my knowledge and belief. (1) (1) (2) (2) (2) (2) (2) (2) (2) (2) (2) (2					
which are a star					
SIGNATURE TITLE Agent DATE: August 8, 2017					
Type or print name Shelly Doescher E-mail address: <u>shelly doescher@yahoo.com</u> PHONE: 505-320-5682					
APPROVED BY: Mabet 2 By u TITLE COMPLIANCE OFFICER DATE & 19/2017					
WELL MUST BE PLUGGED BY 81412018					
Conditions of Approval (if any):					

A SEE	ATTACHED	COA-S
W JEE		





CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 7. Produced water will not be used during any part of the plugging operation.
- 8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 10. Class 'C' cement will be used above 7500 feet.
- 11. Class 'H' cement will be used below 7500 feet.
- 12. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 13. All Casing Shoes Will Be Perforated and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing
- 14. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 15. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 18. No more than **3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
- 19. Any Production Formations will be isolated with cement plugs: Some of these are:
 - A) Strawn, Fusselman, Devonian, Marrow, Atoka, Wolfcamp, Bone springs, Delaware, San Andres, Abo, Glorieta, Any Salt Section, (Potash), Grayburg, Queen, Yates, Tubb, 7-Rivers
 - B) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 20. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)