Submit 1 Copy To Appropriate District Office	State of New Mo		Form C-103
<u>District 1</u> – (575) 393-6161	Engage Minorals and Natural Decourage		Revised July 18, 2013 WELL API NO. 20 04F 2F9C4
<u>District II</u> - (575) 748-1283	District II - (575) 748-1283 OIL CONSEDVATION DIVISION		30-015-35864
District III – (505) 334-6178 1220 South St. Francis Dr.		5. Indicate Type of Lease STATE FEE	
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, NM 8	7505	6. State Oil & Gas Lease No.
87505		303271	
SUNDRY NOTICES AND REPORTS ON WELLS  (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH  PROPOSALS.)			7. Lease Name or Unit Agreement Name PINNACLE STATE
1. Type of Well: Oil Well Gas Well Other		8. Well Number 017	
2. Name of Operator RKI EXPLORATION & PRODUCTION, LLC			9. OGRID Number 246289
3. Address of Operator <sub>3500 ONE</sub> WILLIAMS CENTER MD 35 TULSA, OK 74172			10. Pool name or Wildcat HERRADURA BEND;DELAWARE, EAST
4. Well Location Unit Letter	: 990 feet from the NOR	TH line and	2310feet from the _ WEST _line
Section 36		ange 28E	NMPM EDDY County
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3,148' GR			
3, 140 GIV			
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:			
PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐ REMEDIAL WORK ☐ ALTERIN TEMPORARILY ABANDON ☐ CHANGE PLANS ☐ COMMENCE DRILLING OPNS.☐ P AND A			<del>-</del>
PULL OR ALTER CASING   MULTIPLE COMPL   CASING/CEMENT JOB			
DOWNHOLE COMMINGLE CLOSED-LOOP SYSTEM			
OTHER:		OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of			
proposed completion or recompletion.			
RKI EXPLORATION AND PRODUCTION, LLC REQUESTS APPROVAL TO P&A THE ABOVE WELL.			
THE PROPERTY OF A PROPERTY OF			
WBDS AND PLAN ARE AT	TACHED.		
			NM OIL CONSERVATION
			ARTESIA DISTRICT
			AUG 2 8 2017
			RECEIVED
Spud Date: 11/24/2	Rig Release D	ate: 01/	12/2008
L	PLUBEED BY	10/29/201	1,2
I hereby certify that the information above is true and complete to the best of my knowledge and belief.			
$A \subset A \cap A \cap A = A \cap A \cap A \cap A \cap A \cap A \cap A \cap$			
SIGNATURE ON LOIR Permit Technician II DATE 08/23/2017			
Type or print name Caitlin O'Hair  E-mail address: caitlin.o'hair@wpxenergy.com  PHONE: 539-573-3527			
APPROVED BY: flatet 2 Region TITLE COMPLIANCE OFFICER DATE 8/29/2017 Conditions of Approval (if any):  ### SEE ATTACHED COA-S			
SEE ATTACHED COA-S			

### **PROCEDURE:**

- 1) Test safety anchors and replace as necessary. Set 1 clean frac tank and fill with 480 BFW.
- 2) MIRU Service Unit. Deliver, unload and tally 5,900'- 2-3/8" 4.7# J-55 EUE work string.
- 3) ND WH, NU 3K# BOP.
- 4) POOH rods & tbg. & Lay Dn.
- 5) MI RU wireline unit. Run 5 1/2" GR/JB to 5,880'.
- 6) RIH w- 5 1/2" tbg. conveyed CIBP & set @ 5,880' PU 1 jt. Pump 135 bbls. heavy mud. Spot 30 sx Class C Cement (14.8 ppg, 6.3 gps, 1.32 cfs yield) 5,880' 5,630' flush with heavy mud. TOOH w- tbg. we 3 TAG-
- 7) PU & LD tbg. to 4,366 '- Spot 30 sxs from 4,366' 4,216. (DV TOOL @ 4,316') woe + TAG
- 8) PU & LD tbg. Stand back 2,200'.
- 9) RUWL RIH & Perf @ 2,635' (Base of Salt @ 2,585')
- 10) Sqz. 70 sxs. Class C Cement (14.8 ppg, 6.3 gps, 1.32 cfs yield), from 2,635' to 2,485'.
- 11) WOC & Tag @ 2,485'.
- 12) RU WL Perf @ 488' Sqz. 70 sxs. Class C Cement (14.8 ppg, 6.3 gps, 1.32 cfs yield), from 488' 338'. Wolf & MA
- 13) RU WL Perf @ 150' Sqz. 70 sxs. Class C Cement (14.8 ppg, 6.3 gps, 1.32 cfs yield), from 150' to Surface.
- 14) RDMO Service Unit. RDMO Cementers.
- 15) MIRU Welder. Cut-off casing head. WO cap with well name and number, operator name, and date.
- 16) Pull safety anchors, dress, and reclaim surface location if necessary.

# **Proposed Plugged WBD**

KB: 3160' GL: 3148' Pinnacle State #17
Proposed WBD

Les Peeler 08-22-17 30-015-35864

Spud: 11-24-07 Completed: 12/08/07

Perf @ 150' & sqz 70 sxs. cmt. to surf.

Sct 36, 22S -28E
Eddy Co., New Mexico
Herradura Bend; Delaware East Field
Property # 303271

Perf @ 488' & sqz 70 sxs. cmt. to 338' 9 5/8" (12 1/4" Hole) 36# J-55 Csg. to 438' Cmt'd w-476 sxs to surface - WW + 1366

**SIOT - WVC & TAC** Perf @ 2,635' & sqz 80 sxs WOC - Tag @ 2,485

IF THERE IS CEMENT IN THE ANNULAS COUERING SALT PERFORATING IS NOT REQUISED


5 1/2" ( 7 7/8" hole) 17# J-55 csg. to 6,660' Cmt'd w-1573 sxs. to 1,410' per CBL

Spot 30 sxs. cmt. from 4,366' - 4,216' DV Tool @ 4,316' - WOE - TAG

SET CIBP @ 5,880' & Spot 30 sxs. cmt. on top

WOL > TAL


PBTD: 6,613' KB



Salt @ 2585'

Delaware: 5,980' - 6,094' 6,212' - 6,284'

les@peeleroilfield.com



### CONDITIONS FOR PLUGGING AND ABANDONMENT

### District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
  operations are conducted. A cement evaluation tool is required in order to ensure isolation of
  producing formations, protection of water and correlative rights. A cement bond log or other
  accepted cement evaluation tool is to be provided to the division for evaluation if one has not
  been previously run or if the well did not have cement circulated to surface during the original
  casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water **will not** be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
  - A) Fusselman
  - B) Devonian
  - C) Morrow
  - D) Wolfcamp
  - E) Bone Springs
  - F) Delaware
  - G) Any salt sections
  - H) Abo
  - 1) Glorieta
  - J) Yates.
  - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

### **DRY HOLE MARKER REQUIRMENTS**

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

# (SPECIAL CASES)

### AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)