NM OIL CONSERVATION

Form 3160-5 (September 2001)


UNITED STATES DEPARTMENT OF THE INTERIOR

WALEDIA DIST	RICI
OCT 13 2	OM B No. 1004-0135 Expires: January 31, 2004
ELLS RECEIVE	S. Lease Serial No.
-enter an roposals.	6. If Indian, Allottee or Tribe Name
erse side.	7. If Unit or CA/Agreement, Name and/or No.
	8. Well Name and No. SCB 13 FEDERAL #006
de area code)	9. API Well No. 30-015-33777
	10. Field and Pool, or Exploratory Area LOVING; DELAWARE, EAST
	11. County or Parish, State EDDY COUNTY, NEW MEXICO
TRE OF NOTICE, R	EPORT, OR OTHER DATA
YPE OF ACTION	
Production (Sta	Well Integrity Other
ions and measured and tru	ny proposed work and approximate duration thereof. The vertical depths of all pertinent markers and zones. The subsequent reports shall be filed within 30 days.

BUREAU OF LAND MANAGEMENT SUNDRY NOTICES AND REPORTS ON W Do not use this form for proposals to drill or to reabandoned well. Use Form 3160-3 (APD) for such p SUBMIT IN TRIPLICATE- Other instructions on reve 1. Type of Well Oil Well Gas Well Other 2. Name of Operator ROCKCLIFF OPERATING NEW MEXICO LLC 3a. Address 3b. Phone No. (inclu 1301 MCKINNEY; STE 1300; HOUSTON TX 77010 713-351-0534 4. Location of Well (Footage, Sec., T., R., M., or Survey Description) SEC 13, T23S, R28E 2235' FNL & 990W' FEL 12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATU TYPE OF SUBMISSION Acidize Deepen Notice of Intent Alter Casing Fracture Treat Casing Repair **New Construction** Subsequent Report Change Plans Pius and Abandon Final Abandonment Notice Convert to Injection Plug Back 13. Describe Proposed or Completed Operation (clearly state all pertinent details, including ex If the proposal is to deepen directionally or recomplete horizontally, give subsurface locat Attach the Bond under which the work will be performed or provide the Bond No. on file following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.) Well is on OCD inactive list. Rockcliff Operating NM LLC requests TA status for 12 months until a more economic climate exists for recompletion. Accepted for record
NMOCDEF Proposed TA Procedure: 1. Pull rads and tubing from well 2. Set 5.5in CIBP @ 4,734ft 3. Tag CIBP circ hole with FW + Blocide & Corrosion inhib. SEE ATTACHED FOR 4. Spot 25 sxs @ 4,734ft-4,634ft, WOC for 4hrs/Tag 5. Circulate FW + Biocide & Corrosion inhib CONDITIONS OF APPROVAL 6. Psi test to 500psi for 30mins, BLM needs to witness 14. I hereby certify that the foregoing is true and correct Name (Printed/Typed) Title SR. REGULATORY DEST JAMIE A. ROBINSON Signature jreblasen@reckellffeeergy.com 10/11/201

THIS SPACE FOR FEDERAL OR STATE OF FICE CONSET 2 Title Conditions of approval, if any, are attached. Approval of this notice does not warrant or CARLSBAD/NELD OFFICE certify that the applicant holds legal or equitable title to those rights in the subject lease Offic which would entitle the applicant to conduct operations thereon, Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person belowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to anymatter within its jurisdiction.

(Instructions on page 2)



BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Approved for a period of 12 months ending 10/12/2018 subject to conditions of approval.

Temporary Abandonment of Wells on Federal Lands Conditions of Approval

A temporarily abandoned well is defined as a completion that is not capable of production in paying quantities but which may have value as a service well. Pursuant to 43 CFR 3162.3-4 (c), no well may be temporarily abandoned for more than 30 days without the prior approval of the authorized officer.

Temporary Abandonment (TA) status approval requires a successful mechanical or casing integrity test as follows:

- A Notice of Intent (NOI) Sundry Notice (Form 3160-5) requesting approval to run a mechanical integrity test (MIT) or casing integrity test (CIT).
- 2. A description of the temporary abandonment procedure.
 - a. A bridge plug or packer must be installed as close to 50 feet above any open perforations or open hole as possible. If a cement plug is used, the top of the cement must be verified by tagging. CIBP must be capped with minimum 25 sacks cement, placed with tubing, or 35 feet of cement if placed with bailer.
 - b. The wellbore must be filled with corrosion inhibited fluid and pressure tested to 500 psi. The casing shall be capable of holding this pressure for at least 30 minutes. Any leak-off will be evaluated.
 - c. All downhole production/injection equipment (tubing, rods, etc.) shall be removed from the casing if they are not isolated by a packer.
 - d. A bradenhead test must be conducted. If the test indicates a problem exists, a remedial plan and time frame for remediation shall be submitted within ninety (90) days of the test.
 - e. Contact the appropriate BLM office at least 24 hours prior to the scheduled Casing Integrity Test. For wells in Eddy County, 575-361-2822; Lea County 575-393-3612.
- 3. Provides justification why the well should be temporarily abandoned rather than permanently plugged and abandoned and an estimated date that the well will be returned to beneficial use or plugged and abandoned. 43 CFR 3162.3-4 (a) The operator shall promptly plug and abandon...wells in which oil or gas is not encountered in paying quantities...

Wells that successfully pass the casing integrity test may be approved for Temporary Abandonment (TA) status provided that the operator:

- 1. Submits a subsequent Sundry Notice (Form 3160-5) requesting TA approval with well bore diagram with all perforations and CIBP's and tops of cement on CIBP's.
- 2. Describes the temporary abandonment procedure.
- 3. Attaches a clear copy or the original of the pressure test chart.
- 4. Give justification to allow well to be place in TA status and plan for future use of well with time frame that well will be place back on line or plans to P&A well will be submitted.

If the well does not pass the casing integrity test, then the operator shall within 30 days submit to BLM for approval one of the following:

- 1. A procedure to repair the casing so that a TA approval can be granted.
- 2. A procedure to plug and abandon the well.

SCB 13 Federal 6

- 1. Well is approved to be TA/SI for a period of 12 months or until 10/12/2018
- 2. This will be the last TA approval for this well.
- 3. Must submit NOI to recomplete or NOI to P&A. Must be submitted by 10/12/2018
- 4. COA's met at this time.