

Submit 3 Copies To Appropriate District  
Office  
District I  
1625 N. French Dr., Hobbs, NM 88240  
District II  
1301 W. Grand Ave., Artesia, NM 88210  
District III  
1000 Rio Brazos Rd., Aztec, NM 87410  
District IV  
1220 S. St. Francis Dr., Santa Fe, NM  
87505

State of New Mexico  
Energy, Minerals and Natural Resources

Form C-103  
March 4, 2004

OIL CONSERVATION DIVISION  
1220 South St. Francis Dr.  
Santa Fe, NM 87505

WELL API NO. 30-015-04058
5. Indicate Type of Lease STATE <input checked="" type="checkbox"/> FEE <input type="checkbox"/>
6. State Oil & Gas Lease No. B-2130
7. Lease Name or Unit Agreement Name Burnham GB SA Unit TR 1
8. Well Number 3 A
9. OGRID Number 216852
10. Pool name or Wildcat Square Lake GB SA

**SUNDRY NOTICES AND REPORTS ON WELLS**  
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well:  
Oil Well ☐ Gas Well ☐ Other ☐ Water Injection ☒

2. Name of Operator  
CBS Operating Corp.

3. Address of Operator  
P O Box 2236, Midland, TX 79702

4. Well Location  
Unit Letter H : 1980 feet from the north line and 660 feet from the east line  
Section 2 Township 17S Range 30E NMPM Eddy County NM

11. Elevation (Show whether DR, RKB, RT, GR, etc.)  
3755' GR

Pit or Below-grade Tank Application (For pit or below-grade tank closures, a form C-144 must be attached)

Pit Location: UL        Sect        Twp        Rng        Pit type        Depth to Groundwater        Distance from nearest fresh water well         
Distance from nearest surface water        Below-grade Tank Location UL        Sect        Twp        Rng        ;  
       feet from the        line and        feet from the        line

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data			
NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	PLUG AND ABANDONMENT <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPLETION <input type="checkbox"/>	CASING TEST AND CEMENT JOB <input type="checkbox"/>	
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

See attached procedure

**If earthen pits are used in association with this work a pit permit is required prior to construction.**

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐, a general permit ☐ or an (attached) alternative OCD-approved plan ☐.

SIGNATURE M. A. Sirgo III TITLE Engineer DATE 4-10-06

Type or print name M. A. Sirgo, III E-mail address: mastres@aol.com Telephone No. 432/685-0878

(This space for State use)

APPROVED BY [Signature] TITLE Ad. DATE 4/25/06  
Conditions of approval, if any:

**Notify OCD 24 hrs. prior to any work done.**

CBS OPERATING CORP.

Plugging Procedure for Burnham GB SA Unit TR 1 Well No. 3

Attachment Form C-103

1. MI & RU pulling unit.
2. Pressure up tubing and casing to 500# for 15 minutes to check casing integrity. TOH with packer.
3. RIH with bailer and spot 35' of cement on top of CIBP.
4. RIH with packer and establish casing leak, if any. Casing leaks are common from 300' to 600' in this area. Squeeze holes in casing with enough cement to bring the cement top behind the casing up to the top of the salt. WOC. Test casing to 500# for 15 minutes. TOH with packer. TAC
5. RIH with tubing open ended and tag plug set above CIBP. Circulate hole with plugging mud. Pump 100'+ cement plug across 4-1/2" liner hanger, sufficient to bring plug 50'+ above top of 4-1/2" and 50'+ below 4-1/2" hanger. WOC. TAC
6. Tag plug set across 4-1/2" liner hanger. Pump 100'+ cement plug across 5-1/2" cutoff sufficient to bring plug from 2338' to 2455 below 5-1/2" cutoff. WOC.
7. Set 25 sack plug at 1400' and tag.
8. Tag plug set across 5-1/2" cutoff. Pump 100'+ cement plug across 8-5/8" shoe, sufficient to bring plug 50'+ above top of shoe and 50'+ below 8-5/8" shoe. WOC.
9. Set 60' surface plug, 0-60' all casing strings, inside and outside.
10. Cut off casing and set dry hole marker.
11. Clean and remediate location.

Note: NMOCD will be notified at least 24 hours before starting work on well.


CBS OPERATING CORP.

BURNHAM GBSAU, TRACT 1, #3  
1980' FNL & 660' FEL  
SEC 2, T17S, R30E  
EDDY COUNTY, NEW MEXICO

TD. 3212'



CURRENT



PROPOSED

