Submit 1 Copy To Appropriate District	State of New Mexico	Form C-103
Office <u>District I</u> – (575) 393-6161	Energy, Minerals and Natural Resources	Revised July 18, 2013 WELL API NO.
1675 N. French Dr., Hobbs, NM 88240 District II – (575) 748-1283	are account to the first of the	30-015-20684
811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION	5. Indicate Type of Lease
<u>District III</u> – (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.	STATE S FEE
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, NM 87505	6. State Oil & Gas Lease No. B-2130
87505		
SUNDRY NOT	CICES AND REPORTS ON WELLS OSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A	7. Lease Name or Unit Agreement Name ETZ State Unit
DIFFERENT RESERVOIR. USE "APPL	ICATION FOR PERMIT" (FORM C-101) FOR SUCH	8. Well Number 102
PROPOSALS.)	Gas Well Other	o. Well Number 102
Type of Well: Oil Well Name of Operator	Gas Well Other	9. OGRID Number
COG Operating, LLC		229137
3. Address of Operator		10. Pool name or Wildcat
600 W. Illinois Ave, Midland, T	X 79701	GRBG-Jackson, SR-Q-GRBG-SA
4. Well Location		Con Control WV line
Unit Letter D :	660 feet from the N line and	
Section 16	Township 17S Range 30E	NMPM County Eddy
	11. Elevation (Show whether DR, RKB, RT, GR, etc. 3683' GR	3.)
	2002 GR	
12. Check	Appropriate Box to Indicate Nature of Notice	, Report or Other Data
		BSEQUENT REPORT OF: RK □ ALTERING CASING □
PERFORM REMEDIAL WORK		RILLING OPNS. P AND A
TEMPORARILY ABANDON PULL OR ALTER CASING		
DOWNHOLE COMMINGLE		
CLOSED-LOOP SYSTEM		
OTHER:	□ OTHER:	
13. Describe proposed or com	ppleted operations. (Clearly state all pertinent details, a	and give pertinent dates, including estimated date
of starting any proposed v	work). SEE RULE 19.15.7.14 NMAC. For Multiple Completion	ompletions: Attach welloofe diagram of
	A	
Notif NMOCD 24h	is before MIRU	
1. Tag 5 1/2" CIBP @ 2865'. Spot 25 sx cmt @ 2865-2665'		
2. Set 5 1/2" CIBP @ 2508'. Circulate hole w/ MLF. Pressure test csg. Spot 50 sx cmt @ 2508-2040'. WOC & Tag. 3. Perf & Sqz 50 sx cmt @ 1100-900'. (B/Salt). WOC & Tag		
4. Perf & Sqz 125 sx cmt @ 580-Surface. (T/Salt & 8 5/8" Shoe)		
	o surface, weld on dry hole marker.	
		RECEIVED
		APR 3 0 2018
Spud Date:	Rig Release Date:	DISTRICT II-ARTESIA O.C.D.
)		
* See HHA	relied COAs Must	be Plugged by 5-2-19
I hereby certify that the information	on above is true and complete to the best of my knowled	dge and belief.
SIGNATURE Manael A	TITLE AGAIN	DATE 4/23/18
SIGNATURE MELGALE TO	ton gomeker TITLE Agent	associates com
Type or print name Abique N	TITLE Agent abby mabumand E-mail address:	PHONE: 432-580-7161
For State Use Only	7	
APPROVED BY:	ONS TITLE STATE MY	DATE 5-2-18
Conditions of Approval (if any):	THE JATT 1 3	

COG Operating LLC

Lease & Well # ETZ State Unit # 102 API# 30-015-20684 Spud - 06/24/1972 Elevation - 3683' GR 8 5/8" 20# @ 530', 100 sx cmt, circ. TOC est @ 1200' 1/23/1974 Perforate Queen: 2092 - 2098', 13 holes QUEEN Acidized with 250 gal, fraced with 30,000 gal, 300 sx sd 8/29/1978: Squeezed perfs with 75 sx. 7/9/1972 Perforate Grayburg/San Andres: 2558 - 3895', (94 holes, 0.35") Acidized with 3,500 gal 15% NEFE Fraced with 175,000 gal GW, 1750 sx sd in six stages. **GRAYBURG** 2558' 2806' CIBP - 2865' 11/02/89: Set CIBP @ 2865' + 4 sx cmt on top. 2877' SAN ANDRES 3895' PBTD - 3915' TOC not available in well file, est top @ 1200' TD - 3950' 5-1/2" 14# csg @ 3950'. Cmt w/600 sx Dowell Expanding Cmt.

32.8400536 - 103.9834747

COG Operating LLC

Lease & Well # API

Spud - 06/24/1972 Elevation - 3683' GR

TOC est @ 1200' 1/23/1974 Perforate Queen: 2092 - 2098', 13 holes

Acidized with 250 gal, fraced with 30,000 gal, 300 sx sd 8/29/1978: Squeezed perfs with 75 sx.

7/9/1972


Perforate Grayburg/San Andres:
2558 - 3895', (94 holes, 0.35")

Acidized with 3,500 gal 15% NEFE

Fraced with 175,000 gal GW, 1750 sx sd in six stages.

PBTD - 3915' TD -/3950'

ETZ State Unit # 102 30-015-20684



CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)