District I - (575) 393-6161		of New Mex		Form C-10 Revised August 1, 20
1625 N. French Dr., Hobbs, NM 88240	Energy, Minera	ls and Natur	al Resources	WELL API NO.
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSE	RVATION	DIVISION	30-015-26544
District III - (505) 334-6178	1220 South St. Francis Dr.			5. Indicate Type of Lease STATE FEE
1000 Rio Brazos Rd., Aztec, NM 87410				STATE FEE 6. State Oil & Gas Lease No.
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505	Juliu	10,111107		o. State off & Gas Lease No.
SUNDRY NOTION	CES AND REPORTS			7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOS DIFFERENT RESERVOIR. USE "APPLIC				Markham
PROPOSALS.)				8. Well Number: 1
	Gas Well Other	ou cons	SERVATION	
2. Name of Operator Chevron USA, Inc.	NW	ARTESIA D	SERVATION DISTRICT	9. OGRID Number 4323
3. Address of Operator	**************************************			10. Pool name or Wildcat
6301 Deauville Blvd., Midland,	TX 79706	APR 30	2018	Loving, Brushy Canyon, East
4. Well Location				
Unit Letter C: 330 feet from	m the NORTH line an	d 225RECE	WED WEST lin	e
Section 22 Township 235				
	11. Elevation (Show 3015' GL	whether DR,	RKB, RT, GR, etc	
	3015 GL			
12. Check A	ppropriate Box to	Indicate Na	ature of Notice	, Report or Other Data
NOTICE OF IN	TENTION TO:		SUE	SEQUENT REPORT OF:
PERFORM REMEDIAL WORK	PLUG AND ABANDO	ON 🛛	REMEDIAL WOR	The state of the s
TEMPORARILY ABANDON	CHANGE PLANS			RILLING OPNS. P AND A
PULL OR ALTER CASING	MULTIPLE COMPL		CASING/CEMEN	
DOWNHOLE COMMINGLE	MOLITEL COMIT		OADING/OLIVIE	
DOWN TOLL OOM MINGEL				
OTHER:	(0)		OTHER:	nd give pertinent dates, including estimated
13. Describe proposed or complete of starting any proposed we	leted operations. (Clea	arly state all p	bertinent details, a	nd give pertinent dates, including estimated
proposed completion or reco	rk). SEE RULE 19.13 ompletion. 8 5/8'' 24 #	5.7.14 NMAC @ 530': TO	. For Multiple Co	ompletions: Attach wellbore diagram of /2" 15.5# @ 6341": TOC @ surface
proposed completion or reco	ompletion. 8 5/8" 24#	@ 530': TO	C. For Multiple Co C @ surface; 5 1	ompletions: Attach wellbore diagram of /2" 15.5# @ 6341": TOC @ surface
proposed completion or reco	ompletion. 8 5/8" 24# on USA INC respect	@ 530': TO fully reques	C. For Multiple Co C @ surface; 5 1	ompletions: Attach wellbore diagram of /2" 15.5# @ 6341": TOC @ surface
proposed completion or reco	ompletion. 8 5/8" 24# on USA INC respect	@ 530': TO fully reques	C. For Multiple Co C @ surface; 5 1	ompletions: Attach wellbore diagram of /2" 15.5# @ 6341": TOC @ surface
Chevro Chevro MiRU, pull rods, N/U BO	ompletion. 8 5/8" 24# on USA INC respect Sefre & DPE, pull tubing	© 530': TO fully reques	For Multiple CoC @ surface; 5 1ts to abandon thin	ompletions: Attach wellbore diagram of 1/2" 15.5# @ 6341": TOC @ surface s well as follows:
Chevro Chevro 1. MIRU, pull rods, N/U BO 2. Set CIBP @ 6050', circui	ompletion. 8 5/8" 24# on USA INC respect on USA INC	e 6 530': TO fully reques コエルム gel KCl wat	C. For Multiple Co C @ surface; 5 1. ts to abandon thi ter, and pressure	ompletions: Attach wellbore diagram of /2" 15.5# @ 6341": TOC @ surface
Chevro Chevro MiRU, pull rods, N/U BO Set CIBP @ 6050', circui Spot 25 sx CL "C" cemer	ompletion. 8 5/8" 24# on USA INC respect on USA INC	fully reques TEV gel KCl wat 325'. WOC	C. For Multiple Co C @ surface; 5 1. ts to abandon thi ter, and pressure @ tag	ompletions: Attach wellbore diagram of /2" 15.5# @ 6341": TOC @ surface s well as follows: test casing t/ 500 psi for 10 min.
Chevro Chevro Miru, pull rods, N/U Bo Set CIBP @ 6050', circu Spot 25 sx CL "C" cemer 4. Spot 25 sx CL "C" cemer	ompletion. 8 5/8" 24# on USA INC respect on USA INC	fully reques TLU gel KCl wat 325'. WOC 330' (DV To	C. For Multiple Co C @ surface; 5 1. ts to abandon thi ter, and pressure @ tag ol). — ~ 0 C	ompletions: Attach wellbore diagram of /2" 15.5# @ 6341": TOC @ surface s well as follows: test casing t/ 500 psi for 10 min.
Chevro Chevro Chevro 1. MIRU, pull rods, N/U BC 2. Set CIBP @ 6050', circu 3. Spot 25 sx CL "C" cemer 4. Spot 25 sx CL "C" cemer 5. Spot 25 sx CL "C" cemer	ompletion. 8 5/8" 24# on USA INC respect OPE, pull tubing late well w/ 9.5 ppg nt plug f/ 6050' t/ 58 nt plug f/ 4058' t/ 38	fully reques TLU gel KCl war 325'. WOC 330' (DV To	C. For Multiple Co C @ surface; 5 1. ts to abandon thi ter, and pressure @ tag ool). — • • • • • • • • • • • • • • • • • •	ompletions: Attach wellbore diagram of /2" 15.5# @ 6341": TOC @ surface s well as follows: test casing t/ 500 psi for 10 min.
Chevro Chevro Chevro MiRU, pull rods, N/U BO Set CIBP @ 6050', circu Spot 25 sx CL "C" cemer	ompletion. 8 5/8" 24# on USA INC respect OPE, pull tubing late well w/ 9.5 ppg nt plug f/ 6050' t/ 58 nt plug f/ 4058' t/ 38 nt plug f/ 2643' t/ 24 nt plug f/ 580' t/ sur	fully reques TLU gel KCl wat 325'. WOC 330' (DV To	C. For Multiple Co C @ surface; 5 1. ts to abandon thi ter, and pressure @ tag ool). — • • • • • • • • • • • • • • • • • •	ompletions: Attach wellbore diagram of /2" 15.5# @ 6341": TOC @ surface s well as follows: test casing t/ 500 psi for 10 min.
Chevro Chevro Chevro 1. MIRU, pull rods, N/U BC 2. Set CIBP @ 6050', circu 3. Spot 25 sx CL "C" cemer 4. Spot 25 sx CL "C" cemer 5. Spot 25 sx CL "C" cemer	ompletion. 8 5/8" 24# on USA INC respect OPE, pull tubing late well w/ 9.5 ppg nt plug f/ 6050' t/ 58 nt plug f/ 4058' t/ 38 nt plug f/ 2643' t/ 24 nt plug f/ 580' t/ sur	fully reques TLU gel KCl wat 325'. WOC 330' (DV To	C. For Multiple Co C @ surface; 5 1. ts to abandon thi ter, and pressure @ tag ool). — • • • • • • • • • • • • • • • • • •	ompletions: Attach wellbore diagram of /2" 15.5# @ 6341": TOC @ surface s well as follows: test casing t/ 500 psi for 10 min.
Chevro Chevro Chevro Chevro A. A	ompletion. 8 5/8" 24# on USA INC respect DPE, pull tubing late well w/ 9.5 ppg nt plug f/ 6050' t/ 58 nt plug f/ 4058' t/ 38 nt plug f/ 2643' t/ 24 nt plug f/ 580' t/ sur urface on all casing	fully reques gel KCl wat 325'. WOC 330' (DV To 115' (Delawa face (Shoe, ' strings	E. For Multiple Co C @ surface; 5 1. Its to abandon this er, and pressure @ tag ool). — • • • • • • • • • • • • • • • • • •	empletions: Attach wellbore diagram of 1/2" 15.5# @ 6341": TOC @ surface s well as follows: test casing t/ 500 psi for 10 min. test
Chevro Chevro Chevro MiRU, pull rods, N/U BO Set CIBP @ 6050', circu Spot 25 sx CL "C" cemer Spot 25 sx CL "C" cemer Spot 25 sx CL "C" cemer Spot 65 sx CL "C" cemer Verify top of cement at s I hereby certify that the information	ompletion. 8 5/8" 24# on USA INC respect DPE, pull tubing late well w/ 9.5 ppg nt plug f/ 6050' t/ 58 nt plug f/ 4058' t/ 38 nt plug f/ 2643' t/ 24 nt plug f/ 580' t/ sur urface on all casing	fully reques gel KCl wat 325'. WOC 330' (DV To 15' (Delawat face (Shoe, ' strings plete to the be	E. For Multiple Co C @ surface; 5 1. Its to abandon this er, and pressure @ tag ool). — • • • • • • • • • • • • • • • • • •	test casing t/ 500 psi for 10 min. test Perf@ 580' ge and belief.
Chevro Chevro Chevro 1. MIRU, pull rods, N/U BO 2. Set CIBP @ 6050', circu 3. Spot 25 sx CL "C" cemer 4. Spot 25 sx CL "C" cemer 5. Spot 25 sx CL "C" cemer 6. Spot 65 sx CL "C" cemer 7. Verify top of cement at state I hereby certify that the information SIGNATURE Type or print name Nick Glann E-m	ompletion. 8 5/8" 24# on USA INC respect on USA INC	fully reques Fu	E. For Multiple Co. C @ surface; 5 1. Its to abandon this ter, and pressure @ tag ool). — W O Co.	completions: Attach wellbore diagram of $\frac{1}{2}$ 15.5# @ 6341': TOC @ surface is well as follows: test casing $\frac{1}{500}$ psi for 10 min. ter). $-\frac{1}{600}$ 580' lige and belief. TE $\frac{04}{30}$ 2018
Chevro Chevro 1. MIRU, pull rods, N/U BO 2. Set CIBP @ 6050', circu 3. Spot 25 sx CL "C" cemer 4. Spot 25 sx CL "C" cemer 5. Spot 25 sx CL "C" cemer 6. Spot 65 sx CL "C" cemer 7. Verify top of cement at state I hereby certify that the information SIGNATURE Type or print name Nick Glann E-m For State Use Only APPROVED BY:	ompletion. 8 5/8" 24# on USA INC respect on USA INC	fully reques gel KCl wat 325'. WOC 330' (DV To 15' (Delawa face (Shoe, ' strings plete to the bachevron.com	E. For Multiple Co. C @ surface; 5 1. Its to abandon this ter, and pressure @ tag ool). — • • • • • • • • • • • • • • • • • •	completions: Attach wellbore diagram of $\frac{1}{2}$ 15.5# @ 6341': TOC @ surface is well as follows: test casing $\frac{1}{500}$ psi for 10 min. test casing $\frac{1}{500}$ psi for $\frac{10}{580}$ min. ter). $-\frac{1}{600}$ 580' lge and belief. TE $\frac{04}{30}$ 2018
Chevro Chevro Chevro I. MIRU, pull rods, N/U BO 2. Set CIBP @ 6050', circu 3. Spot 25 sx CL "C" cemer 4. Spot 25 sx CL "C" cemer 5. Spot 25 sx CL "C" cemer 6. Spot 65 sx CL "C" cemer 7. Verify top of cement at start in the information SIGNATURE Type or print name Nick Glann E-market Use Only	ompletion. 8 5/8" 24# on USA INC respect OPE, pull tubing late well w/ 9.5 ppg nt plug f/ 6050" t/ 58 nt plug f/ 4058" t/ 38 nt plug f/ 2643" t/ 24 nt plug f/ 580" t/ sur urface on all casing above is true and com	fully reques gel KCl wat 325'. WOC 330' (DV To 15' (Delawa face (Shoe, ' strings plete to the bachevron.com	E. For Multiple Co. C @ surface; 5 1. Its to abandon this ter, and pressure @ tag ool). — • • • • • • • • • • • • • • • • • •	completions: Attach wellbore diagram of $\frac{1}{2}$ 15.5# @ 6341': TOC @ surface is well as follows: test casing $\frac{1}{500}$ psi for 10 min. ter). $-\frac{1}{600}$ 580' lige and belief. TE $\frac{04}{30}$ 2018

Markham 1 Current Wellbore Diagram

Created:	01/28/18	By: HJ DeBruin		H #:		se Phyal	<u>a</u>					
Updated:	······	8y:	AP		30-015-20		***************************************					
Updated: Lease:	\$4 a -	By:kham		face t Ltr.:	TSHP/Rng 2: C Section	3S / 28E	MANAGEMENT					
Field:	***************************************	g - Delaware		tom Hole	TSHP/Rng	00 22						
Surf. Loc		2,250' FWL		t Ltr.:	Sacti	ion.	1000000					
Bot Loc		Letter 1 19L		STICTR	UCUS14							
County	Eddy	SI,: NM		EVNO:	OU997		000000					
Status		Oil Well			***************************************	······································	********					
Surface Casing Size Wt., Grd. Depth Sxs Cmt. Circulate TOC: Hole Size Note Topped up 8 annulus w/ 8 yds rece				Tubing -	Ini. Sp Ini. Com	K6 3,030 DF GL 3,015 12/10/ 01/05/	5° 90 91	.0 Origina	l Hole			Die
								Wt		Top	Top	Btm
				Annual Company of the	tem Des	OD (in) 2 7/8		(lb/ft)	Grade	Thread	d (ftKB) 14.5	(ftKB) 6,002
Formation Tops				Tubing		2110					14.0	0,002
T. Salt @ 340' 8. Salt @ 2593'				Anchor/cat	cher	2 7/8	1				6,002.0	6,005.
Deleware @ 2593*				Tubing		2 7/8					6.005.0	
Sone Springs & 62	535,	and the same of th		Seat Nipple		2 7/8					6,172.0	6,173.
				Seat taibbu	3	2 770					0,112.0	0
	DV1	Fool @ 4,006'		Perf Sub	AAAAAAA	27/8					6,173.0	6,177.
		***************************************		Mud Ancho	X	2 7/8					6,177.0	6,235.
		-		Rod - Co	onventional R	un Date	: 4/15/	2005				
				Set Depth (fix	(B) In Tubing String)	*******************************		Wellbore			
				6,1	173.0 Tubing - Pro on 4/15/200	oduction s 05 12:00 A	et at 6,23	5.0ftKB	Original Hole	!		
					Item Des	(OD (in)	Grade	Len (ft)	Jts	Top (ftKB)	8tm (ftKB)
		nanaana .		Polished R	od		1 1/4		22.00		9.0	31.0
		- Control of the Cont		Rod Sub			7/8		4.00		31.0	35.0
				Rod Sub			1		4.00		35.0	39.0
				Rod Sub			1		4.00		39.0	43.0
				Rod Sub			1		6.00		43.0	49.0
				Rod Sub	20000000 xxxxxxxxxxxxxxxxxxxxxxxxxxxxxx		1		6.00		49.0	55.0
				Sucker Ro	d		1	·····	350.00	14	55.0	405.0
		PANALOGIA PANALO		Sucker Ro	d		7/8		2,075.00	71	405.0	2,480.0
Production Casino	_	and the same of th		Sucker Ro	d		3/4		3,675.00	147	2,480.0	6,155.0
Size:	5-1/2"	H		Rod Sub			3/4	***************************************	2.00		6,155.0	6,157.0
Wt., Grd.;	15.5#, 3-55			Rod Pump)		1 1/4		16.00		6,157.0	6,173.0
Depth: Sxs Cmt: Circulate: TOC; Hole Size:	8,341' s 1,752 Yes. 40 5x3 Surface 7-778'				Perfs 6 105' - 6.206' (Brushy Canyon				•			

PBTO 6.312' TD 6.349'

Markham 1 Proposed Wellbore Diagram

Created	01/28/18	By: RJ D	eBruin	Well #:	1 St.	Lse: Private	
Updated:		Ву:	annon-managementals	API	30-015-		
Updated:	,00	By:	······	Surface	TSHP/Rng	235 / 28E	
Lease:	***************************************	Markham		Unit Ltr.:	C Sec	ction: 22	
Field:	East L	oving - Delaware		Bottom Hole	TSHP/Rng		
Surf. Loc.:		NL 8 2,250' FWL		Unit Ltr.:	Sec	ction:	
Bot. Local		······································		COST CTR	UCUS1	······································	
County:	Eddy	St.: N	M	CHEVNO:	OU9		
Status:	The	ctive Oil Well					
		ghinggagagan entities			000	KB: 3,030'	
						DF:	
					7.50	GL: 3,015.5'	
Surface Casing						Spud: 12/10/90	
Size:	8-5/8*				Int. Co	omp.: 01/05/91	
Wt., Grd.:	24#, J-55						
Depth:	530'						
Sxs Cmt	420						
Circulate:	No						
TOC:	Surface*						
Hole Size	12-1/4*	2		Snot SE	- CI C (1 EQD)	't' surface (Shoe, T.	Call Early Water
*Note: Topped up 8	3.5/8" x 10.1/4"			Spot 65 8	SX CL C CIM 1/ 300	e sunace (anda, 1.	San, riesh water)
annulus w/ 8 yds re							
Formation Tops							
T. Salt @ 340'							
9. Salt © 2593'							
Delaware @ 2593'				Spot 25 c	av CI C cmt 1/ 254	3' V 2415' (Delaware	B Calt\
Bone Springs @ 6	222'			opat 25 s	or or o citi ii rose	2 0 2413 (Dalamaio	, D Dairy
Done Springs w o.	432						
		DV Tool @ 4,008"					
				Spot 25 t	sx CL C cmt f/ 405	8' 1/ 3630' (DV Tool)	
						,	
Drock votice Ca-1-				Contar	sx CL C cmt 1/ 605	'ACBR 14 'A	
Production Casin Size:	-		VVV		8X CF C CHI 1/ 603	O J JURG	
Wt., Grd.:	5-1/2"		^^	Set Clb?	# 0000		
Depth:	15.5#, J-55 6,341'						
Sxs Cmt:	1,782				Perfs: 6,105' - 6,206'	(1 SPE)	
Circulate:	Yes, 40 sxs				Brushy Canyo		
TOC:	Surface				wisony wanyo		
Hole Size:	7-7/8*						
	- 710						
			PBTD:	6,312			
				6,349'			

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)