Office*	State of New Mexico	Form C-103
District I - (575) 393-6161	Energy, Minerals and Natural Resou	rces Revised July 18, 2013
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283		WELL API NO.
811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION	ON 30-015-20531 5. Indicate Type of Lease
District III (505) 334-6178	1220 South St. Francis Dr.	STATE STATE
1000 Rio Brazos Rd., Aztec, NM 87410 <u>District IV</u> – (505) 476-3460	Santa Fe, NM 87505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505	·	B-2071
	ICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPO	SALS TO DRILL OR TO DEEPEN OR PLUG BACK TO	NG Phillips State
PROPOSALS.)	CATION FOR PERMIT" (FORM C-101) FOR SUCH	8. Well Number #10
1. Type of Well: Oil Well	Gas Well Other	
2. Name of Operator		9. OGRID Number
COG Operating, LLC		229137
3. Address of Operator		10. Pool name or Wildcat
600 W. Illinois Ave, Midland, T.	X 79701	Artesia, Q-GB-SA
4. Well Location		
Unit Letter G:	2645 feet from the S line and	1325 feet from the E line
Section 27	Township 17S Range 28E	NMPM County Eddy
	11. Elevation (Show whether DR, RKB, RT,	GR, etc.)
	3649' GR	
12. Check	Appropriate Box to Indicate Nature of I	Notice, Report or Other Data
NOTICE OF I	NTENTION TO:	SUBSEQUENT REPORT OF:
PERFORM REMEDIAL WORK		AL WORK ALTERING CASING
TEMPORARILY ABANDON	= !	NCE DRILLING OPNS. P AND A
PULL OR ALTER CASING	_	CEMENT JOB
DOWNHOLE COMMINGLE	MOETH LE COMI E	CLIMEIA1 30B
CLOSED-LOOP SYSTEM		
OTHER:	OTHER:	
10 70 11		
13. Describe proposed or com	pleted operations. (Clearly state all pertinent de	etails, and give pertinent dates, including estimated date
of starting any proposed w	ork). SEE RULE 19.15.7.14 NMAC. For Mul	tiple Completions: Attach wellbore diagram of
of starting any proposed w proposed completion or re	ork). SEE RULE 19.15.7.14 NMAC. For Mul	tiple Completions: Attach wellbore diagram of OCD 24 hrs. prior to
of starting any proposed w proposed completion or re	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. prior to only work done.
of starting any proposed w proposed completion or re	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. prior to only work done.
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900-	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. prior to only work done.
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. plact to only work done. sx cmt @ 1960-1690'. — \(\circ \)
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. prior to only work done.
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. plact to only work done. sx cmt @ 1960-1690'. — \(\sigma \sigma \sigma^{-1} \sigma^{-1} \) RECEIVED
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. plact to only work done. sx cmt @ 1960-1690'. — \(\sigma \sigma \sigma^{-1} \sigma^{-1} \) RECEIVED
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. plact to only work done. sx cmt @ 1960-1690'. — \(\circ \)
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. plact to only work done. sx cmt @ 1960-1690'. — \(\sigma \sigma \sigma^{-1} \sigma^{-1} \) RECEIVED
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. pilot to only work done. sx cmt @ 1960-1690'. — \(\sigma = \sigma \cdot \) RECEIVED DEC 2 4 2018
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. pilot to only work done. sx cmt @ 1960-1690'. — \(\sigma = \sigma \cdot \) RECEIVED DEC 2 4 2018
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, veri	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. prior to only work done. sx cmt @ 1960-1690'. — \(\sigma \sig
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, veri	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker.	tiple Completions: Attach wellbore diagram of OCD 24 hrs. prior to only work done. sx cmt @ 1960-1690'. — \(\sigma \sig
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, veri	ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker.	RECEIVED DEC 2 4 2018 DISTRICT II-ARTESIA O.C.D.
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, veri	Ork). SEE RULE 19.15.7.14 NMAC. For Mulcompletion. Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker. Rig Release Date:	RECEIVED DEC 2 4 2018 DISTRICT H-ARTESIA O.C.D.
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, veri	Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker. Rig Release Date: COA's above is true and complete to the best of my k	RECEIVED DEC 2 4 2018 DISTRICT II-ARTESIA O.C.D. Placed by 12/26/19 nowledge and belief.
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, veri	Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker. Rig Release Date: COA's above is true and complete to the best of my k	Tiple Completions: Attach wellbore diagram of OCD 24 hrs. Diagram
of starting any proposed w proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, veri	Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker. Rig Release Date: COA's above is true and complete to the best of my k	Tiple Completions: Attach wellbore diagram of OCD 24 hrs. Diagram
of starting any proposed we proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, verified the second of the second	Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker. Rig Release Date: COA's above is true and complete to the best of my k	RECEIVED DEC 2 4 2018 DISTRICT II-ARTESIA O.C.D. Placed by 12/26/19 nowledge and belief.
of starting any proposed we proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, verically the starting of the starting	Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker. Rig Release Date: COA's above is true and complete to the best of my k	Tiple Completions: Attach wellbore diagram of OCD 24 hrs. Diagram OCD 24 hrs. Diagram OCD 24 hrs. Diagram OCD 24 hrs. Diagram RECEIVED DEC 2 4 2018 DISTRICT II-ARTESIA O.C.D. DATE 12/19/2018 Manadassociates.com PHONE: 432-580-7161
of starting any proposed we proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, verified the set of the s	Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker. Rig Release Date: COA's above is true and complete to the best of my k	Tiple Completions: Attach wellbore diagram of OCD 24 hrs. Diagram
of starting any proposed we proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, verically the starting of the starting	Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker. Rig Release Date: COA's above is true and complete to the best of my k	Tiple Completions: Attach wellbore diagram of OCD 24 hrs. Diagram OCD 24 hrs. Diagram OCD 24 hrs. Diagram OCD 24 hrs. Diagram RECEIVED DEC 2 4 2018 DISTRICT H-ARTESIA O.C.D. DATE 12/19/2018 Manadassociates.com PHONE: 432-580-7161
of starting any proposed we proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, verified the set of the s	Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker. Rig Release Date: COA's above is true and complete to the best of my k	Tiple Completions: Attach wellbore diagram of OCD 24 hrs. Diagram OCD 24 hrs. Diagram OCD 24 hrs. Diagram OCD 24 hrs. Diagram RECEIVED DEC 2 4 2018 DISTRICT H-ARTESIA O.C.D. DATE 12/19/2018 Manadassociates.com PHONE: 432-580-7161
of starting any proposed we proposed completion or re 1. Set 7" CIBP @ 1960'. 2. Spot 40 sx cmt @ 900- 3. Perf & Sqz 190 sx cmt 4. Cut off well head, verified the set of the s	Pressure test csg. Circ hole w/ MLF. Spot 50 700'. WOC & Tag. @ 535' to surface. Fy cmt to surface, weld on Dry Hole Marker. Rig Release Date: COA's above is true and complete to the best of my k	Tiple Completions: Attach wellbore diagram of OCD 24 hrs. Diagram OCD 24 hrs. Diagram OCD 24 hrs. Diagram OCD 24 hrs. Diagram RECEIVED DEC 2 4 2018 DISTRICT H-ARTESIA O.C.D. DATE 12/19/2018 Manadassociates.com PHONE: 432-580-7161

Field & Pool ____ Artesia, Q-GB-SA

NG Phillips St #10

Well ID Info: API No: 30-015-20531 Spud Date: 11/16/1971

	Csg: Set @ Cement w/ circ.	9-5/8" 40# 485' 400 sx Circulated	
	<u>Tubing Detail</u> Unknown EOT @ 2019'	Rod Detail 80 - 3/4" Rods 12' X 1 1/2" PUMP	
	2007' - 2022' Frac 12,000 ga 12,000 # sand Re-Fraced 197	Frac 12,000 gals Curde 12,000 # sand Re-Fraced 1979 Frac 1500 bbl Curde 30,000 # sand	
2	Depth: Cement w/ circ.	2043' 275SX No, TOC 395'	

TD 2039' PBTD 2038'

> 32.8057785 _164.1597595

Field & Pool Artesia, Q-GB-SA

NG Phillips St #10

circ.

NO TIME	301#10	•	
			Well ID Info: API No: 30-015-20531 Spud Date: 11/16/1971
	Csg: Set @ Cement w/ circ.	9-5/8" 40# 485' 400 sx Circulated	
4	3. Perf & Sqz 1	190 sx cmt @ 535' to Su	rface.
		:mt @ 900-700'. WOC &	
	1. Set 7" CIBP @ 1960'. Pressure test csg. Circ hole w/ MLF. Spot 50 sx cmt @ 1960-1690'.		
	Grayburg / San 2007' - 2022' Frac 12,000 gal 12,000 # sand Re-Fraced 1979 Frac 1500 bbl C 30,000 # sand	Andres 2SPF is Curde	
	Csg:	7" 20# J55	
Z	Depth:	2043'	
	Cement w/	275SX	

No, TOC 395'

TD 2039' PBTD 2038'

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least '%'' welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)