

Submit 1 Copy To Appropriate District Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

NM OIL CONSERVATION
ARTESIA DISTRICT

WELL API NO. 30-015-22830
5. Indicate Type of Lease STATE ☒ FEE ☐
6. State Oil & Gas Lease No. E-1392
7. Lease Name or Unit Agreement Name Travis State
8. Well Number #1
9. OGRID Number 228937
10. Pool name or Wildcat Illinois Camp; Bone Spring, East
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3585' GL

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator
Matador Production Company

3. Address of Operator
5400 LBJ Freeway Suite 1500
Dallas TX 75240

4. Well Location
Unit Letter K : 1780 feet from the SOUTH line and 2080 feet from the WEST line
Section 13 Township 18S Range 28E NMPM County EDDY

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
3585' GL

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐
CLOSED-LOOP SYSTEM ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐
OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

MIRU, Kill Well, ND WH, NU BOPs, Pull Tbg
Set CIBP at 6152'. Spot 25 sx Cl C cmt on top. WOC. Tag
PU to 5540'. Spot 25 sx Cl C cmt. WOC. Tag
PU to 4100'. Spot 25 sx Cl C cmt. WOC. Tag
PU to 2950'. Perf & Sqz 35 sx Cl C cmt. WOC. Tag
PU to 1230'. Perf and Sqz 35 sx Cl C cmt. WOC. Tag
PU to 430'. Perf and Sqz Cl C cmt to surface.
Cut off WH. Verify cmt in annulus. Install dry hole marker as per NMOCD specifications.

Notify OGD 24 hrs. prior to any work done.

Spud Date:

1979

Rig Release Date:

1979

* See Attached CDA's must be plugged by 1/8/20
I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

TITLE Engineer

DATE 12/7/18

Type or print name Chris Villarreal

E-mail address: cvillarreal@matadorresources.com

PHONE: (972) 371-5471

For State Use Only

APPROVED BY:

TITLE

DATE

Conditions of Approval (if any):


ENTERED
y

Matador Production Company
 Travis State #1
 1780' FSL & 2080' FWL Sec 13 - 185 - 28E
 Eddy County, NM
 API: 30-015-22830
CURRENT WELLBORE SCHEMATIC
 Spudded: 3/19/1979

Casing Information						
	Hole Size	Casing Size	Type	Weight lb/ft	Joints	Depth Set
Surface	17 1/2	13 3/8		48	13	380
Intermediate	12 1/4	9 5/8	J-55 & H-40	36 & 32.3	73	2900
Production	8 3/4	5 1/2	N-80 & J-55	17	275	11,061
	DV Tool	4050				

Cementing Record	
Surface	100 sxs thickset & 375 sxs CI C & Add 8 yards readi-mix (Circulated)
Intermediate	950 sxs Hal Lite & 200 sxs CI C & 250 sxs CI C through 1" tubing (Circulated)
Production	1st- 520 sxs HLW & 350 sxs CI H 2nd- 220 sxs HLW & 100 sxs CI H

Tubing		Rods		Geologic Markers	
Joints	194	Total		Yates	878
Diam.	2 3/8	7/8"		Seven Rivers	1230
Grade		3/4"		Queen	1896
Weight		7/8"		Grayburg	2260
Packer		1"		1st BS	6156
PBTD	6340	Pony		2nd BS	7103
TA		Pump		3rd BS	7986
SN	6300			Wolfcamp	8255
BP				Canyon	9762
				Atoka	10296
				Morrow	10528



DV Tool @ 4050'

(2/5/1996) 4 sqz holes @ 5490
 Thief Zone @ 5765-5780
 Took cmt while reversing out

(2/15/1996) Perf: 6202-6494. 1st Bone Spring
 Frac w/ 50360 gal of X-Link & 94800 #
 of 16/30 and 25000# of 16/30 Resin
 Addz w/ 3000 gal of 15% NEFE
 (3/19/1996) CIBP set @ 6340

(2/5/1996) Cmt Ret @ 7228
 4 sqz holes @ 7300

(2/2/1996) CIBP set @ 8260


(2/1/1996) CIBP set @ 9790 + 35' cmt
 (7/10/1979) Perf: 9816-9862
 Addz w/ 6000 gal of 15% D5-30

(7/8/1979) CIBP set @ 10550 + 12' cmt

(6/23/1979) Perf: 10622-10630. Atoka

(7/8/1979) CIBP set @ 10655 + 12' cmt
 (6/3/1979) Perf: 10674-10830. Morrow
 Frac 30000 3 1/2% MS gelled acid & 17850# 20/40
 Addz w/ 5000 gal of 7 1/2% MS acid

Matador Production Company
 Travis State #1
 1780' FSL & 2080' FWL Sec 13 - 18S - 28E
 Eddy County, NM
 API: 30-015-22830
 PROPOSED P&A WELLBORE SCHEMATIC
 Spudded: 3/19/1979



Casing Information						
	Hole Size	Casing Size	Type	Weight lb/ft	Joints	Depth Set
Surface	17 1/2	13 3/8		48	13	380
Intermediate	12 1/4	9 5/8	J-55 & H-40	36 & 32.3	73	2900
Production	8 3/4	5 1/2	N-80 & J-55	17	275	11,061
DV Tool		4050				

Cementing Record	
Surface	100 sxs thickset & 375 sxs CI C & Add 8 yards readi-mix (Circulated)
Intermediate	950 sxs Hal Lite & 200 sxs CI C & 250 sxs CI C though 1" tubing (Circulated)
Production	1st- 520 sxs HLW & 350 sxs CI H 2nd- 220 sxs HLW & 100 sxs CI H

Geologic Markers	
Yates	878
Seven Rivers	1230
Queen	1896
Grayburg	2260
1st BS	6156
2nd BS	7103
3rd BS	7986
Wolfcamp	8255
Canyon	9762
Atoka	10296
Morrow	10528

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If the well is not plugged within 1
7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
8. **Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.**
9. Produced water **will not** be used during any part of the plugging operation.
10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
12. **Class 'C' cement will be used above 7500 feet.**
13. **Class 'H' cement will be used below 7500 feet.**
14. **A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged**
15. **All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing**

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. **A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.**
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, **(WOC 4 hrs and tag).**
19. **No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, **WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.**
21. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)