
	Submit 1 Copy To Appropriate District Office	State of New Me			Form C-103		
1	District I - (575) 393-6161	<u>District I</u> – (575) 393-6161 Energy, Minerals and Natural Resour 625 N. French Dr., Hobbs, NM 88240 District II – (575) 748-1283		WELL API NO.	Revised July 18, 2013		
	District II – (575) 748-1283			30-015-29930			
	811 S. First St., Artesia, NM 88210				5. Indicate Type of Lease		
	1000 Rio Brazos Rd., Aztec, NM 87410	strict III - (505) 334-6178 1220 South St. Francis Dr.		STATE FEE			
	<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	strict IV – (505) 476-3460 Santa Fe, NM 8/505			Gas Lease No.		
	7505						
	SUNDRY NOTICES AND REPORTS ON WELLS			7. Lease Name	or Unit Agreement Name		
	(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH			Coyote 21			
	PROPOSALS.)						
	1. Type of Well: Oil Well			8. Well Number	<u> </u>		
	. Name of Operator OXY USA Inc.		9. OGRID Number				
	3. Address of Operator		16696 10. Pool name or Wildcat				
		P.O. Box 50250 Midland, TX 79710			Cedar Canyon Delawere		
ı	4. Well Location						
	Unit Letter K: 2310 feet from the South line and 2310 feet from the west line						
	Section 21	Township 245 Ra	inge 29E	NMPM	County Eddy		
		11. Elevation (Show whether DR,	RKB, RT, GR, etc.)			
l		2948					
	10 (1)			_			
	12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data						
	NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF:						
	PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☑ REMEDIAL WORK ☐ ALTERING CASING ☐						
	TEMPORARILY ABANDON				P AND A		
	PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT JOB						
	DOWNHOLE COMMINGLE						
	CLOSED-LOOP SYSTEM OTHER:		OTHER:				
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date					tes_including estimated date		
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellhore diagram of							
	proposed completion or recompletion.				hrs . prior to		
proposed completion or recompletion. TD-5372' PBTD-5323' Perfs-2970-2980' 4876-5245' Notify OCD 24 hrs . prior to any work done.				k done.			
40.2/48.40.58							
	10-3/4" 40.5# csg @ 567' w/ 730sx, 14-3/4" hole, TOC-Surf-Circ 7-5/8" 26.4# csg @ 2810' w/ 765sx, 9-7/8" hole, TOC-Surf-Circ				RECEIVED		
	4-1/2" 11.6 csg @ 5372', DVT @ 4000' w/ 580sx, 6-3/4" hole, TOC 2050'-CBL						
FEB 1 4 2019					FFR 11 4 2019		
	1. RIH & set CIBP @ 4826' w/ 25sx cmt to 4576'				125 2 - 2010		
	2. M&P 25sx cmt @ 4125-3875' WOC-Tag			DIST	RICT II-ARTESIA O.C.D.		
3. RIH & set CIBP @ 2920' w/ 25sx cmt to 2670'							
4. Perf @ 1755' sqz 30sx cmt to 1635' WOC-Tag 5. Perf @ 690' sqz 150sx cmt to Surface							
10# MLF between plugs - Above ground steel tanks will be utilized					54, 2.20-19 U)		
	Spud Date:	Pig Palaga Da	ta				
	Spud Date: Rig Release Date:						
)	* See Attached COA's Must be Plant be 2/18/20						
7	I hereby certify that the information above is true and complete to the best of my knowledge and belief.						
•	SIGNATURE // /	TITLE Sr.	Regulatory Adviso	rDAT	= 214/19 Jr Jr Jr 70		
-	Type or print name David Stewart E-mail address: david_stewart@oxy.com PHONE:432-685-5717						
1	For State Use Only						
APPROVED BY: DATE 2/18/19							
	Conditions of Approval (if any):	TITLE //A	t ply-	DA	ATE 2/18//9		

OXY USA Inc - Proposed Coyote 21 #1 API No. 30-015-29930

150sx @ 690'-Surface 14-3/4" hole @ 567' 10-3/4" csg @ 567' w/ 730sx-TOC-Surf-Circ Perf @ 690' 30sx @ 1755-1635' WOC-Tag Perf @ 1755' 9-7/8" hole @ 2810' CIBP @ 2920' w/ 25sx to 2670' 7-5/8" csg @ 2810' w/ 765sx-TOC-Surf-Circ Perfs @ 2970-2980' 25sx @ 4125-3875' WOC-Tag 6-3/4" hole @ 5372' 4-1/2" csg @ 5372' CIBP @ 4826' w/ 25sx to 4576' w/ 580sx-TOC-2050'-CBL DVT @ 4000' Perfs @ 4876-4898' Perfs @ 5006-5016' Perfs @ 5220-5245' PB - 5323' TD-5372'



CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter
Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date
8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)