

Submit 1 Copy To Appropriate District
Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO. 30-015-00260
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Cleaveland
8. Well Number 2
9. OGRID Number 7377
10. Pool name or Wildcat Dayton; San Andres, West

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH
PROPOSALS.)

1. Type of Well: Oil Well ☒ Gas Well ☐ Other

2. Name of Operator
EOG Resources, Inc.

3. Address of Operator
104 South Fourth Street, Artesia, NM 88210

4. Well Location

Unit Letter B : 330 feet from the North line and 2310 feet from the East line
Section 33 Township 18S Range 26E NMPM Eddy County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
3362' GR

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐
CLOSED-LOOP SYSTEM ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐
OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. JSA
 2. MIRU WOR
 3. NU Rod BOP
 4. TOOH w/ Rod String and pump.
 5. ND Tree/NU BOPs. *Squeezed Perf. 1438'-62'*
 6. POOH with tubing
 7. Run Casing scraper, Gauge ring with Junk Basket to top perf
 - Set CIBP at 1388 ft with 35 ft of CLS C on top. *CIBP @ 1500'*
 - Spot a 25 SX (142 ft) CLS C cement plug 1008 ft - 1150 ft. This will plug the 7" Shoe. *Perf @ 1150' & Attempt to 582*
 - Spot a 10 SX (57 ft) CLS C cement plug 0 ft - 57 ft. This will plug the Top. *Perf @ 100' & Attempt to 582.*
 8. RDMO Workover Rig
 9. PXA Marker
- 9.1. Cut off wellhead and weld on dry hole marker. Clean location as per regulation.

*Notify OCD 24 hrs. prior to
any work done.*

RECEIVED

MAR 12 2019

DISTRICT II-ARTESIA O.C.D.

Perf @ 1150' & Attempt to 582

ENTERED
3-13-19

Spud Date:

Rig Release Date:

** See Attached COA's Must be Plugged by 3/13/20*

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Jeremy Haass* TITLE Regulatory Specialist DATE February 7, 2019

Type or print name Jeremy Haass E-mail address: jeremy_haass@eogresources.com PHONE: 575-748-4311

For State Use Only

APPROVED BY: *Staff mg.* TITLE Staff mg. DATE 3/13/19

Cleveland #2

API

GL: 3362

Surface Location: B-33-18S-26E 330 FNL 231 Lat/Long: 32.7106934, -104.3860092

COMMENTS

Perforations

A

1438 - 1462
1580 - 1773

Squeezed
PBTD 2027
CIBP 2070

2465 - 2446
2586 - 2623
2618 - 2623
2699 - 2709
2728 - 2733
2758 - 2762
2816 - 2826

Squeezed
CIBP 5686

Reamed to 2

CIBP 5100

5128 - 5138
5114 - 5116
5110 - 5112
5092 - 5096

B

PBTD 2,027 MD
TD 5,203 MD

Tubing

#	O. D. IN	I. D. IN	LENGTH FT	Top set FT					Description
1	2.875	2.441							
2									
3									
4									
5									
6									
7									
8									
9									
10									
11									
12									

Rods

	OD	Length	Top set
1			
2			
3			
4			
5			
6			
7			

CASING DETAIL

#	SIZE	WGHT	GRADE	THREAD	Top	Bottom	SX	Cement	TOC
A	9 5/8	32			0	1,100	300	Circ to Surf	surf
B	7	17			0	3,210	500	Circ to Surf	Surf
C	4 1/2				3050	5,203	100		Est 3800'

TOPS

Glorieta	2446	
B. Springs	3850	
ABO	4560	
Reef	5100	

Prepared by: MJM

Date: 4-Mar-2019

Cleveland #2

API

GL: 3362

Surface Location: B-33-18S-26E 330 FNL Lat/Long: 32.7106934,-104.3860092

CASING DETAIL

#	SIZE	WGHT	GRADE	THREAD	Top	Bottom	SX	Cement	TOC
A	9 5/8	32			0	1,100	300	Circ to Surf	surf
B	7	17			0	3,210	500	Circ to Surf	Surf
C	4 1/2				3050	5,203	100		Est 3800'

TOPS

Glorleta 2446

B. Springs 3850

ABO 4560

Reef 5100

Plugs

#	SX	CMT Class	Top	BTM	Description
1	60	Class C	5300	5660	Set CIBP at 1388 ft with 35 ft of CLS C on top.
2	25	Class C	4100	4250	Spot a 25 SX (142 ft) CLS C cement plug 1008 ft - 1150 ft. This will plug the 7" Shoe.
3	25	Class C	1900	2050	Spot a 10 SX (57 ft) CLS C cement plug 0 ft - 57 ft. This will plug the Top.

COMMENTS

Perforations

A

Plug 1

1438 - 1462
1580 - 1773

Squeezed

PBTD 2027

CIBP 2070

2465 - 2446

2586 - 2623

2618 - 2623

2699 - 2709

2728 - 2733

2758 - 2762

2816 - 2826

Squeezed

CIBP 5686

CIBP 5100

5128 - 5138

5114 - 5116

5110 - 5112

5092 - 5096

Reamed to 2027'

B

PBTD 2,027

MD

TD 5,203

MD

Prepared by: MJM

Date: 4-Mar-2019

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If the well is not plugged within 1
7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
8. **Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.**
9. Produced water **will not** be used during any part of the plugging operation.
10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
12. **Class 'C' cement will be used above 7500 feet.**
13. **Class 'H' cement will be used below 7500 feet.**
14. **A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged**
15. **All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing**

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. **A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.**
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, **(WOC 4 hrs and tag).**
19. **No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, **WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.**
21. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)