Submit I Copy To Appropriate District	State of New Mexico	Form C-103
Office . District 1 – (575) 393-6161	Energy, Minerals and Natural Resources	Revised August 1, 2011
1625 N. French Dr., Hobbs, NM 88240 District II – (575) 748-1283		WELL APT NO. 30-035-61888
811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION	5. Indicate Type of Lease
<u>District III</u> - (505) 334-6178 1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Francis Dr.	STATE FEE
District IV – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM 87505	Santa Fe, NM 87505	6. State Oil & Gas Lease No.
	ICES AND REPORTS ON WELLS	7. Lease Name or Unit Agreement Name
	OSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A CATION FOR PERMIT" (FORM C-101) FOR SUCH	BAJILLO DRAW WQ STATE
1. Type of Well: Oil Well X	Gas Well Other	8. Well Number 1
Name of Operator Vanguard Operating LLC		9. OGRID Number
3. Address of Operator		10. Pool name or Wildcat
5847 San Felipe St., Suite 300	0, Houston, TX 77057	Pecos Slope; ABO, West
4. Well Location	660 feet from the North line and	660 feet from the West line
Unit Letter D :	icet from the mie tald	
Section 28	Township 07S Range 23E 11. Elevation (Show whether DR, RKB, RT, GR, etc.)	MINIT IVI County
	GR 3885	'
12. Check	Appropriate Box to Indicate Nature of Notice,	Report or Other Data
		•
		SSEQUENT REPORT OF:
PERFORM REMEDIAL WORK TEMPORARILY ABANDON	PLUG AND ABANDON 🗓 REMEDIAL WOF	RK
PULL OR ALTER CASING	<u>—</u>	
DOWNHOLE COMMINGLE	MOETH LE GOIM E	
OTHER:	OTHER:	
13. Describe proposed or comp	pleted operations. (Clearly state all pertinent details, ar ork). SEE RULE 19.15.7.14 NMAC. For Multiple Co	ad give pertinent dates, including estimated date
proposed completion or re		impletions. Attach welloofe diagram of
proposed completion of te	•	- dor to
1. Notify OCD 24 hrs prior to MIRU I	o P&A. Notify OC	D 24 hrs . prior to
2. Set CIBP @ 2678' tag w/tbg circ t	nole w/MLF test csg & CIBP.	work done.
3. Spot 25 sx's cmt @ 2678'-2578' V		
 Spot 25 sx's cmt @ 1676'-1576' (Spot 45 sx's cmt @ 1172'-1072' (CLIOE) 14/00 A TAO	RECEIVED
5. Spot 45 sx's cmt @ 1172-1072 (erf @ 100' + Attempt to Circ.	1 EPATIATO
7. Cutoff wellhead and anchors, inst	all dry hole marker & move off.	****
7. Oddin Walinada and analoto, inc	and any note market a more on	MAR 1 2 2019
		DISTRICT II-ARTESIA O.C.D.
Spud Date:	Rig Release Date:	
11/2		
See Attached	COA's Must be Plage	cd d, 3/13/20
I hereby certify that the information	above is true and complete to the best of my knowled	ge and belief.
SIGNATURE /A - 15	// /	
SIGNATURE / /	TITLE Agent	DATE 03/08/19
وليك مناوريا	TITLE Agent	DATE 03/08/19
Type or print name Justin Ba		
Type or print name		
For State Use Only	gley E-mail address: sunsetwellservice@	2yahoo.com PHONE: 432-561-8600
Type or print name For State Use Only APPROVED BY: Conditions of Approval (if any):		

ENTERED Ly313:19 BAJILLO DRAW WQ STATE #1 GR 3885 660' FNL & 660' FWL SPUDDED 2/19/1983 D-SEC 28-T07S-R23E COMPLETED 3/11/1983 CHAVES COUNTY, NEW MEXICO LAT 33.6847115 PECOS SLOPE; ABO, WEST LONG -104.626953 30-015-61888 FORMATION TOPS PER C-105 BEFORE PAA SURF SAN ANDRES GLORIETA 1626 ABO ORIGINAL 10-3/4" TOC @ 90'. SPOT 100 SX W/ 1" TO CIRC 14-3/4" HOLE 10-3/4" 40.5# J-55 ST&C CMT W/ 1,000 SX. CIRC. 7-7/8" HOLE ABO PERFS: 2,728-2,844' (18 HOLES) -ACIDIZE W/ 3,000 GALS 7.5% HCL -FRAC W/ 40,000 GALS GELLED KCL WATER & 70,000# 20/40 SAND 4-1/2" 9.5# J-55 ST&C 3,250 CMT W/ 575 SX. PBTD: 3,217 KDZ 03-04-2019 TD: 3,250'

LEASE/WELL:

LOCATION

CO/ST:

FIELD:

API NO.

LEASE/WELL: BAJILLO DRAW WQ STATE #1 GR 3885 LOCATION 660' FNL & 660' FWL SPUDDED 2/19/1983 D-SEC 28-T07S-R23E COMPLETED 3/11/1983 CO/ST: CHAVES COUNTY, NEW MEXICO LAT 33.6847115 FIELD: PECOS SLOPE; ABO, WEST LONG -104.626953 API NO. 30-015-61888 FORMATION TOPS PER C-105 SAN ANDRES SURF AFTER PAA GLORIETA 1626 ABO 2664 ORIGINAL 10-3/4" TOC@90'. SPOT 100 SX W/1" TO CIRC SPOT 15 SX CMT @30 - SURFALE 14-3/4" HOLE 1,122'SPOT 45 SX CMT 21172-1072 (SHOE) 10-3/4" 40.5# J-55 ST&C CMT W/ 1,000 SX. CIRC. MLF 7-7/8" HOLE SPOT 25 SX CMT 21674-1574 (GLORZETA) MLF SPOT 25 PX CONT D 2678-2578 CIBP & 7678

> 4-1/2" 9.5# J-55 ST&C CMT W/ 575 SX.

PBTD: 3,217' TD: 3,250' KDZ 03-04-2019

-FRAC W/ 40,000 GALS GELLED KCL WATER & 70,000# 20/40 SAND

ABO PERFS: 2,728-2,844' (18 HOLES) -ACIDIZE W/ 3,000 GALS 7.5% HCL

3,250

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- A notice of intent to plug and abandon a wellbore is required to be approved before plugging
 operations are conducted. A cement evaluation tool is required in order to ensure isolation of
 producing formations, protection of water and correlative rights. A cement bond log or other
 accepted cement evaluation tool is to be provided to the division for evaluation if one has not
 been previously run or if the well did not have cement circulated to surface during the original
 casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)