Form 3160-5 (June 2015)

UNITED STATES DEPARTMENT OF THE INTERIOR **BUREAU OF LAND MANAGEMENT**

OCD Artesia

FORM APPROVED

OMB	NO.	1004	1- 0]	137
Expires:	Janu	ary	31,	201
0 111				

SUNDRY NOTICES AND REPORTS ON WELLS Do not use this form for proposals to drill or to re-enter an

5. Lease Serial No. NMNM93190

abandoned well. Use form 3160-3 (APD) for such proposals.					6. If Indian, Allottee or Tribe Name		
SUBMIT IN TRIPLICATE - Other instructions on page 2					7. If Unit or CA/Agreement, Name and/or No.		
1. Type of Weil ☑ Oil Well ☐ Gas Well ☐ Other					8. Well Name and No. LUCKY LOBO ASX FEDERAL COM 2		
2. Name of Operator Contact: JEREMY HAASS YATES PETROLEUM CORPORATION€-Mail: jeremy_haass@eogresources.com					9. API Well No. 30-015-33411-00-S1		
			(include area code) .4311	10. Field : WILD	10. Field and Pool or Exploratory Area WILDCAT		
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)				11. Count	11. County or Parish, State		
Sec 28 T16S R27E SESE 660		EDDY	EDDY COUNTY, NM				
12. CHECK THE AI	PPROPRIATE BOX(ES)	TO INDICAT	E NATURE O	NOTICE, REPORT	, OR OTH	ER DATA	
TYPE OF SUBMISSION	TYPE OF ACTION						
Notice of Intent ■	☐ Acidize	☐ Acidize ☐ Deepen		☐ Production (Start/Resume)		■ Water Shut-Off	
	☐ Alter Casing ☐ Hydraulic Fracturing		☐ Reclamation		■ Well Integrity		
☐ Subsequent Report	Casing Repair	Casing Repair		☐ Recomplete		□ Other	
☐ Final Abandonment Notice	☐ Change Plans	Plug and Abandon		□ Temporarily Abandon			
	☐ Convert to Injection	□ Plug	Back	■ Water Disposal	Water Disposal		
following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection. 1. JSA 2. MIRU WOR 3. NU Rod BOP 4. TOOH w/ Rod String and pump. 5. ND Tree/NU BOPs. 6. POOH with tubing 7. Run Casing scraper, Gauge ring with Junk Basket to top perf Plug as follows Set CIBP at 9750-ft-with 95 ft of CLS H on top, Ref Completion or recompletion in a new interval, a Form 3160-4 must be filed once testing has been completed. Final Abandonment Notices must be filed once testing has been completed. Final Abandonment Notices must be filed only after all requirements, including reclamation, have been completed and the operator has determined that the site is ready for final inspection. SEE ATTACHED FOR CONDITIONS OF APPROVAL 4. CONDITIONS OF APPROVAL 5. ND Tree/NU BOPs. 6. POOH with tubing 7. Run Casing scraper, Gauge ring with Junk Basket to top perf Plug as follows Set CIBP at 9750-ft-with 95 ft of CLS H on top, Ref Completed for record - NMOCD Completed for record - NMOCD Completed for record - NMOCD Accepted for record - NMOCD Completed for record -							
14. I hereby certify that the foregoing is Commi Name (Printed/Typed) JEREMY	Electronic Submission #4 For YATES PETRO itted to AFMSS for processi	82157 verified LEUM CORPO ng by DEBOR	RÁTION, sent to AH MCKINNEY o	Information System		SONSERVATION SIA DISTRICT T 0 2 2019	
Signature (Electronic S	Submission)		Date 09/06/20)19 <u>'.</u>	RE	CEIVED	
	THIS SPACE FO	R FEDERAI	OR STATE	OFFICE USE			
Approved By Conditions of approval, if any, are attached		Z l	Title SA	7		9-21-19 Date	
certify that the applicant holds legal or equivalent would entitle the applicant to conduct the second of the seco	nitable title to those rights in the act operations thereon.	subject lease	Office <i>CFO</i>	willfully to make to any de	enartment or	agency of the United	
Canada Cara Cara Cara Cara Cara Cara Cara C	totomonto on nomino enteti	and the unit per	in the first and the			-oo, or me omited	

Additional data for EC transaction #482157 that would not fit on the form

32. Additional remarks, continued

Spot a 25 SX (213 ft) CLS H cement plug 8167 ft - 8380 ft. WOC and Tag Plug. This will plug the Atoka.

Spot a 46 SX (391 ft) CLS H coment plug 7173 ft Z564 ft. WOC and Tag Plug. This will plug the Strawn and Ciseo.

Set CTBA 7388. Set 25 SX Class Spot a 25 SX Class Spot a 25 SX (213 ft) CLS H cement plug 5847 ft - 6060 ft. WOC and Tag Plug. This will plug the

Wolfcamp.

Spot a 25 SX (238 ft) CLS C cement plug 4596 ft - 4834 ft. WOC and Tag Plug. This will plug the Abo.

Spot a 25 SX (238 ft) CLS C cement plug 3992 ft - 4230 ft. WOC and Tag Plug. This will plug the Tubb.

Spot a 36 SX (344 ft) CLS C cement plug 2512 ft - 2856 ft. WOC and Tag Plug. This will plug the Yeso and Glorieta.

Perforate at 1482 ft. Attempt to establish Circulation. Spot a 25 SX (238 ft) CLS C cement plug 1244 ft - 1482 ft. WOC and Tag Plug. This will plug the 9.625 inch casing shoe.

Spot a 19 SX (95 ft) CLS C cement plug 0 ft - 95 ft. WOC and Tag Plug. This will plug the Top.


Perf @ 100/95 SQZ Cnf Surf.

T/Cisco C. Covers

^{8.} RDMO Workover Rig

^{9.} PXA Marker

^{9.1.} Cut off wellhead and weld on dry hole marker. Clean location as per regulation.



Sec-TWN-RNG: 28- T16S - R27E API: 30-015-33411 **LUCKY LOBO ASX FEDERAL #2** FOOTAGES: 660 FSL 1200 FEL GL: 3439 COMMENTS ্রী Plua Proposed KB: CASING DETAIL # HOLE SIZE SIZE WGHT GRADE Тор Bottom Sx Cmt Circ/TOC TOC Method Α 14 3/4 9 5/8 36 J55 0 1,432 1200 0 В 8 3/4 5 1/2 15.5 & 17 P110 0 9.170 2200 900 Calc - N. g., FORMATION TOPS Atoka 8330 TOC: 900' Strawn 7514 54 Cisco 7336 Wolfcamp 6010 Abo 4784 Tubb 4180 Yeso 2806 Glorieta 2700 10年70年30年30年 6 Plugs 5 Set CIBP at 9750 ft with 35 ft of CLS H on top. Spot a 25 SX (213 ft) CLS H cement plug 8167 ft - 8380 ft. WOC & Tag Plug. This will plug the Atoka. Spot a 46 SX (391 ft) CLS H cement plug 7173 ft - 7564 ft. WOC & Tag Plug. This will plug the Strawn & Cisco. Spot a 25 SX (213 ft) CLS H cement plug 5847 ft - 6060 ft. WOC & Tag Plug. This will plug the Wolfcamp. TOC 8399' Spot a 25 SX (238 ft) CLS C cement plug 4596 ft - 4834 ft. WOC & Tag Plug. This will plug the Abo. Spot a 25 SX (238 ft) CLS C cement plug 3992 ft - 4230 ft, WOC & Tag Plug. This will plug the Tubb. Packer @ 7332' 7 Spot a 36 SX (344 ft) CLS C cement plug 2512 ft - 2856 ft. WOC & Tag Plug. This will plug the Yeso & Glorieta. E PARTY CONTRACTOR Perforate at 1482 ft. Attempt to establish Circulation. Spot a 25 SX (238 ft) CLS C cement plug 1244 ft - 1482 ft. WOC & Tag Perf 7438 - 7610 Plug. This will plug the 9.625 inch casing shoe. Spot a 10 SX (95 ft) CLS C cement plug 0 ft - 95 ft. WOC & Tag Plug. This will plug the Top. RBP @ 7664 CIBP @ 8670 +30' cmt Perfs 8726-56 CIBP 8820 Perfs 8856-62 Prepared by: MJM Date: 5-Sep-2019 PBTD: 9,121 MD TD: 9,170 MD

BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90th day provide this office, prior to the 90th day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. Notification: Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
 - 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
 - 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of brime water. Minimum nine (9) pounds per gallon.
 - 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. <u>Dry Hole Marker</u>: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10th day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. <u>Show date well was plugged.</u>
- 8. <u>Trash:</u> All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation objectives.