
Submit 1 Copy To Appropriate District	State of New Me	exico	Form C-10	
Office District I – (575) 393 FRENED	Energy, Minerals and Natu		Revised August 1, 20	
$\frac{District 1}{1625 \text{ N. French Dr., Hobbs, NM 88240}}$	Znorg, minorals and Matt		WELL API NO.	
<u>District II</u> – (575) 748-1283	OIL CONSERVATION		30-015-27559	
811 S. First St., Artesia, NM \$821019 District III – (505) 334-6178			5. Indicate Type of Lease	
1000 Rio Brazos Rd., Aztec, NM 87410	1220 South St. Fran		STATE X FEE	
District IN SWARD THE SHAD C.D. 1220 S. St. Francis Dr., Santa Fe, NM	Santa Fe, NM 8	/505	6. State Oil & Gas Lease No.	
1220 S. St. Francis Dr., Santa Fe, NMP 87505	-		V708	
SUNDRY NOTIO	CES AND REPORTS ON WELLS		7. Lease Name or Unit Agreement Name	
(DO NOT USE THIS FORM FOR PROPOS				
DIFFERENT RESERVOIR. USE "APPLIC PROPOSALS.)	ATION FOR PERMIT" (FORM C-101) F	OR SUCH	EV STATE COM	
,	s Well X Other		8. Well Number	
			002	
2. Name of Operator			9. OGRID Number	
CHISHOLM ENERGY OPERATIN 3. Address of Operator	NG, LLC	•	372137 10. Pool name or Wildcat	
801 CHERRY ST., SUITE 1200, U	76102	HAPPY VALLEY, MORROW 78060		
	the zo, roter worth, reads		HALL AND LI, WORKOW 70000	
4. Well Location				
	100 feet from the NORTH lin		eet from the EAST line	
Section 32	Township 22S	8+	26E NMPM EDDY County	
	11. Elevation (Show whether DR			
	3,320' – G	<u>K</u>		
12. Check A	ppropriate Box to Indicate N	ature of Notice,	Report or Other Data	
NOTICE OF IN			SEQUENT REPORT OF:	
	PLUG AND ABANDON X			
	CHANGE PLANS			
PULL OR ALTER CASING		CASING/CEMEN		
OTHER:		OTHER:		
			d give pertinent dates, including estimated	
		C. For Multiple Co	mpletions: Attach wellbore diagram of	
proposed completion or reco	ompletion.	Notify OCD 24		
		ONY WORK	0,842'-9,652' (T/MRRW.); CIRC. WELL.	
	@ 8,656'-8,226' (7" DV TOOL, "			
	a) 5,016'-4,876' (T/BNSG.).	1, WOULD, WOUL	A TAO CMITTEOO.	
	a) 3,833'-3,703' (7" DV TOOL); V	WOC X TAG CMT	. PLUG.	
5) PUMP 30 SXS. CMT. (a 1,704'-1,598' (9-5/8" CSG.SHO	DE, T/DLWR.); WO	DC X TAG CMT. PLUG,	
6) MIX X CIRC. TO SUR	F. 95 SXS. CMT. @ 420'-3' (13-3	3/8" CSG.SHOE). 🗸	-Perf @ 420' + Attempt to Circ	
7) DIG OUT X CUT OFF	WELLHEAD 3' B.G.L.; WELD	ON STEEL PLATE	TO CSGS. X INSTALL DRY HOLE	
MARKER.				
	RE WE PLAN TO USE THE CLO UIRED DISPOSAL, PER OCD R		rem W/ A STEEL TANK AND HAUL	
CONTENTS TO THE REQ			ATTACHED COA'S - Perised	
		*** SEE A	ATTACHED	
handher antifis that the information	have is this and somelets to the -	est of my MUST B	E PLUGGED BY	
hereby certify that the information a		est of my woot of	1-11-1	
\sim	\mathcal{O} =	. •		
SIGNATURE	L'ITLE: AG	ENT	DATE: 12/09/19	
	AU AU			
Type or print name: DAVID A. EX	LER E-mail address: I	DEYLER@MILAG	RO-RES.COM PHONE: 432.687.3033	
For State Use Only				
		N	/ /	
APPROVED BY:	TITLE STA	H We-	DATE 12/12/19	
Conditions of Approval (if any):	·	P	/ / /	
			•	
			×	
1	· .			
		1	1	
· /				



		ERGY PRODUCT				- 1
Well Name: EV STATE Location: 2100' FNL &	660' FEL: SEC 32-T225-R2		HAPPY VALLE			
Elevation: 3334' KB; 33			Date: 10/16/96	State: NM Compl Date: 1/29/9	7	{
API#: 30-015-27559	Prepared by: BMS	Date:		Rev: 9/23/14		1
Current Wellbore 17-1/2" hole 13-3/8", 54.4#, J55, STC, Cmt'd w/400 Sx to surface				IRC. 95 5×5,	@ 420'-3 [']	
12-1/4" Hole <u>9-5/8", J55, 54.5#, LTC, (</u> Cmtd w/525 Sx to surface	3	M.L.F. M.L.F.		ump 30 SKS @	1,704 - 1,5	
Casing leak @ 5015'-503 Re-sqzd casing loak w/1	DV Tool @ 3768* 10°, sqzd w/200 sx. (7/18/08) 09 sx (7/24/08)	M.L.F.		mp 35 5×50		
tested to 1000 psi T/DLWR	DV Tool @ 8606'	M.L.F.		' mj) 100 545. mp 45 5×50		
TI BNSG		M.L.t.	De Do	mo 45 sxs0	P9,842	9,650
TIWCMP. ~		ET CO				
TI PENN	9,782 '		B indicates	' w/ 400# sand (17') parted casing @ 9,952' (4/12 sh out packer. (<i>Fishing Ops</i> 2/1		
4-1/2" Liner Top @ 10208	:			<u>cker @ 10,100'</u> (8/16708)		
<u>194 Jts-7", 23#, L80, LTC</u>			Arrowset Pa	<u>cker @ 10,100'</u> (8/16/08) ers & slips on top. <i>(7/14/08)</i> 225' w/blanking plug in place		I
	Set @ 10.466'		Arrowset Pa Packer rubb Packer @ 10	ers & slips on top. <i>(7/14/08)</i> 225' w/blanking plug in place	<u>(6/17/08)</u>	1
194 Jts-7", 23#, L80, LTC 9 Jts-7", 26#, N80, LTC. 5 Cmt'd w/1080 Sx, then bull <u>ATOKA</u> (6/17/08) 10478-10482'; 10502' <u>ATOKA</u> (6/12/08) 10741'- 52'; 10756'-64 10784'-87'; 10794'-804 Acidized 10741-10804 w/7500	<u>Set @ 10,466'</u> head top of 7" w/400 Sx -10510 [.] I'; 10772 ¹ -78'; 4'		Arrowset Pa Packer rubb Packer @ 10	ers & slips on top. <i>(7/14/08)</i> 225' w/blanking plug in place 200 thru plug @ 10,710' <i>(6/17</i>	<u>(6/17/08)</u>	1
194 Jts-7", 23#, L80, LTC 9 Jts-7", 26#, N80, LTC. 5 Cmt'd w/1080 Sx, then bull <u>ATOKA</u> (6/17/08) 10478-10482'; 10502' <u>ATOKA</u> (6/12/08) 10741'- 52'; 10756'-64 10784'-87'; 10794'-804 Acidized 10741-10804 w/7500 <u>MORROW</u> 11,106'- 11,112' 6 sp Acidized 11106-11112 w/105014	Set @ 10,466; head top of 7" w/400 Sx -10510: 1; 10772-78; 4 9 gata 15% HCI (8/13/08) 5f (12/7/06) 1 gata 7.5% HCI (12/2/06)		Packer rubb Packer @ 10 Composite f	ers & slips on top. <i>(7/14/08)</i> 225' w/blanking plug in place ow thru plug @ 10;710' <i>(6/17</i> 11/08) <i>(6/11/08)</i> D @ 11265'	<u>(6/17/08)</u>	1
194_Jts-7", 23#, L80, LTC, 9 9_Jts-7", 26#, N80, LTC, 5 Cmt'd w/1080 Sx, then bull ATOKA (6/17/08) 10478'-10482'; 10502' ATOKA (6/12/08) 10741'- 52'; 10756'-64 10784'-87'; 10794'-804 Acidized 10741'-10804 w/7500 MORROW 11,106'-11112 w/1000 Fraced 11106-11112 w/1000 Fraced 11106-11112 w/105516 MORROW 11,320'-11,328' 11,485'-11,400' 11,468'-11,472' 11,490'-11,493' 11,490'-11,576'	Set @ 10,466; head top of 7" w/400 Sx -10510: 1; 10772-78; 4 9 gata 15% HCI (8/13/08) 5f (12/7/06) 1 gata 7.5% HCI (12/2/06)		Arrowset Pa Packer rubb Packer @ 10 Packer @ 10 Sundry (7/2/97	ers & slips on top. <i>(7/14/08)</i> 225' w/blanking plug in place ow thru plug @ 10;710' <i>(6/17</i> 11/08) <i>(6/11/08)</i> D @ 11265'	<u>(6/17/08)</u>	- -

Υ.

• •

.

CONDITIONS FOR PLUGGING AND ABANDONMENT

OCD - Southern District

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work. After MIRU rig will remain on well until it is plugged to surface. OCD is to be notified before rig down. Company representative will be on location during plugging procedures.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs. Insure all bradenheads have been exposed, identified and valves are operational prior to rig up.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 7. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 8. Produced water will not be used during any part of the plugging operation.
- 9. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 10. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 11. Class 'C' cement will be used above 7500 feet.
- 12. Class 'H' cement will be used below 7500 feet.
- 13. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 14. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing.

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E)Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)

SITE REMEDIATION DUE WITHIN ONE YEAR OF WELL PLUGGING COMPLETION