Form 3160-5 (April 2004)

UNITED STATES DEPARTMENT OF THE INTERIOR

OCD-ARTESIA FORM APPROVED OMB No. 1004-0137 Expires: March 31, 2007

BUREAU OF LAND MANAGEMENT

٠.		
	NM23417	
		and the second s

SUNDRY NOTICES AND REPORTS O	NM23417			
Do not use this form for proposals to drill or abandoned well. Use Form 3160-3 (APD) for s	6. If Indian, Allottee or Tribe Name			
SUBMIT IN TRIPLICATE- Other instructions of	7. If Unit or CA/Agreement, Name and/or No.			
1. Type of Well Gas Well Other	RECEIVED	8. Well Name and No.		
2. Name of Operator Vates Energy Corporation	APR 2 5 2006	9. API Well No.		
3a Address	to timbute man fode) ESVA	30-015-23205		
4. Location of Well (Footage, Sec., T., R., M., or Survey Description)		10. Field and Pool, or Exploratory Area Empire Morrow South (Gas)		
1800' FSL and 2310' FEL of Sec. 17, T18 S, R29E		11. County or Parish, State		
1000 FGL and 2510 FGL 01 Get. 17, 110 S, R272		Eddy, New Mexico		
10 CHECK APPROPRIATE POWER NO DEDUCATE				
12. CHECK APPROPRIATE BOX(ES) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA				
TYPE OF SUBMISSION TYPE OF ACTION				
Notice of Intent Acidize Deepen Alter Casing Fracture T Casing Repair New Con		nt/Resume)		
Change Plans Plug and		andon		
Final Abandonment Notice Convert to Injection Plug Back	Water Disposal			
following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.) 1. Pull out of the hole with tubing and set a CIBP at 10,860' with 35' cement on top., or RBP. 2. Perforate the Atoka zone from 10,418' to 10,424' K.B. 3. Acidize and swab/flow test well. 4. Frac down production tubing, generic frac. 5. Put well into production system. 6. If Atoka formation is not commercial procede with the following. 7. Pull out of the hole with tubing and go back in the hole to set a CIBP at 10,380' with 35' of cement on top., or RBP. 8. Perforate the Strawn zone from 9986' to 10,010'. 9. Large acid job with nitrogen. 10. Put well into production system.				
14. I hereby certify that the foregoing is true and correct		10-21-06		
Name (Printed/Typed) Sheryl L. Jonas 432-63-5511	ENDING	70 7		
Signature Ally J. O. Conach	Title Agent for Yates Energ Date 0	y Corporation 4/13/2006		
THIS SPACE FOR FEDERAL OR STATE OFFICE USE				
Approved by Conditions of approval, if any, are attached. Approval of this notice does not warra certify that the applicant holds legal or equitable title to those rights in the subject le which would entitle the applicant to conduct operations thereon. Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any	ease Office	Date Date		