



UNITED STATES  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT  
**SUNDRY NOTICES AND REPORTS ON WELLS**

Do not use this form for proposals to drill or to re-enter an abandoned well. Use Form 3160-3 (APD) for such proposals

**OCD-ARTESIA**

FORM APPROVED  
OMB NO. 1004-0135  
EXPIRES: NOVEMBER 30, 2000

SUBMIT IN TRIPLICATE

**SEP 15 2008**

1a. Type of Well ☒ Oil Well ☐ Gas Well ☐ Other \_\_\_\_\_

2. Name of Operator  
**DEVON ENERGY PRODUCTION COMPANY, LP**

3. Address and Telephone No.  
**20 North Broadway, Ste 1500, Oklahoma City, OK 73102 405-552-4615**

4. Location of Well (Report location clearly and in accordance with Federal requirements)\*  
**2310 FNL 990 FWL Unit E Sec 6 T18S R27E**

5. Lease Serial No.  
**LC 069274**

6. If Indian, Allottee or Tribe Name

7. Unit or CA Agreement Name and No.

8. Well Name and No.  
**Fred Federal 2**

9. API Well No.  
**30-015-00801**

10. Field and Pool, or Exploratory  
**Red Lake; Queen Grayburg San Andres**

12. County or Parish 13. State  
**Eddy NM**

**CHECK APPROPRIATE BOX(s) TO INDICATE NATURE OF NOTICE, REPORT, OR OTHER DATA**

TYPE OF SUBMISSION	TYPE OF ACTION			
<input type="checkbox"/> Notice of Intent	<input type="checkbox"/> Acidize	<input type="checkbox"/> Deepen	<input type="checkbox"/> Production (Start/Resume)	<input type="checkbox"/> Water Shut-Off
<input checked="" type="checkbox"/> Subsequent Report	<input type="checkbox"/> Alter Casing	<input type="checkbox"/> Fracture Treat	<input type="checkbox"/> Reclamation	<input type="checkbox"/> Well Integrity
<input type="checkbox"/> Final Abandonment Notice	<input type="checkbox"/> Casing Repair	<input type="checkbox"/> New Construction	<input type="checkbox"/> Recomplete	<input type="checkbox"/> Other _____
	<input type="checkbox"/> Change Plans	<input checked="" type="checkbox"/> Plug and Abandon	<input type="checkbox"/> Temporarily Abandon	
	<input type="checkbox"/> Convert to Injection	<input type="checkbox"/> Plug Back	<input type="checkbox"/> Water Disposal	


13. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work and approximate duration thereof. If the proposal deepens directionally or recompletes horizontally, give subsurface location and measured and true vertical depths of all pertinent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirement, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection)

1. 9/3/08: MIRU. TIH to CIBP @ 1731'. Circulate wellbore w/10 ppg mud.
2. Spot 25 sx cement in 5-1/2" casing on top of CIBP from 1731' to 1491'.
3. Spot 25 sx cement @ 1028'. Tagged TOC @ 810'. (8-5/8" casing shoe @ 978').
4. Spot 25 sx cement surface plug @ 240'
5. 9/4/08: Cut wellhead off. Fill 8-5/8" x 5-1/2" casing with cement. Set dry hole marker and clean location.

ACCEPTED FOR RECORD

**SEP 16 2008**

Gerry Guye, Deputy Field Inspector  
NMOCD-District II ARTESIA



14. I hereby certify that the foregoing is true and correct

Signed Ronnie Slack Name Ronnie Slack  
Title Engineering Technician Date 9/4/2008

(This space for Federal or State Office use)

Approved by \_\_\_\_\_ Title \_\_\_\_\_ Date \_\_\_\_\_  
Conditions of approval, if any: \_\_\_\_\_

**DEVON ENERGY PRODUCTION COMPANY LP**

Well Name: FRED FEDERAL #2		Field: RED LAKE	
Location: 2310' FNL & 990' FWL; SEC 6-T18S-R27E		County: EDDY	State: NM
Elevation: 3378' GL		Spud Date: 11/30/58	Compl Date: 1/12/59
API#: 30-015-00801	Prepared by: Ronnie Slack	Date: 9/4/08	Rev:

PLUGGED & ABANDONED 9/4/08

1. Spot 25 Sx from 240' to surface. (9/4/08)
2. Cut wellhead off. Fill 8-5/8" x 5-1/2" casing w/cement. Set dry hole marker. (9/4/08)
3. Clean location.

10-3/4"  
8-5/8", 32#, 8RD, @ 978'  
Cmt'd w/350 Sx

25 Sx cement 1028'. Tagged TOC @ 810'. (9/4/08)

10 ppg mud

10 ppg mud

25 Sx cement on CIBP from 1731' to 1491' (9/3/08)

CIBP @ 1,731' (3/4/08)

SAN ANDRES  
1,742' - 1,760' (1/12/59)

1,772' - 1,784' (1/28/66)

5-1/2", 14#, J55, 8RD, @ 1,855'  
Cmt'd w/400 Sx cmt, circulated

1,855' TD