

FEB -9 2009

Form C-103

May 27, 2004

Submit 3 Copies To Appropriate District

Office

District I

1625 N French Dr, Hobbs, NM 87240

District II

1301 W. Grand Ave, Artesia, NM 88210

District III

1000 Rio Brazos Rd., Aztec, NM 87410

District IV

1220 S St Francis Dr, Santa Fe, NM 87505

State of New Mexico
Energy, Minerals and Natural ResourcesOIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

WELL API NO.

30-015-22808

5. Indicate Type of Lease

STATE ☒ FEE ☐6. State Oil & Gas Lease No.
E-78337. Lease Name or Unit Agreement Name:
Empire Abo Unit 'L'

8. Well Number

156

9. OGRID Number

00778

10. Pool name or Wildcat
Empire Abo

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS)

1. Type of Well:

Oil Well ☒ Gas Well ☐ Other ☐

2. Name of Operator

BP America Production Company

3. Address of Operator

P.O. Box 1089 Eunice NM 88231

4. Well Location

Unit Letter 0 : 600 feet from the S line and 1330 feet from the E lineSection 2 Township 18S Range 27E NMPM County Eddy

11. Elevation (Show whether DR, RKB, RT, GR, etc.)

3574.8' GR

Pit or Below-grade Tank Application ☐ or Closure ☐

Pit type _____ Depth to Groundwater _____ Distance from nearest fresh water well _____ Distance from nearest surface water _____

Pit Liner Thickness: _____ mil Below-Grade Tank: Volume _____ bbls; Construction Material _____

12. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐TEMPORARILY ABANDON ☐ CHANGE PLANS ☐PULL OR ALTER CASING ☐ MULTIPLE COMPLETION ☐OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☒CASING TEST AND CEMENT JOB ☐OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1/27/09: RU, LOAD & KILL TBG, ND WELLHEAD & NU -BOP, UNSET LOCSET-PKR, POOH LAYING DOWN
 1/28/09: POOH LD TBG & PKR. UNLOAD WORK STRING ON RACK'S. TALLEY TBG WORK STRING, MU CIBP & TIH PU FROM RACK. TAG UP @ 5665'.
 1/29/09: POOH W/ CIBP, LAY DOWN CIBP. MAKE UP BIT & SCRAPER, TIH TO 5917', TAG UP 5665' WORK SCRAPER THRU 4 TO 5 TIMES UNTIL TRAVEL WAS FREE. PU 8 JTS TO REACH 5917'. POOH W / BIT & SCRAPER. MAKE UP CIBP & TIH TO 5870' SET & RELEASE SETTING TOOL LAY DN ONE JT & PICK UP 10' SUB, SI-BOP & LOAD HOLE W /FW, SI WELL & PRESS TEST CSG & CIBP TO 500 PSI. OK
 Continued on page 2.

I hereby certify that the information above is true and complete to the best of my knowledge and belief. I further certify that any pit or below-grade tank has been/will be constructed or closed according to NMOCD guidelines ☐ , a general permit ☐ or an (attached) alternative OCD-approved plan ☐

SIGNATURE

TITLE Area Operations Team Lead DATE 2/5/09

E-mail address:

barry.price@bp.com

Type or print name Barry C. Price

Telephone No. 575-394-1648

For State Use Only

Accepted for record

APPROVED BY

NMOCD

TITLE

Conditions of Approval, if any:

Approved for plugging of well bore only.
 Liability under bond is retained pending receipt
 of C-103 (Subsequent Report of Well Plugging)
 which may be found at OCD Web Page under DATE 2/7/09
 Forms: www.emnrd.state.nm.us/oed.

Form C-103
Empire Abo Unit L-156
30-015-22808
Continued from Page 1

1/30/09: PUMP 25 SXS CLASS - C FROM 5870' - 5623' 14.8 PPG. POOH LD TBG TO 5572' PUMP & LOAD HOLE WITH PLUG MUD. POOH LAYING DOWN TO 4129'. MIX & SPOT 25 SXS CLASS-C FROM 4129' TO 3882' 14.8 PPG. POOH TO 3450', HOOK UP EQUIP. MIX & SPOT 25 SXS CLASS-C FROM 3450' TO 3203'. POOH & LAY DOWN 10 JTS STAN BACK 20. WOC.

2/2/09: POOH & LD SETTING TOOL FOR CIBP. MAKE UP PERF SUB & RIH & TAG CMT @ 3195'. POOH LAYING DOWN TO 1120'.

2/3/09: SPOT 25 SXS CLASS-C CMT FROM 1120'. POOH TO WOC. WOC. RIH & TAG CMT @ 920'. POOH LD TBG. RIG DOWN FLOOR & ND BOP. PICK UP 8 JTS TBG, RIH TO 250' SPOT 25 CLASS-C FROM 250' TO SURF, POOH LD TBG, TOP OFF HOLE WITH CMT.

2/4/09: DIG OUT AROUND WELLHEAD. CUT OFF ALL ANCHORS AND WELL HEAD, WELD IN PLATE, 1" NIPPLE & VALVE, DRY HOLE MARKER, BACKFILL AND LEVEL LOCATION.