Submit 3 Copies To Appropriate District Office	State of New Mexico	FEB 1 0 2009 Form C-	
District I  1625 N. French Dr., Hobbs, NM 88240	nergy, Minerals and Natural Resources	May 27, WELL API NO.	2004
District II	OIL CONSERVATION DIVISION	30-015-00307	
District III	1220 South St. Francis Dr.	5. Indicate Type of Lease  STATE FEE	
1000 Rio Brazos Rd., Aztec, NM 87410 District IV	Santa Fe, NM 87505	► 6. State Oil & Gas Lease No.	
1220 S. St Francis Dr , Santa Fe, NM 87505		3	
	ND REPORTS ON WELLS	7. Lease Name or Unit Agreement Nam	ne
(DO NOT USE THIS FORM FOR PROPOSALS TO DIFFERENT RESERVOIR. USE "APPLICATION		ATOKA SAN ANDRES UNIT	
PROPOSALS.)  1. Type of Well: Oil Well Gas Well	ell Other <u>INJECTION WELL</u>	8. Well Number	
2. Name of Operator  DEVON ENERGY PRODUCTION COMPANY, LP		9. OGRID Number 6137	
3. Address of Operator		10. Pool name or Wildcat	
20 North Broadway, Ste 1500, Oklahom	a City, OK 73102 405-552-4615	SAN ANDRES	
4. Well Location Unit Letter N: 330'	feet from the _SOUTH line and _23	10' feet from the WEST line	
Section 11	Township 18S Range 26E	NMPM County EDDY	7
	Elevation (Show whether DR, RKB, RT, GR,	· · · · · · · · · · · · · · · · · · ·	
Pit or Below-grade Tank Application ☐ or Closure			
Pit typeDepth to Groundwater		Dictance from negrest surface water	
·		Construction Material	
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data			
• •		•	
NOTICE OF INTENT PERFORM REMEDIAL WORK ☐ PLUC	TION TO: SU GIAND ABANDON ☐ REMEDIAL W	JBSEQUENT REPORT OF: ORK ALTERING CASING	
	= 1	ORIC ☐ ALTERING GAGING  DRILLING OPNS.☐ P AND A ☒	Ц
	TIPLE COMPL		
OTHER:	□ OTHER:		
13. Describe proposed or completed or	perations. (Clearly state all pertinent details,	and give pertinent dates, including estimated	d date
of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.			
or recompletion.			
4 4/40/00 MIDLL BOOLL w/ 2 2/	0" 4h: 2 4 402		
<ol> <li>1/16/09: MIRU. POOH w/ 2-3/8" tubing &amp; packer from 1,463'.</li> <li>TIH w/CIBP &amp; set @ 1,475'. Dump 35' cement on top. (San Andres perfs from 1,517' to 1,669')</li> </ol>			
3. Circulate wellbore w/10 ppg mud.			
4. Spot 25 sx cement plug in 5-1/2" production casing @ 1,230'. Tagged TOC @ 1001'. (8-5/8" casing shoe @ 1,178'). 5. Cut 5-1/2" casing @ 800' and POOH w/casing.			
6. Spot 30 sx cement stub plug @ 850'. Tagged TOC @ 674'.			
7. Spot 30 sx cement from 110' to	surface.		
<ol> <li>Removed wellhead, set P&amp;A magnetic</li> <li>2/6/09-Plugged &amp; Abandoned.</li> </ol>	arker, cleaned location.		
3. 2/0/03-1 lugged & Aballdolled.			
	is true and complete to the best of my knowl		
1 1 1	ccording to NMOCD guidelines □, a general permi	t 🔲 or an (attached) alternative OCD-approved plan	n ∐.
SIGNATURE KOMME Sfac	TITLE Engineering	Technician DATE 2/6/09	_
Type or print name Ronnie Slack	E-mail address: Ronnie.Slack@d	vn.com Telephone No. 405-552-4615	
For State Use Only			
APPROVED BY:	TITLE	DATE	_
Conditions of Approval (if any):	Accepted for record NMOCD		uk

