

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505



WELL API NO. 30-005-60675
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/> X
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name J. G. O'Brien (11602)
8. Well Number 001
9. OGRID Number 24581
10. Pool name or Wildcat Elkins; Fusselman, South (21720)

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other

2. Name of Operator
Walter Exploration, Inc

3. Address of Operator
6116 N Central Expressway #313, Dallas TX 75206

4. Well Location
Unit Letter E (Lot 2) : 1980 feet from the North line and 660 feet from the West line
Section 31 Township 7-S Range 29-E NMPM County Chaves

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
GL 4020

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☐
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PANDA ☒ X
CASING/CEMENT JOB ☐

OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

1. Rig up J&B Well Servicing. Install BOP. RIH with tubing and tag existing CIBP with 35' cement on top at 6612'.
2. Circulate hole with 9.5# mud. POH to 6037 pot 25 sx cement. Wolfcamp plug 6025-5925.
3. POH tubing. RIH wireline and perf at 5264' and 3056'.
4. RIH with packer set at 4765'to squeeze perfs at 5264'. Would not squeeze. Released packer RIH to 5273' and spotted 25 sx. WOC and tag at 5098'.
5. POH to 2500'. Set packer to squeeze perfs at 3056'. Pumped 120 sx cement covering Glorietta and intermediate shoe. WOC and tag at 2550'.
6. POH tubing. RIH wireline and perf at 784' and 461'.
7. RIH to 550' set packer and squeeze perf at 784'. WOC and tag at 711'. TOC was 27' low. Spot 10 additional sx cement. WOC and tag at 615'.
8. Lay down remaining tubing. Rig up on 5 1/2 casing. Pumped 155 sx cement down 5 1/2 casing to perfs at 461' and up annulus to surface covering Yates and surface shoe.
9. Rig down, cut off wellhead, installed marker, removed anchors, and filled in cellar.

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

J. B. ...

TITLE

U. A.

DATE

6-22-09

Type or print name

J. B. ...

E-mail address:

brim@wmt-x.com

PHONE:

(214) 365-4564

For State Use Only

APPROVED BY:

[Signature]

TITLE

Approved for plugging of well bore only.
Liability under bond is retained pending receipt of C-403 (Subsequent Report of Well Plugging) which may be found at OCD Web Page under Forms. www.emnrd.state.nm.us/oed.

DATE

6/26/09

Conditions of Approval (if any):