Submit 3 Copies to Appropriate
District Office

State of New Mexico Energy, Minerals and Natural Resources Department

Form C-103 Revised 1-1-89

JAN 28 2004

DISTRICT I

CONDITIONS OF APPROVAL, IF ANY:

OIL CONSERVATION DIVISION

WELL API NO.

P.O. Box 1980, Hoods NM 88240	2040 South Pach		30-015-01464
DISTRICT II 811 South First, Artesia, NM 88210	Santa Fe, New Mexico 87505		5. Indicate Type of Lease STATE FEE
DISTRICT III 1000 Rio Brazos Rd, Aztec, NM 87410			6. State Oil & Gas Lease No.
			B-2178
SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS).			
			7. Lease Name or Unit Agreement Name
1. Type Of Well: OIL GAS WELL WELL		RECEIVED	Red Lake Sand Unit
2. Name of Operator		JAN 2 6 7004	8. Well No. 24
Mack Energy Corporation 3. Address of Operator		CD-ARTESIA	9, Pool name or Wildcat
P.O. Box 960, Artesia, NM 8821			Red Lake; Queen-Grayburg-SA
4. Well Location			
Unit Letter K: 23	10 Feet From The South	Line and 16	50 Feet From The West Line
Section 20	Township 17S R	ange 28E	NMPM Eddy County
	10. Elevation (Show whether	**··5°	Johns
Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data			
			SEQUENT REPORT OF:
PERFORM REMEDIAL WORK	PLUG AND ABANDON	REMEDIAL WORK	ALTERING CASING
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. PLUG AND ABANDONMENT			
PULL OR ALTER CASING		CASING TEST AND CE	EMENT JOB
OTHER:	П	OTHER	
12. Describe Proposed or Completed	Operations (Clearly state all pertinent detail		luding estimated date of starting any proposed
12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.			
Mack Energy Corporation proposes to plug and abandon well as follows:			
1. Notify OCD 24 hours prior to sta 2. Set 100' cement plug from 1925- 3. Circulate hole with mud gel. 4. Perforate @ 594' squeeze 100' ce 5. Perforate @ 300' squeeze 100' ce 6. Perforate @ 60' circulate cement 7. Install dry hole marker.	ement 50' above and below 8 5/8 ca ement back to 200'. Perf. Both s to surface. Strings =	sing. WOC and tag. drings 's place 100 300' 300' rings 's place 60' '-60' - WOC - 20	o'opent. Inside foutside of both o'of ent. inside & outside of both
I hereby certify that the information above is tr	ue and complete to the best of my knowledge and TIT	Producti	on Clerk DATE 1/24/04 TELEPHONE NO.
(This space for State Use)	del	Till	Les D JAN 2 . 200
APPROVED BY	TIT	LE	DATE

MACK ENERGY CORPORATION RED LAKE SAND UNIT #24 Sec 20 T17S R28E 2310FSL 1650FWL

| '8 5/8"-28# | 8 5/8"-28# Set @ 544' w/50sks

5 1/2" 14# @ 1887' C/w 50sks

OPEN HOLE 1887'-1925'

- 1. Notify OCD 24 hrs. prior to any work done.
- 2.Set 100' cmt plug 1925-1825' and tag.
- 3.Circ hole with mud gel.
- 4.Perf @ 594' squeeze 100' cmt plug 50' above & below 8 5/8" and tag.
- 5. Perf @ 300' squeeze 100' cmt plug 50' above & below back to 200'
- 6. Perf @ 60' circ cmt to surface
- 7. Install Dry Hole Marker