

Submit 3 Copies
to Appropriate
District Office

State of New Mexico
Energy, Minerals and Natural Resources Department

Form C-103
Revised 1-1-89

DISTRICT I
P.O. Box 1980, Hobbs NM 88240

DISTRICT II
811 South First, Artesia, NM 88210

DISTRICT III
1000 Rio Brazos Rd, Aztec, NM 87410

OIL CONSERVATION DIVISION
2040 South Pacheco
Santa Fe, New Mexico 87505

WELL API NO.
30-015-01610

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
B-5084

7. Lease Name or Unit Agreement Name

Red Lake Sand Unit

8. Well No.
13

9. Pool name or Wildcat
Red Lake; Queen-Grayburg-SA

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"
(FORM C-101) FOR SUCH PROPOSALS).

1. Type Of Well:
OIL WELL ☒ GAS WELL ☐ OTHER

RECEIVED

2. Name of Operator
Mack Energy Corporation

JAN 22 2004

3. Address of Operator
P.O. Box 960, Artesia, NM 88211-0960

OCD-ARTESIA

4. Well Location

Unit Letter A : 330 Feet From The North Line and 990 Feet From The East Line

Section 29 Township 17S Range 28E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11. Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐
CASING TEST AND CEMENT JOB ☐
OTHER: ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Mack Energy Corporation proposes to plug and abandon well as follows:

1. Notify OCD 24 hours prior to starting plugging operations.
2. Set 100' cement plug from 1779-1679'. WOC and tag.
3. Circulate hole with mud gel.
4. Perforate @ 495' squeeze 100' cement 50' above and below 8-5/8 casing. WOC and tag. *Place cnt inside; outside of csg from 370'-495' - TAG*
5. Perforate @ 220' squeeze 100' cement back to 120'.
6. Perforate @ 60' circulate cement to surface. *Both strings - WOC - 24 HRS TAG*
7. Install dry hole marker.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Jerry W. Sherrell TITLE Production Clerk DATE 1/22/04

TYPE OR PRINT NAME

Jerry W. Sherrell

TELEPHONE NO.

(This space for State Use)

APPROVED BY _____ TITLE _____ DATE _____

CONDITIONS OF APPROVAL, IF ANY:

STATE

MACK ENERGY CORPORATION
RED LAKE SAND UNIT #13
Sec29 T17S R28E 330 FNL 990 FEL

'8 5/8"-28#

1. Notify OCD 24 hrs. prior to any work done.
2. Set 100' plug 1779'-1679' & tag.
3. Circ hole with mud gel.
4. Perf @ 495' squeeze 100' cmt plug 50' above & below 8 5/8" and tag.
5. Perf @ 220' squeeze 100' cmt plug 50' above & below back to 120'.
- 6.. Perf @ 60' circ cmt to surface
7. Install Dry Hole Marker

8 5/8" 28# @445' c/w 50sx.

7"20# @ 1729' c/w 100sx

Open hole 1729-1920'