

Submit 3 Copies  
to Appropriate  
District Office

State of New Mexico  
Energy, Minerals and Natural Resources Department

Form C-103  
Revised 1-1-89

DISTRICT I  
P.O. Box 1980, Hobbs NM 88240

OIL CONSERVATION DIVISION  
2040 South Pacheco  
Santa Fe, New Mexico 87505

DISTRICT II  
811 South First, Artesia, NM 88210

DISTRICT III  
1000 Rio Brazos Rd, Aztec, NM 87410

WELL API NO.

30-015-01612

5. Indicate Type of Lease

STATE ☒

FEE ☐

6. State Oil & Gas Lease No.

B-11538

7. Lease Name or Unit Agreement Name

Red Lake Sand Unit

8. Well No.

12

9. Pool name or Wildcat

Red Lake; Queen-Grayburg-SA

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A  
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT"  
(FORM C-101) FOR SUCH PROPOSALS).

1. Type Of Well:

OIL ☒  
WELL

GAS ☐  
WELL

OTHER

RECEIVED

2. Name of Operator

Mack Energy Corporation

JAN 22 2004

3. Address of Operator

P.O. Box 960, Artesia, NM 88211-0960

OCD-ARTESIA

4. Well Location

Unit Letter B : 330 Feet From The North Line and 1650 Feet From The East Line

Section 29 Township 17S Range 28E NMPM Eddy County

10. Elevation (Show whether DF, RKB, RT, GR, etc.)

11.

Check Appropriate Box to Indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐

COMMENCE DRILLING OPNS. ☐ PLUG AND ABANDONMENT ☐

CASING TEST AND CEMENT JOB ☐

OTHER ☐

12. Describe Proposed or Completed Operations (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work) SEE RULE 1103.

Mack Energy Corporation proposes to plug and abandon well as follows:

1. Notify OCD 24 hours prior to starting plugging operations.

2. Set 100' cement plug from 1850-1750'. WOC and tag.

3. Circulate hole with mud gel.

4. Perforate @ 458' squeeze 100' cement 50' above and below 8 5/8 casing. WOC and tag.

6. Perforate @ 60' circulate cement to surface.

7. Install dry hole marker.

*inside & outside of both strings  
Perf Both strings place 60' of cement inside & outside of  
both strings 0'-60' woc 24 hrs - Tag*

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE

*Jerry W. Sherrell*

TITLE

Production Clerk

DATE

1/22/04

TYPE OR PRINT NAME

Jerry W. Sherrell

TELEPHONE NO.

(This space for State Use)

APPROVED BY

*[Signature]*

TITLE

*[Signature]*

DATE

JAN 28 2004

CONDITIONS OF APPROVAL, IF ANY:

STATE

MACK ENERGY CORPORATION  
RED LAKE SAND UNIT #12  
Sec29 T17S R28E 330FNL 1650FEL

'8 5/8"-28#

1. Notify OCD 24 hrs. prior to any work done.
2. Set 100' cmt plug 1850-1750' and tag.
3. Circ hole with mud gel.
4. Perf @ 458' squeeze 100' cmt plug 50' above & below 8 5/8" and tag.
5. Perf @ 60' circ cmt to surface
6. Install Dry Hole Marker

8 5/8"-28# Set @ 408' w/50sks

7" -20# Set @ 1800' w/100sks

OPEN HOLE 1800-1920'