Submit I Copy To Appropriate District Office	State of New Me		Form C-103 RM
District I 1625 N French Dr , Hobbs, NM 88240	Energy, Minerals and Natu	ral Resources	October 13, 2009 WELL API NO.
District 1301 W Grand Ave, Artesia, NM 88210	OIL CONSERVATION DIVISION		30-015-21478
District III 1000 Rio Brazos Rd, Aztec, NM 87410	1220 South St. Francis Dr.		5. Indicate Type of Lease STATE FEE FEE
District IV 1220 S St Francis Dr, Santa Fe, NM		/505	6. State Oil & Gas Lease No. K-6096
(DO NOT USE THIS FORM FOR PROPO	ICES AND REPORTS ON WELLS SALS TO DRILL OR TO DEEPEN OR PLU CATION FOR PERMIT" (FORM C-101) FO Gas Well Other IM 88210 660 feet from the South	UG BACK TO A OR SUCH	7. Lease Name or Unit Agreement Name NDDUP Unit 8. Well Number 138 9. OGRID Number 025575 10. Pool name or Wildeat Dagger Draw; Upper Penn, North 980 feet from the West line
Section 28		nge 25E	NMPM Eddy County
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3506'GR			
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data			
NOTICE OF IN PERFORM REMEDIAL WORK TEMPORARILY ABANDON PULL OR ALTER CASING	ITENTION TO: PLUG AND ABANDON ⊠ CHANGE PLANS □ MULTIPLE COMPL □	SUBS REMEDIAL WORK COMMENCE DRIL CASING/CEMENT	LING OPNS. P AND A
DOWNHOLE COMMINGLE	_		
OTHER:		OTHER:	
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. Yates Petroleum Corporation plans to plug and abandon this well as follows: 1. NU BOP. Rug up any safety equipment as needed. No casing recovery will be attempted. 2. Set a CIBP at 7633' with 35' cement on top. This will place a plug over open Canyon perforations and damaged casing. 3. Spot a 160' cement plug from 6000'-6160'. This will leave a plug across Wolfcamp top. 4. Perforate at 3240'. Pressure test perforations to 500 psi, if they hold pressure spot a 140' cement plug inside casing, if not spot a 140' cement plug inside and outside casing from 3100'-3240'. WOC and tag plug, reset if necessary. This will leave a plug across Bone Spring top. 5. Perforate at 2288'. Pressure test perforations to 500 psi, if they hold pressure spot a 120' cement plug inside casing, if not spot a 120' cement plug inside and outside casing from 2168'-2288'. WOC and tag plug, reset if necessary. This will leave a plug across Glorieta top. 6. Perforate at 1348'. Pressure test perforations to 500 psi, if they hold pressure spot a 150' cement plug inside casing, if not spot a 150' cement plug inside and outside casing from 1198'-1348'. WOC and tag plug, reset if necessary. This will leave a plug across Glorieta top. 6. Perforate at 314'. Tie on to casing and spot a 514' cement plug inside and outside casing, if not spot a 150' cement plug inside and outside casing from 198'-1348'. WOC and tag plug, reset if necessary. This will leave a plug across intermediate casing shoe. 7. Perforate at 514'. Tie on to casing and spot a 514' cement plug inside and outside casing from 0-514'. WOC and tag plug, reset if necessary. This will leave a plug from 514' to surface and surface casing shoe. 8. Remove all surface equipment and weld dry hole marker per			
I hereby certify that the information above is true and complete to the best of my knowledge and belief.			
SIGNATURE (Sine therte TITLE Regulatory Compliance Supervisor DATE June 7, 2010			
Type or print name Tina Huerta E-mail address: tinah@yatespetroleum.com PHONE: 575-748-4168 For State Use Only			
APPROVED BY: Conditions of Approval (if any):	TITLE I	Approval Granted provise complete by	viding work DATE 6/9/200



