# UNITED STATES DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT

FORM APPROVED OMB NO. 1004-0135 Expires: July 31, 2010

B	Expires: July 31, 2010						
SUNDRY	5. Lease Serial No. NMNM17095						
Do not use th	6. If Indian, Allottee or Tribe Name						
abandoned we	o. If indian, Another of Tribe Name						
SUBMIT IN TRI	7. If Unit or CA/A	greement, Name an	d/or No.				
1. Type of Well					8. Well Name and		
Oil Well Gas Well Ot  2. Name of Operator		LINDA GOOL			9. API Well No.		
CHESAPEAKE OPERATING	, INC. E-Mail: linda.good@	@chk.com	•		30-015-2555	9	
3a. Address P.O. BOX 18496 OKLAHOMA CITY, OK 7315	4-0496	3b. Phone No. Ph: 405-93	(include area cod 5-4275	le)	10. Field and Pool UNKNOWN	or Exploratory	
4. Location of Well (Footage, Sec., )	T., R., M., or Survey Description	1)			<ol><li>County or Pari</li></ol>	sh, and State	
Sec 1 T21S R27E SESE 660  D C 12. CHECK APP  D C YPE OF SUBMISSION  Notice of Intent  Subsequent Report	FNL 660FEL				EDDY COUN	ITY, NM	
D 12. CHECK APP.	ROPRIATE BOX(ES) TO	INDICATE	NATURE OF	NOTICE, RE	PORT, OR OTH	HER DATA	
TYPE OF SUBMISSION			ТҮРЕ (	OF ACTION			
Notice of Intent	☐ Acidize	☐ Deep	en	□ Production	on (Start/Resume)	☐ Water Sl	nut-Off
	☐ Alter Casing	□ Fract	ure Treat	☐ Reclamat	ion	□ Well Inte	egrity
	Casing Repair	_	Construction	□ Recompl		Other	
☐ Final Abandonment Notice	Change Plans	■ Plug	Plug and Abandon		☐ Temporarily Abandon		
	Convert to Injection	□ Plug	Back	□ Water Di	sposal		
13. Describe Proposed or Completed Op If the proposal is to deepen direction Attach the Bond under which the wo following completion of the involved testing has been completed. Final A determined that the site is ready for	nally or recomplete horizontally, a pork will be performed or provide doperations. If the operation resubandonment Notices shall be file	give subsurface I the Bond No. on sults in a multiple	ocations and mea file with BLM/B completion or re	sured and true ver IA. Required sub ecompletion in a n	tical depths of all pe sequent reports shal ew interval, a Form	ertinent markers and I be filed within 30 3160-4 shall be file	d zones.  days ed once
CHESAPEAKE, RESPECTFU	JLLY REQUESTS PERMI	SSION TO P8	A THIS WELL	PER THE FO	LLOWING PRO	CEDURE:	
1. MIRU PU. Unseat pump & standing back 84 jts of tbg &	POOH laying down rods & LD remaining tbg and BH/	& pump. NDW A. Circulate w	H, NUBOP. Pell w/9 # mud.	OOH w/tbg & E	BHA while	E E	ARTESIA
2. MIRU E-line w/portable ma Set CIBP @ ?2,825'. Dump 3	stcrane & pressure contro 5' cmt on it by dump baile	ol. Run gauge r.	ring and junk	basket to ?2,8	50'.	EIVE 28 2011	_ 1
3. RD É-line & RU PU. RIH w	open-ended tbg & spot ba	alanced cmt p	lug @2,660-2	,560'. WOC &	tag plug.	M M	잉
	NATION PROCEDURE ATTACHED	& tag plug.	_	ATTACHE DITIONS	ED FOR OF APPRO		NMOCD
14. Thereby certify that the foregoing is	s true and correct. Electronic Submission #1 For CHESAPEAR	101009 verified KE OPERATING	by the BLM W G, INC., sent to	ell Information the Carlsbad	System		
Name (Printed/Typed) LINDA GO	DOC		Title SR R	EGULATORY	COMPLIANCE	SPEC	
Signature (Electronic	Submission)	1	Date 01/21/	2011		·	
	THIS SPACE FO	R FEDERA	L OR STATE	<b>OFFICIELYS</b>	MFD		
Approved By	WILL		Title			Date	
Conditions of approval, if any, are attach certify that the applicant holds legal or eq which would entitle the applicant to cond	quitable title to those rights in the	not warrant or e subject lease	Office /s	JAN 25 Dustin V			

Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowing United With the Wi

# .Additional data for EC transaction #101009 that would not fit on the form

## 32. Additional remarks, continued

- 5. PUH and spot balanced cmt plug @ 60'-surface.
- 6. NDBOP & Weld on ID plate. RDMO. Remove all equipment and restore location.


Clean and reclaim location.

(CHK PN 890972)

# Chesapeake

#### **Proposal Schematic**

#### **GOVERNMENT D 13**



# Chesapeake Operating, Inc. Government D 13 P&A Procedure Section 1-21S-27E 660 FSL & 660 FEL Eddy County, New Mexico

# January 19, 2011

Status:

Shut in

Perforations:

2,871-2,909 (Delaware); 3,069-3,081 (Delaware); 5,604-5,624 (CIBP-

**Bone Springs)** 

TD:

5,710'

PBTD:

3,180

KB:

13'

Fluid in Well:

**Production** 

#### **Casing Details**

OD (in)	Weight (lb/ft)	Grade	Depth (ft)	ID (in)	Drift (in)	Capacity (bbls/ft)	Burst (100%/70% psi)	Collapse (100%/70% psi)
5 1/2	14.0	K-55	0-5,710	5.012	4.887	0.0244	4,270/2,989	3,120/2,184
9 5/8	43.5	S-95	0-2,610	8.755	8.599	0.0744	7,510/5,257	5,600/3,920
13 3/8	48.0	S-95	0-645	12.715	12.559	0.1570	?	?

## **Production Tubing Details**

OD (in)	Weight (lb/ft)	Grade	Depth (ft)	ID (in)	Drift (in)	Capacity (bbls/ft)	Burst (100%/70% psi)	Collapse (100%/70% psi)
2 7/8	6.5	J-55*	0-3,071	2.441	2.347	0.00579	7,260/5,082	7,680/5,376

<sup>\*</sup>Grade unknown, J-55 is best guess to in-hole grade

#### PROCEDURE:

- 1. MIRU PU. Unseat pump & POOH laying down rods & pump. NDWH, NUBOP. POOH w/tbg & BHA while standing back 84 jts of tbg & LD remaining tbg and BHA. Circulate well w/9 # mud.
- 2. MIRU E-line w/portable mastcrane & pressure control. Run gauge ring and junk basket to ±2,850'. Set CIBP @ ±2,825'. Dump 35' cmt on it by dump bailer.
- 3. RD E-line & RU PU. RIH w/open-ended tbg & spot balanced cmt plug @2,660-2,560'. WOC & tag plug.

Created by Neevia Document Converter trial version http://www.neevia.com

Chesapeake Operating Inc. NM-17095: Government D #13 API: 30-015-25559 Eddy County, New Mexico

RE: Plugging and Abandonment Requirements, Conditions of Approval

- 1. OK
- 2. Change: Spot 30sx on top of CIBP Otherwise OK (Perfs Delaware Casing shoe)
- 3. Move: Spot cement from 1610'-1490' (minimum 25sx). Tag at 1490' or shallower Otherwise OK (Capitan Reef BOS)
- 3a. Spot a 110' plug from 1250'-1140' (minimum 25sx). WOC and tag at 1140' or shallower. (TOS)
- 4. Minimum 25sx. Tag at 585' or shallower Otherwise OK (Casing shoe)
- 5. Change: Spot cement (approx 45sx) from 400' to surface. (Cave/Karst Surface)
- 6. Verify that all annuluses have cement to surface and fill in as required Otherwise OK
- 7. Submit a subsequent report to the BLM.

H<sub>2</sub>S monitoring equipment shall be on location.

See attached standard COAs.

DHW 012511

# BUREAU OF LAND MANAGEMENT Carlsbad Field Office 620 East Greene Street Carlsbad, New Mexico 88220 575-234-5972

# Permanent Abandonment of Federal Wells Conditions of Approval

Failure to comply with the following Conditions of Approval may result in a Notice of Incidents of Noncompliance (INC) in accordance with 43 CFR 3163.1.

1. Plugging operations shall commence within <u>ninety (90)</u> days from the approval date of this Notice of Intent to Abandon.

If you are unable to plug the well by the 90<sup>th</sup> day provide this office, prior to the 90<sup>th</sup> day, with the reason for not meeting the deadline and a date when we can expect the well to be plugged. Failure to do so will result in enforcement action.

The rig used for the plugging procedure cannot be released and moved off without the prior approval of the authorized officer. Failure to do so may result in enforcement action.

- 2. <u>Notification:</u> Contact the appropriate BLM office at least 24 hours prior to the commencing of any plugging operations. For wells in Chaves and Roosevelt County, call 575-627-0272; Eddy County, call 575-361-2822; Lea County, call 575-393-3612.
- 3. <u>Blowout Preventers</u>: A blowout preventer (BOP), as appropriate, shall be installed before commencing any plugging operation. The BOP must be installed and maintained as per API and manufacturer recommendations. The minimum BOP requirement is a 2M system for a well not deeper than 9,090 feet; a 3M system for a well not deeper than 13,636 feet; and a 5M system for a well not deeper than 22,727 feet.
- 4. <u>Mud Requirement:</u> Mud shall be placed between all plugs. Minimum consistency of plugging mud shall be obtained by mixing at the rate of 25 sacks (50 pounds each) of gel per 100 barrels of **brine** water. Minimum nine (9) pounds per gallon.
- 5. <u>Cement Requirement</u>: Sufficient cement shall be used to bring any required plug to the specified depth and length. Any given cement volumes on the proposed plugging procedure are merely estimates and are not final. Unless specific approval is received, no plug except the surface plug shall be less than 25 sacks of cement. Any plug that requires a tag will have a minimum WOC time of 4 hours.

In lieu of a cement plug across perforations in a cased hole (not for any other plugs), a bridge plug set within 50 feet to 100 feet above the perforations shall be capped with 25 sacks of cement. If a bailer is used to cap this plug, 35 feet of cement shall be sufficient. Before pumping or bailing cement on top of CIBP, tag will be required to verify depth. Based on depth, a tag of the cement may be deemed necessary.

Unless otherwise specified in the approved procedure, the cement plug shall consist of either Neat Class "C", for up to 7,500 feet of depth or Neat Class "H", for deeper than 7,500 feet plugs.

6. Dry Hole Marker: All casing shall be cut-off at the base of the cellar or 3 feet below final restored ground level (whichever is deeper). The BLM is to be notified a minimum of 4 hours prior to the wellhead being cut off to verify that cement is to surface in the casing and all annuluses. Wellhead cut off shall commence within ten (10) calendar days of the well being plugged. If the cut off cannot be done by the 10<sup>th</sup> day, the BLM is to be contacted with justification to receive an extension for completing the cut off.

The well bore shall then be capped with a 4-inch pipe, 10-feet in length, 4 feet above ground and embedded in cement, unless otherwise noted in COA (requirements will be attached). The following information shall be permanently inscribed on the dry hole marker: well name and number, name of the operator, lease serial number, surveyed location (quarter-quarter section, section, township and range or other authorized survey designation acceptable to the authorized officer such as metes and bounds).

- 7. <u>Subsequent Plugging Reporting:</u> Within 30 days after plugging work is completed, file one original and three copies of the Subsequent Report of Abandonment, Form 3160-5 to BLM. The report should give in detail the manner in which the plugging work was carried out, the extent (by depths) of cement plugs placed, and the size and location (by depths) of casing left in the well. **Show date well was plugged.**
- 8. <u>Trash</u>: All trash, junk and other waste material shall be contained in trash cages or bins to prevent scattering and will be removed and deposited in an approved sanitary landfill. Burial on site is not permitted.

Following the submission and approval of the Subsequent Report of Abandonment, surface restoration will be required. See attached reclamation procedure.

DHW 122010



# United States Department of the Interior

**BUREAU OF LAND MANAGEMENT** 

Carlsbad Field Office 620 E. Greene St. Carlsbad, New Mexico 88220-6292 www.blm.gov/nm



In Reply Refer To: 1310

### **Reclamation Objectives and Procedures**

Reclamation Objective: Oil and gas development is one of many uses of the public lands and resources. While development may have a short- or long-term effect on the land, successful reclamation can ensure the effect is not permanent. During the life of the development, all disturbed areas not needed for active support of production operations should undergo "interim" reclamation in order to minimize the environmental impacts of development on other resources and uses. At final abandonment, well locations, production facilities, and access roads must undergo "final" reclamation so that the character and productivity of the land and water are restored.

The long-term objective of final reclamation is to set the course for eventual ecosystem restoration, including the restoration of the natural vegetation community, hydrology, and wildlife habitats. In most cases this means returning the land to a condition approximating or equal to that which existed prior to the disturbance. The final goal of reclamation is to restore the character of the land and water to its pre-disturbance condition. The operator is generally not responsible for achieving full ecological restoration of the site. Instead, the operator must achieve the short-term stability, visual, hydrological, and productivity objectives of the surface management agency and take steps necessary to ensure that long-term objectives will be reached through natural processes.

To achieve these objectives, remove any and all contaminants, scrap/trash, equipment, pipelines and powerlines. Strip and remove caliche, contour the location to blend with the surrounding landscape, re-distribute the native soils, provide erosion control as needed, rip and seed as specified in the original APD COA. This will apply to well pads, facilities, and access roads. Barricade access road at the starting point. If reserve pits have not reclaimed due to salts or other contaminants, submit a plan for approval, as to how you propose to provide adequate restoration of the pit area.

1. The Application for Permit to Drill or Reenter (APD, Form 3160-3), Surface Use Plan of Operations must include adequate measures for stabilization and reclamation of disturbed lands. Oil and Gas operators must plan for reclamation, both interim and final, up front in the APD process as per Onshore Oil and Gas Order No. 1.

- 2. For wells and/or access roads not having an approved plan, or an inadequate plan for surface reclamation (either interim or final reclamation), the operator must submit a proposal describing the procedures for reclamation. For interim reclamation, the appropriate time for submittal would be when filing the Well Completion or Recompletion Report and Log (Form 3160-4). For final reclamation, the appropriate time for submittal would be when filing the Notice of Intent, or the Subsequent Report of Abandonment, Sundry Notices and Reports on Wells (Form 3160-5). Interim reclamation is to be completed within 6 months of well completion, and final reclamation is to be completed within 6 months of well abandonment.
- 3. The operator must file a Subsequent Report Plug and Abandonment (Form 3160-5) following the plugging of a well.
- 4. Previous instruction had you waiting for a BLM specialist to inspect the location and provide you with reclamation requirements. If you have an approved Surface Use Plan of Operation and/or an approved Sundry Notice, you are free to proceed with reclamation as per approved APD. If you have issues or concerns, contact a BLM specialist to assist you. It would be in your interest to have a BLM specialist look at the location and access road prior to the removal of reclamation equipment to ensure that it meets BLM objectives. Upon conclusion submit a Form 3160-5, Subsequent Report of Reclamation. This will prompt a specialist to inspect the location to verify work was completed as per approved plans.
- 5. The approved Subsequent Report of Reclamation will be your notice that the native soils, contour and seedbed have been reestablished. If the BLM objectives have not been met the operator will be notified and corrective actions may be required.
- 6. It is the responsibility of the operator to monitor these locations and/or access roads until such time as the operator feels that the BLM objective has been met. If after two growing seasons the location and/or access roads are not showing the potential for successful revegetation, additional actions may be needed. When you feel the BLM objectives have been met submit a Final Abandonment Notice (FAN), Form 3160-5, stating that all reclamation requirements have been achieved and the location and/or access road is ready for a final abandonment inspection.
- 7. At this time the BLM specialist will inspect the location and/or access road. If the native soils and contour have been restored, and the revegetation is successful, the FAN will be approved, releasing the operator of any further liability of the location and/or access road. If the location and/or access road have not achieved the objective, you will be notified as to additional work needed or additional time being needed to achieve the objective.

If there are any questions, please feel free to contact any of the following specialists:

Jim Amos Supervisory Environmental Protection Specialist 575-234-5909, 575-361-2648 (Cell)

Terry Gregston Environmental Protection Specialist 575-234-5958

Bobby Ballard Environmental Protection Specialist 575-234-2230

Randy Rust Natural Resource Specialist 575-234-5943

Linda Denniston Environmental Protection Specialist 575-234-5974

Jennifer Van Curen Environmental Protection Specialist 575-234-5905

Justin Frye Environmental Protection Specialist 575-234-5922 Cody Layton Natural Resource Specialist 575-234-5959

Trishia Bad Bear Natural Resource Specialist 575-393-3612

Todd Suter Surface Protection Specialist 575-234-5987

Doug Hoag Civil Engineering Technician 575-234-5979

Tanner Nygren Natural Resource Specialist 575-234-5975

John Fast Natural Resource Specialist 575-2345996