

Attachment I.

- 9) GIH with overshot and catch top Model "D" packer. POOH with Model "D" and bottom Model "D" seal assembly.
- 10) GIH with packer picker and mill out bottom Model "D" at 8980'. POOH.
- 11) GIH with 7" packer on 2-7/8" workstring and set packer at + 8800'. Squeeze off Morrow perforations.
- 12) POOH and GIH with 6" bit on 4 - 4-3/4" drill collars on 2-7/8" workstring.
- 13) Drill out squeeze and test squeeze to 500 psig.
- 14) If squeeze holds, continue in hole and drill out to 10,430'. Circulate hole clean. POOH.
- 15) GIH with 7" packer on 2-7/8" workstring. Set packer at + 9500'. Perform injectivity test into open hole section of the Devonian formation. If necessary perform acid job on open-hole section.
- 16) Release packer. POOH.
- 17) GIH with 7" nickel plated packer on 2-3/8" internally coated tubing to 9800'. Displace backside with packer fluid. Set packer.
- 18) ND BOP's. NU wellhead.
- 19) RD pulling unit.
- 20) Connect surface injection system and begin injection.