

Instructions

General: This form is designed for submitting proposals to perform certain well operations, and reports of such operations when completed, as indicated, on Federal and Indian lands pursuant to applicable Federal law and regulations, and, if approved or accepted by any State, on all lands in such State, pursuant to applicable State law and regulations. Any necessary special instructions concerning the use of this form and the number of copies to be submitted, particularly with regard to local, area, or regional procedures and practices, either are shown below or will be issued by, or may be obtained from, the local Federal and/or State office.

Item 4: If there are no applicable State requirements, locations on Federal or Indian land should be described in accordance with Federal requirements. Consult local State or Federal office for specific instructions.

Item 17: Proposals to abandon a well and subsequent reports of abandonment should include such special information as is required by local Federal and/or State offices. In addition, such proposals and reports should include reasons for the abandonment; data on any former or present productive zones, or other zones with present significant fluid contents not sealed off by cement or otherwise; depths (top and bottom) and method of placement of cement plugs; mud or other material placed below, between and above plugs; amount, size, method of parting of any casing, liner or tubing pulled and the depth to top of any left in the hole; method of closing top of well; and date well was conditioned for final inspection looking to approval of the abandonment.

GPO : 1981 O - 347-166

6. RIH and tag plug @ 8005'. Circulated hole w/ mud laden fluid. Pulled tbg. to 5850' and spotted a 50 sack cement plug 5850-5750' across the top of the 3rd Bone Springs.
7. Pulled tbg. to 4750' and spotted a 50 sack cement plug 4750-4650' across the top of the 2nd Bone Springs.
8. Pulled tbg. to 4420' and spotted a 50 sack plug 4420-4320' across the top of the Bone Springs.
9. Pulled tbg. to 3165' and spotted a 75 sack cement plug 3165-3065' half above and half below 9-5/8" casing shoe @ 3115'. POOH.
10. RIH w/ tbg. to 3175. No plug. Circulated hole w/ mud laden fluid. Spotted a 50 sack cement plug @ 3165'. POOH.
11. WOC 18 hours. RIH w/ tbg. and tagged plug @ 3021'. Pulled tbg. to 1200'. Spotted a 50 sack cement plug 1200-1100'. POOH.
12. Cut 9-5/8" casing @ 582'. POOH. John Wade w/ MMS witnessed job.
13. RIH w/ tbg. to 632'. Loaded hole w/ mud laden fluid. Spotted a 75 sack cement plug 632-532' half in and half out of 9-5/8" casing stub @ 582'.
14. Pulled tbg. to 410' and spotted a 75 sack cement plug 410-310' half below and half above the 13-3/8" casing shoe @ 361'. POOH. MMS notified but did not witness job.
15. Set a 30 sack cement plug 50' to surface. CUT OFF WH AND Installed a dry hole marker to designate a plugged and abandoned location. Cleaned location.