

Oil Cons.  
N.M. Div. Dist. 2  
1301 W. Grand Avenue  
Alamogordo, NM 88210  
DEPARTMENT OF THE INTERIOR  
BUREAU OF LAND MANAGEMENT

Budget Bureau No. 1004-0135  
Expires August 31, 1985

5

SUNDRY NOTICES AND REPORTS ON WELLS

(Do not use this form for proposals to drill or to deepen or plug back to a different reservoir.  
Use "APPLICATION FOR PERMIT - " for such proposals.)

1. OIL WELL ☐ GAS WELL ☐ OTHER ☐ WIW

2. NAME OF OPERATOR  
The Wiser Oil Company

3. ADDRESS OF OPERATOR  
P.O. Box 2568 Hobbs, New Mexico 88241

4. LOCATION OF WELL (Report location clearly and in accordance with any State requirements.  
See also space 17 below.)  
At surface  
660' FNL & 1880' FEL  
Unit B

5. LEASE DESIGNATION AND SERIAL NO.  
LC-029419-A

6. IF INDIAN, ALLOTTEE OR TRIBE NAME

7. UNIT AGREEMENT NAME  
Skelly Unit

8. WELL NAME AND NO.  
42

9. API WELL NO.  
30-015-05356

10. FIELD AND POOL, OR WILDCAT  
Grayburg Jackson 7-Rivers-QN-GB-SA

11. SEC., T., R., M., OR BLK. AND  
SURVEY OR AREA  
Sec. 22-T17S-R31E

14. PERMIT NO

15. ELEVATIONS (Show whether DF, RT, GR, etc.)  
3875' DF

12. COUNTY OR PARISH  
Eddy County

13. STATE  
NM

16. Check Appropriate Box to indicate Nature of Notice, Report, or Other Data

NOTICE OF INTENTION TO:

TEST WATER SHUT OFF ☐ PULL OR ALTER CASING ☐  
FRACTURE TREAT ☐ MULTIPLE COMPLETE ☐  
SHOOT OR ACIDIZE ☐ ABANDON\* ☐  
REPAIR WELL ☐ CHANGE PLANS ☐

(Other) Plug and Abandon

SUBSEQUENT REPORT OF:

WATER SHUT-OFF ☐ REPAIRING WELL ☐  
FRACTURE TREATMENT ☐ ALTERING CASING ☐  
SHOOTING OR ACIDIZING ☐ ABANDONMENT \* ☐  
(Other) ☐

(Note: Report results of multiple completion on Well  
Completion or Recompletion Report and Log form.)

17. DESCRIBE PROPOSED OR COMPLETED OPERATIONS: (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work. If well is directionally drilled, give subsurface locations and measured and true vertical depths for all markers and zones pertinent to this work.)

Wiser requests approval to Plug and Abandon the well by the procedure listed below.

Surface Casing: 8-5/8" set @ 616'

Production Casing: 4-1/2" set @ 3764' 11.60#

Perfs: 3188'-3606' 2283'-2400' CIBP @ 2100' & 3106' with 40' cement on plug

- Spot 50' plug on CIBP @ 2100'.
- Tag cement plug.
- Circulate abandonment mud.
- Spot 50' cement plug @ 1600' to 1550'.
- Tag cement plug.
- Perforate casing @ 620' & circulate cement to surface. Leave a 50' plug @ 620' to 570'.
- Tag cement.
- Spot 50' cement plug to surface.
- Install dry hole marker.
- Clean location.

APPROVAL SUBJECT TO  
GENERAL REQUIREMENTS AND  
SPECIAL STIPULATIONS ATTACHED

18. I hereby certify that the foregoing is true and correct.

SIGNED Alexis C. Sandoval TYPE Prod. Supt. DATE April 1, 2003

(This space for Federal or State office use)

APPROVED BY (ORIG. SGD.) ALEXIS C. SANDOVAL  
CONDITIONS OF APPROVAL, IF ANY:

PETROLEUM ENGINEER

DATE

APR 08 2003

\*See Instruction On Reverse Side