Submit 1 Copy To Appropriate District State of New Mexico Form C-103 Office Energy, Minerals and Natural Resources Revised August 1, 2011 District I - (575) 393-6161 WELL API NO. 1625 N. French Dr., Hobbs, NM 88240 District II - (575) 748-1283 30-015-01843 OIL CONSERVATION DIVISION 811 S. First St., Artesia, NM 88210 5. Indicate Type of Lease District III - (505) 334-6178 1220 South St. Francis Dr. STATE 🖂 FEE 1000 Rio Brazos Rd., Aztec, NM 87410 Santa Fe, NM 87505 6. State Oil & Gas Lease No. District IV - (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM E1392-14 SUNDRY NOTICES AND REPORTS ON WELLS 7. Lease Name or Unit Agreement Name (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH **COWTOWN UNIT** PROPOSALS.) 8. Well Number 101 1. Type of Well: Oil Well Gas Well Other 9. OGRID Number 2. Name of Operator Alamo Permian Resources. LLC 274841 3. Address of Operator 10. Pool name or Wildcat 415 W. Wall Street, Suite 500, Midland, TX 79701 ARTESIA:OU-GB-SA 4. Well Location line and 1932 Unit Letter K: 1986 feet from the S feet from the W line 18**S** Section 13 Township Range 28E **NMPM EDDY** County 11. Elevation (Show whether DR, RKB, RT, GR, etc.) 12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data NOTICE OF INTENTION TO: SUBSEQUENT REPORT OF: PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WORK ALTERING CASING □ **TEMPORARILY ABANDON CHANGE PLANS** COMMENCE DRILLING OPNS.□ P AND A **PULL OR ALTER CASING** MULTIPLE COMPL П CASING/CEMENT JOB П DOWNHOLE COMMINGLE П OTHER: OTHER: RETURN TO PRODUCTION X 13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion. MIRU pulling unit. POOH with 114 3/4 "rods and pump. ND WH and NU BOP. Secure well and SDFN. 2-28-12 Open well up and picked up 4 joints of 2 3/8" tubing to tag bottom (no fill). POOH with tubing and TIH with bit and scraper to bottom. POOH with 20 joints. Secure well and SDFN. Open well up and POOH with tubing, laid down bit and scraper. Rig up tubing tester and test tubing in the hole. Hole was in 1st and 6th joint. ND BOP, set tubing anchor, and NU WH. TIH with rods and new pump, HWO, and check for pump action. Rig down PU and clean location. Spud Date: Rig Release Date: I hereby certify that the information above is true and complete to the best of my knowledge and belief. TITLE Regulatory Affairs Coordinator DATE 03/08/2012 CARIESTOKER E-mail address: cstoker@alamoresources.com PHONE: 432.897.0673 Type or print name

Conditions of Approval (if any):

APPROVED BY: