Form 3160-5 (April 2004)

3a. Address

1. Type of Well ☐ ☐ Oil Well ☐ ☐

2. Name of Operator OXY USA Inc.

TYPE OF SUBMISSION

P.O. Box 50250 Midland, TX 79710

4. Location of Well (Footage, Sec., T., R., M., or Survey Description) 715 FSL 657 FEL SESE(P)

643 FSL 2003 FEL SWSE(O)

OCD-ARTESIA **UNITED STATES** DEPARTMENT OF THE INTERIOR

BUREAU OF LAND MANAGEMENT

FORM APPROVED

SUNDRY NOTICES AND REPORTS ON WELLS

	OMBN	o. 1004-013 March 31,	7
-			

DEPARTMENT OF THE INTERIOR BUREAU OF LAND MANAGEMENT			OM B No. 1004-0137 Expires: March 31, 2007	
	NOTICES AND REF	5. Lease Serial No. NMNM62589		
Do not use this	s form for proposals t I. Use Form 3160 - 3 (/	6. If Indian, Allottee or Tribe Name		
JBMIT IN TRIP	PLICATE- Other instr	7. If Unit or CA/Agreement, Name and/or No.		
ll Oil Well 🗆 🗀	Gas Well□□ Other	8. Well Name and No. Federal 23 # 4		
rator OXY USA Inc.		3b. Phone No. (include area code) 432-685-5717	9. API Well No.	
			30015-37336	
50 Midland, TX 79710			10. Field and Pool, or Exploratory Area	
Vell (Footage, Sec., T.,	, R., M., or Survey Description)	Livingston Ridge Delaware		
- 657 FEC	SESE(P)	Sec 23 T22S R31E	11. County or Parish, State	
5L 2003 FE	EL SWSE(0)	Eddy, NM		
12. CHECK APP	PROPRIATE BOX(ES) TO	INDICATE NATURE OF NOTICE,	REPORT, OR OTHER DATA	
SUBMISSION	TYPE OF ACTION			
	[]			

Acidize Production (Start/Resume) Deepen Water Shut-Off Notice of Intent Alter Casing Well Integrity Fracture Treat Reclamation Recomplete Casing Repair New Construction Other ___Subsequent Report Change Plans Plug and Abandon Final Abandonment Notice Convert to Injection → Plug Back 13. Describe Proposed or Completed Operation (clearly state all pertinent details, including estimated starting date of any proposed work and approximate duration thereof.

If the proposal is to deepen directionally or recomplete horizontally, give subsurface locations and measured and true vertical depths of all pertunent markers and zones. Attach the Bond under which the work will be performed or provide the Bond No. on file with BLM/BIA. Required subsequent reports shall be filed within 30 days following completion of the involved operations. If the operation results in a multiple completion or recompletion in a new interval, a Form 3160-4 shall be filed once testing has been completed. Final Abandonment Notices shall be filed only after all requirements, including reclamation, have been completed, and the operator has determined that the site is ready for final inspection.)

Accepted for record NMOCD

See Attached

RECEIVED DEC 12 2011 NMOCD ARTESIA

14. I hereby certify that the foregoing is true and correct Name (Printed/Typed)	l Qgo				
David Stewart	Title Regulatory Advisor				
Signature Vu. Sty	Date 9/28/4-DFORM				
THIS SPACE FOR FEDERAL OR STATE OFFICE USE 1					
Approved by	Title Date A CRAMER				
Conditions of approval, if any, are attached. Approval of this notice does not warrant certify that the applicant holds legal or equitable title to those rights in the subject lewhich would entitle the applicant to conduct operations thereon.	nt or				
Title 18 U.S.C. Section 1001 and Title 43 U.S.C. Section 1212, make it a crime for any person knowingly and willfully to make to any department or agency of the United States any false, fictitious or fraudulent statements or representations as to any matter within its jurisdiction.					

(Instructions on page 2)

Federal 23 #4 API No. 30-015-37336

TD-8616'M 8424'V PBTD-8424'M 8205'V Perfs-8260-8282'

11-3/4" 42# @ 853' w/ 330sx, 14-3/4" hole, TOC-Surface-Circ 8-5/8" 32# @ 4248' w/ 1140sx, 10-5/8" hole, TOC-Surface-Circ 5-1/2" 17# @ 8616' DVT's @ 5992, 4347' w/ 1580sx, 7-7/8" hole, TOC-Surf-Circ

Procedure:

- 1. Clean location & set anchors
- 2. RU DDPU, POOH w/ rods and pump. NDWH, NU BOP.
- 3. POOH w/ tubing, ND BOP and NU Frac Valve, RD DDPU.
- 4. RU WL UNIT and RIH w/ Composite BP and set above existing perfs @ 8260-8282'.
- 5. Perforate 1 JSPF @ in 4 stages @ 8061-7756, 7624-7358, 7260-6950, 6838-6536' w/ 4" Titan SDP EXP 4039-321T 38.5 gram charge w/ .43" EHD and 55" penetration on 90 degree phasing. RD WLU.
- 6. Frac well down casing at first available date per Halliburton frac procedure.
- 7. RU WLU and set Composite BP between stages.
- 8. Shut well in overnight and RD Frac equipment and WLU.
- 9. MI RUPU, ND Frac valve, NU BOP.
- 10. PU tubing and RIH with bit and drill out Composite BP's to PBTD.
- 11. RIH w/ tbg & pkr, swab & flow well until sand cleans up.
- 12. POOH & RIH W/ production BHA as directed
- 13. Test well into battery

OXY USA Inc. Federal 23 #4 API No. 30-015-37336

