Submit 1 Copy To Appropriate District	State of New Mexico	Form C-103
Office District I - (575) 393-6161 Energy, N	Ainerals and Natural Resources	Revised August 1, 2011
1625 N. French Dr., Hobbs, NM 88240		WELL API NO.
District II - (575) 748-1283 OIL CO	NSERVATION DIVISION	30-015-21217
611 5. 1 list 5t., 7h testa, 1414 60210	20 South St. Francis Dr.	5. Indicate Type of Lease
1000 Rio Brazos Rd., Aztec, NM 87410		STATE FEE
<u>District + (500) 170 5 100</u>	Santa Fe, NM 87505	6. State Oil & Gas Lease No.
1220 S. St. Francis Dr., Santa Fe, NM 87505		
SUNDRY NOTICES AND REP	ORTS ON WELLS	7. Lease Name or Unit Agreement Name
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL O		Jackson AT
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERI PROPOSALS.)	MIT" (FORM C-101) FOR SUCH	8. Well Number
1. Type of Well: Oil Well Gas Well	Other	5
2. Name of Operator		9. OGRID Number
Yates Petroleum Corporation		025575
3. Address of Operator		10. Pool name or Wildcat
105 South Fourth Street, Artesia, NM 88210		Eagle Creek; San Andres
4. Well Location		
Unit Letter M : 990 feet fro	m the South line and	330 feet from the West line
Section 13 Townsh	nip 17S Range 25E	NMPM Eddy County
	(Show whether DR, RKB, RT, GR, etc.,	
The Devation	3464'GR	
12 Check Appropriate R	ox to Indicate Nature of Notice,	Report or Other Data
12. Check Appropriate B	ox to maleate reactive of reduce,	Report of Other Data
NOTICE OF INTENTION T	O: SUB	SEQUENT REPORT OF:
PERFORM REMEDIAL WORK PLUG AND A		
TEMPORARILY ABANDON CHANGE PLA	NS COMMENCE DRI	LLING OPNS. ☐ P AND A ☐
PULL OR ALTER CASING MULTIPLE CO	DMPL ☐ CASING/CEMENT	T JOB 🔲
DOWNHOLE COMMINGLE		
		_
OTHER:	OTHER:	
13. Describe proposed or completed operations	(Clearly state all pertinent details, and	
13. Describe proposed or completed operations of starting any proposed work). SEE RULI	(Clearly state all pertinent details, and	
13. Describe proposed or completed operations	(Clearly state all pertinent details, and	
13. Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion.	(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Cor	
13. Describe proposed or completed operations of starting any proposed work). SEE RULI	(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Cor	
13. Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion.	(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Cordon this well as follows:	
Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban	(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Cordon this well as follows: TOH with production equipment.	mpletions: Attach wellbore diagram of
 Describe proposed or completed operations of starting any proposed work). SEE RULH proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban MIRU any safety equipment as needed. NU BOI RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 	don this well as follows: TOH with production equipment. TOH with production equipment. CIBP above perfs at 1230' before circ	mpletions: Attach wellbore diagram of 500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx).
 Describe proposed or completed operations of starting any proposed work). SEE RULH proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban MIRU any safety equipment as needed. NU BOI RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be 	don this well as follows: TOH with production equipment. O' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate at surface. If seehind all casing strings at surface.	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then
 Describe proposed or completed operations of starting any proposed work). SEE RULL proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban MIRU any safety equipment as needed. NU BOI RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 	don this well as follows: TOH with production equipment. O' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate at surface. If seehind all casing strings at surface.	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then
 Describe proposed or completed operations of starting any proposed work). SEE RULH proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban MIRU any safety equipment as needed. NU BOI RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be 	don this well as follows: TOH with production equipment. O' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate at surface. If seehind all casing strings at surface.	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing.
 Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban MIRU any safety equipment as needed. NU BOI RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each Install dry hole marker and clean location. 	don this well as follows: TOH with production equipment. TOH with production equipment. CIBP above perfs at 1230' before circle thind all casing strings at surface. If so casing string before cementing to surface.	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing.
 Describe proposed or completed operations of starting any proposed work). SEE RULL proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban MIRU any safety equipment as needed. NU BOI RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 	don this well as follows: TOH with production equipment. O' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulating strings at surface. If so casing string before cementing to surface.	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing.
 Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban MIRU any safety equipment as needed. NU BOI RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each Install dry hole marker and clean location. Wellbore schematics attached 	don this well as follows: TOH with production equipment. Tollow perfs at 1230' before circle ehind all casing strings at surface. If so casing string before cementing to surface.	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing.
 Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban MIRU any safety equipment as needed. NU BOI RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each Install dry hole marker and clean location. 	don this well as follows: TOH with production equipment. Tollow perfs at 1230' before circle ehind all casing strings at surface. If so casing string before cementing to surface.	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing.
 Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban MIRU any safety equipment as needed. NU BOI RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each Install dry hole marker and clean location. Wellbore schematics attached 	don this well as follows: TOH with production equipment. Tollow perfs at 1230' before circle ehind all casing strings at surface. If so casing string before cementing to surface.	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing.
13. Describe proposed or completed operations of starting any proposed work). SEE RULH proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOI 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel	don this well as follows: TOH with production equipment. TOH with production equipment to a CIBP above perfs at 1230' before circle ehind all casing strings at surface. If so a casing string before cementing to surface surface with the casing string before cementing to surface is complete and no earth pits	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing.
 Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban MIRU any safety equipment as needed. NU BOI RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each Install dry hole marker and clean location. Wellbore schematics attached 	don this well as follows: TOH with production equipment. Tollow perfs at 1230' before circle ehind all casing strings at surface. If so casing string before cementing to surface.	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing.
13. Describe proposed or completed operations of starting any proposed work). SEE RULH proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOI 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel	don this well as follows: TOH with production equipment. TOH with production equipment to a CIBP above perfs at 1230' before circle ehind all casing strings at surface. If so a casing string before cementing to surface surface with the casing string before cementing to surface is complete and no earth pits	mpletions: Attach wellbore diagram of 500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing.
13. Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOI 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel Spud Date:	(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Cordon this well as follows: TOH with production equipment. 50' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate all casing strings at surface. If so casing string before cementing to surface pits and no earth pits Rig Release Date:	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing. al Granted providing work plete by June 10 - 2013
13. Describe proposed or completed operations of starting any proposed work). SEE RULH proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOI 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel	(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Cordon this well as follows: TOH with production equipment. 50' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate all casing strings at surface. If so casing string before cementing to surface pits and no earth pits Rig Release Date:	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing. al Granted providing work plete by June 10 - 2013
13. Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOI 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel Spud Date:	(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Cordon this well as follows: TOH with production equipment. 50' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate all casing strings at surface. If so casing string before cementing to surface pits and no earth pits Rig Release Date:	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing. al Granted providing work plete by June 10 - 2013
13. Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOI 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel Spud Date:	(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Condon this well as follows: TOH with production equipment. 50' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate and all casing strings at surface. If so a casing string before cementing to surface and no earth pits Rig Release Date:	mpletions: Attach wellbore diagram of 500° with 115 sx. Note: If fill is tagged and culating cement to 500° (90 sx). o, cement to surface with 60 sx. If not then face inside production casing. The surface work plete by Town 105-2013 The surface with 60 sx. If not then face inside providing work plete by Town 105-2013 The surface with 60 sx. If not then face inside providing work plete by Town 105-2013 The surface with 60 sx. If not then face inside providing work plete by Town 105-2013 The surface with 60 sx. If not then face inside providing work plete by Town 105-2013 The surface with 60 sx. If not then face inside providing work plete by Town 105-2013
13. Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOI 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel Spud Date:	(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Condon this well as follows: TOH with production equipment. 50' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate and all casing strings at surface. If so a casing string before cementing to surface and no earth pits Rig Release Date:	500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing. al Granted providing work plete by June 10 - 2013
13. Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOH 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel Spud Date:	C(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Cord don this well as follows: TOH with production equipment. O' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate all casing strings at surface. If so casing string before cementing to surfaces and no earth pits Rig Release Date: Complete to the best of my knowledged Complete to the best of my	mpletions: Attach wellbore diagram of 500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing. Fall Granted providing work plete by June 15-2013 e and belief.
13. Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOI 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel Spud Date:	(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Condon this well as follows: TOH with production equipment. 50' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate and all casing strings at surface. If so a casing string before cementing to surface and no earth pits Rig Release Date:	mpletions: Attach wellbore diagram of 500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing. Fall Granted providing work plete by June 15-2013 e and belief. The providing work plete by June 15-2013 E and belief. The providing work plete by June 15-2013 The pr
13. Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOH 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel Spud Date: I hereby certify that the information above is true and SIGNATURE Type or print name Tina Huerta	Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Cordon this well as follows: TOH with production equipment. 50' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate and all casing strings at surface. If so casing string before cementing to surface in casing string before cementing to surface is complete to the best of my knowledged and complete to the best of my knowledged. TITLE Regulatory Reporting String address: tinah@yatespetroleur	mpletions: Attach wellbore diagram of 500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing. Fall Granted providing work plete by June 15-2013 e and belief.
13. Describe proposed or completed operations of starting any proposed work). SEE RULI proposed completion or recompletion. Yates Petroleum Corporation plans to plug and aban 1. MIRU any safety equipment as needed. NU BOH 2. RIH with bit and scraper to just below perfs at 14 you are unable to get below perfs then TOH and set 3. Cut off wellhead and verify that there is cement be perforate and circulate cement to surface behind each 4. Install dry hole marker and clean location. Wellbore schematics attached NOTE: Yates Petroleum Corporation will use steel Spud Date: I hereby certify that the information above is true and SIGNATURE Type or print name Tina Huerta	C(Clearly state all pertinent details, and 19.15.7.14 NMAC. For Multiple Cord don this well as follows: TOH with production equipment. O' and circulate Class "C" cement to a CIBP above perfs at 1230' before circulate all casing strings at surface. If so casing string before cementing to surfaces and no earth pits Rig Release Date: Complete to the best of my knowledged Complete to the best of my	mpletions: Attach wellbore diagram of 500' with 115 sx. Note: If fill is tagged and culating cement to 500' (90 sx). o, cement to surface with 60 sx. If not then face inside production casing. Fall Granted providing work plete by June 15-2013 e and belief.


Well Name: <u>Jackson AT #5</u> Field: <u>Eagle Creek</u> Location: 990' FSL & 330' FWL Sec 13-17S-25E

County: Eddy State: New Mexico GL: <u>3,464</u> Zero: KB:

Spud Date: <u>5/22/1974</u> Completion Date: <u>6/7/1974</u>

Comments: API # 30015212170000

Casing Program		
Size/Wt/Grade	Depth Set	
10 ¾" 32# K-55	289'	
7" 23# K-55	1,171'	
4½" 9.5# & 5½" 15.5# K-55	1,483*	



cmtd w/ 400 sx.

San Andres perfs 1,300-1,440' (33)

 $4\,\%$ % 5 % " csg @ 1,483' cmtd w/ 125 sx.

TD 1,483"

DATE: 1/9/2013


Well Name: <u>Jackson AT #5</u> Field: <u>Eagle Creek</u> Location: 990' FSL & 330' FWL Sec 13-17S-25E

County: Eddy State: New Mexico
GL: 3,464' Zero: KB:

Spud Date: <u>5/22/1974</u> Completion Date: <u>6/7/1974</u>

Comments: API # 30015212170000

Casing Program	
Size/WVGrade	Depth Set
10 ¾" 32# K-55	289'
7" 23# K-55	1,171'
4 ½" 9.5# & 5 ½" 15.5# K-55	1,483'
<u> </u>	



7" csg @ 1,171' cmtd w/ 400 sx.

6 1/4" hole

San Andres perfs 1,300-1,440' (33)

4 ½" & 5 ½" csg @ 1,483' cmtd w/ 125 sx.

TD 1,483'

DATE: 1/9/2013

NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

CONDITIONS OF APPROVAL FOR PLUGGING & ABANDONMENT

Operator: Vates Actroleum Corp.

Well Name & Number: Jackson AT #5

API #: 30-015-21217

- 1. Produced water <u>will not</u> be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- 3. Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- 6. If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.
- 8. Cement Retainers may not be used.

- 9. Squeeze pressures are not to exceed 500 PSI, unless approval is given by NMOCD.
- 10. Plugs may be combined after consulting with and getting approval from NMOCD.
- 11. Minimum WOC time for tag plugs will be 4 Hrs.

DATE: May 07-2013

APPROVED BY: Spale

GUIDELINES FOR PLUGGING AND ABANDONMENT

DISTRICT II / ARTESIA

- All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater.
- Mud laden fluids must be placed between all cement plugs.
- Mud laden fluids must be mixed at 25 sacks of gel per 100 bbls of water.
- A cement plug is required to be set 50' below and 50' above all casing shoes and casing stub plugs. These plugs must be tagged.
- A CIBP with 35' of cement on top may be set in lieu of 100' cement plug.
- A plug as indicated above must be placed within 100' of top perforation. This plug must be tagged.
- Plugs set below and above salt zones must be tagged.
- No more than 2000' is to be allowed between cement plugs in open hole and no more than 3000' in cased hole.
- DV tools are required to have a 100' cement plug set 50' above and below the tool and must be tagged.
- Formations to be isolated with plugs placed at the top of each formation are:
 - o Fusselman
 - o Devonian
 - o Morrow
 - o Wolfcamp
 - o Bone Spring
 - o Delaware
 - Any Salt Section (Plug at top and bottom)
 - o Abo
 - o Glorieta
 - Yates (this plus is usually at base of salt section)
- If cement does not exist behind casing strings at recommended formation depths, the casing must be cut and pulled with plugs set at these depths or casing must be perforated and cement squeezed behind casing at the formation depths.
- In the R-111-P area (Potash Mine area) a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts common to the section penetrated and in suitable proportions, but not more than a 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible (50' below and 50' above).