Submit 1 Copy To Appropriate District Office To State of New Mexico Energy, Minerals and Natural Resources	Form C-103 Revised July 18, 2013
1625 N. French Dr., Hobbs, NM 88240	WELL API NO.
District II – (575) 748-1283 811 S. First St., Artesia, NM 88210 OIL CONSERVATION DIVISION	30-015-23566 5. Indicate Type of Lease
District III - (505) 334-6178         1220 South St. Francis Dr.           1000 Rio Brazos Rd., Aztec, NM 87410         5	STATE FEE
<u>District IV</u> – (505) 476-3460 I220 S. St. Francis Dr., Santa Fe, NM	6. State Oil & Gas Lease No. LG-827
87505 SUNDRY NOTICES AND REPORTS ON WELLS (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH	7. Lease Name or Unit Agreement Name Arnold OR State
PROPOSALS.) 1. Type of Well: Oil Well Gas Well Other P&A	8. Well Number
2. Name of Operator	9. OGRID Number
Yates Petroleum Corporation	025575
<ol> <li>Address of Operator</li> <li>South Fourth Street, Artesia, NM 88210</li> </ol>	10. Pool name or Wildcat Wildcat; Abo
4. Well Location Unit Letter O : 660 feet from the South line and	1980 feet from the <u>East</u> line
Section 34 Township 18S Range 24E NMPM Eddy County	
11. Elevation (Show whether DR, RKB, RT, GR, etc.)	
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data	
PERFORM REMEDIAL WORK 🔲 PLUG AND ABANDON 🛛 REMEDIAL WORK 🗌 ALTERING CASING 🗌	
PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT JOB	
CLOSED-LOOP SYSTEMENT S Second and the second se	
<ol> <li>Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.</li> </ol>	
Yates Petroleum Corporation plans to Plug and Abandon this well as follows:	
1. NU BOP. RU all H2S and safety equipment as needed. No casing recovery will be attempted. POOH with tubing and packer if	
any exist. 2. Set a CIBP at 4,884' and spot a 25 sx plug on top from 4,644' to 4,884', this will place a plug over the open Abo perforations.	
3. Load the hole with plugging mud. Spot a 160' plug from 5,024'-5,184' across the Wolfcamp top.	
4. Perforate 4 squeeze holes at 3,880'. TIH to establish an injection rate. Spot a 40 sx plug 150' plug inside and outside of the casing from 3,730' to 3,880'. WOC and tag plug, re-set if necessary. This will leave a plug across the Abo top.	
Approved for plugging of well hore only.	
Liability under bond is retained pending receipt of C-103 (Subsequent Report of Well Plugging)	
which may be found at OCD Web Page under <u>CONTINU</u>	ED ON NEXT PAGE:
Forms, www.cmnrd.state.nm.us/ocd. CONDITIONS OF APPROVAL ATTACHED	RECEIVED
Spud Date: Approval Granted providing work is Completed by A	APR 2.9,2014
April 29, 2015	NMOCD ARTESIA
I hereby certify that the information above is true and complete to the best of my knowledge and belief.	
SIGNATURE fune Watter TITLE Regulatory Reporting Technician DATE April 28, 2014	
Type or print name Laura Watts E-mail address: laura@yatespetroleum.com PHONE: 575-748-4272 For State Use Only 2000 A	
APPROVED BY: ADde TITLE DIST FORWISS DATE 4/29/2014	
Conditions of Approval (if any): See Attached OA's	

Arnold OR State #1 Sec 34-T18S-R24E Eddy County, New Mexico Page 2


î ;


## Form C-103 Continued:

- 5. Perforate 4 squeeze holes at 1,904'. TIH to establish an injection rate. Spot a 40 sx 150' plug inside and outside of the casing from 1,754' to 1,904'. This will leave a plug across the Glorieta top. WOC and tag plug, re-set if necessary.
- 6. Perforate 4 squeeze holes at 1,038'. TIH to establish an injection rate. Spot a 40 sx 150' plug inside and outside of the casing from 888' to 1,038'. This will leave a plug across the intermediate casing shoe. WOC and tag plug, re-set if necessary.
- 7. Perforate 4 squeeze holes at 488'. TIH to establish an injection rate. Spot a 130 sx 488' plug inside and outside of the casing from 0' to 488'. This will leave a plug across the surface casing shoe. WOC and tag plug, re-set if necessary.
- 8. Remove all surface equipment and weld dry hole marker per regulations.

Schematics attached

Regulatory Reporting Technician April 28, 2014





## NEW MEXICO OIL CONSERVATION DIVISION DISTRICT 2 OFFICE 811 S. FIRST STREET ARTESIA, NM 88210 (575)748-1283

<b>CONDITIONS OF APPROVAL FOR PLUGGING &amp; ABANDONMENT</b>
Operator: Kates Actrokum
Operator: Jates Actrokum Well Name & Number: ARNOLD OR State #1
API #: 30-015-23566

- 1. Produced water <u>will not</u> be used during any part of the plugging & abandonment operation.
- 2. Notify NMOCD Dist. 2 office at least 24 hrs before beginning work.
- 3. Closed Loop System is to be used for entire plugging operation. Upon completion, contents of steel pit are to be hauled to a permitted disposal location.
- 4. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator, as well as the contractor, to verify that this permit is place prior to performing work. Drivers shall produce a copy upon request of NMOCD Field Inspectors.
- 5. A subsequent C-103 will serve as notification that the well bore has been plugged ONLY. A C-103 FINAL shall be filed before any bonding can be released on the well. Upon receipt of the Final, an inspection will be performed to verify that the location has been satisfactorily cleaned to NMOCD standards.
- 6. If work has not begun within 90 days of the approval of this procedure, an extension request must be filed, stating reason that well has not been plugged.
- 7. Every attempt must be made to clean the well bore out to below the perfs, before any plugs can be set, by whatever means possible.
- 8. Cement Retainers may not be used.

9. Squeeze pressures are not to exceed 500 PSI, unless approval is given by NMOCD.
10. Plugs may be combined after consulting with and getting approval from NMOCD.
11. Minimum WOC time for tag plugs will be 4 Hrs.

DATE: 4-29-2014

APPROVED BY: A Stele

## **GUIDELINES FOR PLUGGING AND ABANDONMENT**

## DISTRICT II / ARTESIA

- All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater.
- Mud laden fluids must be placed between all cement plugs.
- Mud laden fluids must be mixed at 25 sacks of gel per 100 bbls of water.
- A cement plug is required to be set 50' below and 50' above all casing shoes and casing stub plugs. These plugs must be tagged.
- A CIBP with 35' of cement on top may be set in lieu of 100' cement plug.
- A plug as indicated above must be placed within 100' of top perforation. This plug must be tagged.
- Plugs set below and above salt zones must be tagged.
- No more than 2000' is to be allowed between cement plugs in open hole and no more than 3000' in cased hole.
- DV tools are required to have a 100' cement plug set 50' above and below the tool and must be tagged.
- Formations to be isolated with plugs placed at the top of each formation are:
  - o Fusselman
  - o Devonian
  - o Morrow
  - o Wolfcamp
  - o Bone Spring
  - o Delaware
  - Any Salt Section (Plug at top and bottom)
  - o Abo
  - o Glorieta
  - Yates (this plus is usually at base of salt section)
- If cement does not exist behind casing strings at recommended formation depths, the casing must be cut and pulled with plugs set at these depths or casing must be perforated and cement squeezed behind casing at the formation depths.
- In the R-111-P area (Potash Mine area) a solid cement plug must be set across the salt section.
   Fluid used to mix the cement shall be saturated with the salts common to the section penetrated and in suitable proportions, but not more than a 3% calcium chloride by weight of cement will be considered the desired mixture whenever possible (50' below and 50' above).