

Submit 3 Copies To Appropriate District
Office
District I
1625 N. French Dr., Hobbs, NM 88240
District II
811 South First, Artesia, NM 88210
District III
1000 Rio Brazos Rd., Aztec, NM 87410
District IV
1220 S. St. Francis Dr., Santa Fe, NM
87505

State of New Mexico
Energy, Minerals and Natural Resources

OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised March 25, 1999

WELL API NO.
30-005-00333

5. Indicate Type of Lease
STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
VA-1411

7. Lease Name or Unit Agreement Name:
Caleb AVE State

8. Well No.
1

9. Pool name or Wildcat
Wildcat Mississippian

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A
DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH
PROPOSALS.)

1. Type of Well:

Oil Well ☐ Gas Well ☒ Other ☐

2. Name of Operator

Yates Petroleum Corporation

3. Address of Operator

105 S. 4th Street Artesia, NM 88210

4. Well Location

Unit Letter : 660 feet from the South line and 1980 feet from the East line

Section 10 Township 12S Range 27E NMPM Chaves County

10. Elevation (Show whether DR, RKB, RT, GR, etc.)

3672'GR

11. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐

PLUG AND ABANDON ☒

TEMPORARILY ABANDON ☐

CHANGE PLANS ☐

PULL OR ALTER CASING ☐

MULTIPLE
COMPLETION ☐

OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐

ALTERING
CASING ☐

COMMENCE DRILLING OPNS. ☐

PLUG AND
ABANDONMENT ☐

CASING TEST AND
CEMENT JOB ☐

OTHER: ☐

Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 1103. For Multiple Completions: Attach wellbore diagram of proposed completion or recompilation. ** Perf CSS @ 1750' - Place 100' of cmt inside; outside CSS 1650-1750 - 7A9*
** Perf CSS @ 307' Place 100' of cmt inside; outside CSS 207-307 - 7A5*

Yates Petroleum Corporation plans to plug and abandon this well as follows:

1. Notify the NMOCD at least 24 hrs before starting the plugging work. Release the packer at 5724' and release the RBP at 6150'.
2. Dump 35' of cement on top of the CIBP at 6350'. Set 4-1/2" CIBP at 5750'. Circulate the hole with 10.0 ppg mud with 25#/bbl of gel in the mud then spot 25 sx cement on top of the CIBP. ** 25 sx plug @ 4822'*
3. Shoot 4 holes at 2550' and squeeze 50 sx cement behind the casing to cover the Gloria. *2450-2550* Shoot 4 holes at *2075-2025* and squeeze 50 sx cement behind the casing to cover the base of the 9-5/8" casing. Shoot 4 holes at 100' then screw in a casing swage and squeeze 50 sx cement behind the casing to the surface. Spot 5 sx cement at the surface to fill up the casing if necessary. *-woc 24 HRS - leave 100' of cmt in CSS. 1975-2075 - 7A*
4. Remove the wellhead and install a dry-hole marker and clean up the location.

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina L. Puerta TITLE Regulatory Compliance Supervisor DATE June 13, 2003

Type or print name Tina L. Puerta

Telephone No. 505-748-1471

(This space for State use)

APPROVED BY [Signature] TITLE Field Rep ID DATE 6-24-03

Conditions of approval, if any: