
Submit 1 Copy To Appropriate District	State of New Mexico		Form C-103	
<u>Digrict l'= (575)</u> 393-6161	Energy, Minerals and Natural Resources OIL CONSERVATION DIVISION		Revised July 18, 2013 WELL API NO.	
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283			30-015-21688	
811 S. First St., Artesia, NM 88210 <u>District III</u> – (505) 334-6178	1220 South St. Fran		5. Indicate Type of Le	
1000 Rio Brazos Rd., Aztec, NM 87410	Santa Fe, NM 87505		STATE 6. State Oil & Gas Le	FEE 🗵
<u>District IV</u> – (505) 476-3460 1220 S. St. Francis Dr., Santa Fe, NM	Sultu I vy I III V	303	6. State Off & Gas Lea	ase No.
87505 SUNDRY NOT	7. Lease Name or Unit Agreement Name			
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH		Dayton EY		
PROPOSALS.)			8. Well Number	
1. Type of Well: Oil Well Gas Well Other 2. Name of Operator			9. OGRID Number	
Yates Petroleum Corporation			025575	
3. Address of Operator			10. Pool name or Wildcat	
105 South Fourth Street, Artesia, NM 88210 Atoka; San Andres				
4. Well Location Unit Letter P:	990 feet from the South	line and	990 feet from the	East line
Section 21	Township 18S Rai		NMPM Eddy	County
	11. Elevation (Show whether DR,	RKB, RT, GR, etc.)		
3370°GR				
12 Check	Appropriate Box to Indicate N	ature of Notice	Report or Other Dat	а
12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data				
NOTICE OF INTENTION TO: SUBSEQ PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WORK			SEQUENT REPO	RT OF: ERING CASING []
TEMPORARILY ABANDON CHANGE PLANS COMMENCE DRILLING OPNS. P AND A				
PULL OR ALTER CASING MULTIPLE COMPL CASING/CEMENT JOB				
DOWNHOLE COMMINGLE CLOSED-LOOP SYSTEM	:			•
CLOSED-LOOP SYSTEM OTHER:		OTHER:		
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date				
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.				
Yates Petroleum Corporation plans to plug and abandon this well as follows:				
1. MIRU all safety equipment as needed. TOH with production equipment.				
 MiRU all safety equipment as needed. TOH with production equipment. Set a 4-1/2" CIBP at 1524' and cap it with 50 sx cement. TOC should be at +/-900' woe > TML Spot a 100 sx Class "C" cement plug from 0-900'. WOC and tag, reset if necessary. Cut off wellhead install dry hole marker and class leastion. 				
4. Cut off wellhead, install dry hole	marker and clean location			DISTRICT
Libility under bend is retained pending receipt				
Wellbore schematics attached of C-103 (Subsequent Report of Well Plugging) which may be found at OCD Web Page under				
	Forms, www.cm	inrd.state.nm.us/ocd.	L L	EIVED
	,, .		1656	
Spud Date:	Rig Release Da	ļ.		
WELL MUST BE 1	PLUBBED BY 6/9	12017	•	
I hereby certify that the information above is true and complete to the best of my knowledge and belief.				
SIGNATURE TITLE Regulatory Reporting Supervisor DATE June 7, 2016				
Type or print name Tina Huerta E-mail address: tinah@yatespetroleum.com PHONE: 575-748-4168				
Type or print name E-mail address: tinah@yatespetroleum.com PHONE:575-748-4168 For State Use Only				
APPROVED BY: Jahr 2 Le TITLE COMPLIANCE OFFICER DATE 6/9/2016 Conditions of Approval (if any):				
THE CEG ATTACHED POLA'S				

WELL NAME: Dayton EY # 1 FIELD: Dayton LOCATION: 990' FSL & 990' FEL of Section 21-18S-26E Eddy Co., NM GL: 3,370' ZERO: 9' KB: 3,379' **CASING PROGRAM** SPUD DATE: 12/18/75 __COMPLETION DATE: __1/20/76_ COMMENTS: API No.: 30-015-21688 10-3/4" 32# 426' 7" 23# LT&C 1,213' 5-1/2" 14 # J-55 970' 15" Hole 4-1/2" 9.5# J-55 726 1,698' Bottom **Before** 10-3/4" @ 426" w/ 200 sx 9-1/2" Hole **TOPS** SA 898 7" @ 1,213' 5-1/2" X 4-1/2" XO w/ 500 sx At 972' +3 yards Redi-mix 6-1/8° Hole ← San Andres Perfs: 1,574'-1,667' (32) 5-1/2" x 4-1/2" @ 1,698' Not to Scale W 175 sx (Circ.) 05/4/16 PB: 1,697' **JMH** TD: 1,720



and the second

CONDITIONS FOR PLUGGING AND ABANDONMENT

DISTRICT II / ARTESIA

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases

- 1. Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 7. Produced water will not be used during any part of the plugging operation.
- 8. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 9. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 10. Class 'C' cement will be used above 7500 feet.
- 11. Class 'H' cement will be used below 7500 feet.
- 12. A cement plug is required to be set 50' above and 50' below, all casing shoes, casing stubs, DV tools, attempted casing cut offs, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 13. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 14. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 15. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 16. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 17. Formations to be isolated with cement plugs are:
 - A) Fusselman
 - B) Devonian
 - C) Morrow

- D) Wolfcamp
- E) Bone Springs
- F) Delaware
- G) Any salt sections
- H) Abo
- I) Glorieta
- J) Yates.
- K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 18. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, cement will be set 50' below to 50' above perforation inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

- 1. Operator name
- 2. Lease and well number
- 3. API number
- 4. Unit letter
- 5. Quarter section (feet from North, South, East or West)
- 6.Section, Township and Range
- 7. Plugging date
- 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude be GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)