Submit 1 Copy To Appropriate District Office		New Me			Form C-103
District I - (575) 393-6161	Energy, Minerals	and Natu	ral Resources	WITH ANIAGO	evised July 18, 2013
1625 N. French Dr., Hobbs, NM 88240 <u>District II</u> – (575) 748-1283				$\frac{\text{WEEL ATTO.}}{30-0}$)15-36216
OIL CONSERVATION DIVISION District III – (505) 334-6178 OIL CONSERVATION DIVISION 1220 South St. Francis Dr.			5. Indicate Type of Lease		
1000 Rio Brazos Rd., Aztec, NM 87410				FEE	
1220 S. St. Francis Dr., Santa Fe, NM				6. State Oil & Gas Lease 30327	
87505 SUNDRY NOTICES AND REPORTS ON WELLS				7. Lease Name or Unit A	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)				PINNACLE	·
1. Type of Well: Oil Well Gas Well Other				8. Well Number	022
2. Name of Operator RKI EXPLORATION & PRODUCTION, LLC				9. OGRID Number	246289
3. Address of Operator _{3500 ONE} WILLIAMS CENTER MD 35 TULSA, OK 74172				10. Pool name or Wildcat HERRADURA BEND;DELAWARE, EAST	
4. Well Location Unit Letter D	995 feet from the	NOR	TH line and	1086 feet from the	WEST line
Section 36			inge 28E	NMPM EDDY Count	у
	11. Elevation (Show wh	hether DR, 3,125'			
		0,120			
12. Check	Appropriate Box to In	idicate N	ature of Notice,	Report or Other Data	
NOTICE OF I	NTENTION TO:		SUB	SEQUENT REPORT	OF:
PERFORM REMEDIAL WORK PLUG AND ABANDON REMEDIAL WOR				=	ING CASING
TEMPORARILY ABANDON					A LI
DOWNHOLE COMMINGLE		U !	OAGING/OEMEN		
CLOSED-LOOP SYSTEM	I		071150		
OTHER: 13. Describe proposed or com	pleted operations (Clearly	v state all r	OTHER:	l give pertinent dates, inclu	ding estimated date
	ork). SEE RULE 19.15.7.			npletions: Attach wellbore	
RKI EXPLORATION & PRO	-	QUESTS	S APPROVAL	TO PLUG AND ABAI	NDON THIS
WELL.					
WBD'S AND PLAN ARE AT	TACHED.		oly. cipt	NM OIL CONSERVA	TION
	.,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,		Well bore onding receding	•	
		Fringer dia to	well bore only. well bore only. stained pending receipt stained pending receip	AUG 2 5 2017	
	Approved to	ider hondent R	OCD Web		
	Liability 103	in he found a	ate.nm.u.	RECEIVED	
	or which ma	WWW.CELLIL			
	Forme		COCD Web Page.		
Spud Date: 06/02/2	2008 Rig F	Release Da	te: 07/	10/2008	
WELL MUST BE	PLUBALD BY	1 81.	28/2018		
I hereby certify that the information		te to the be	est of my knowledge	and belief.	
1 - 0	11 -	D			10410047
SIGNATURE WITH ON			nit Technicia		/21/2017
Type or print name Caitlin O' For State Use Only	Hair E-ma	ail address	caitlin.o'hair@wr	PHONE:	539-573-3527
APPROVED BY: Malet 2	Burel TITI	e (BM)	DIANCE OFF	FIEER DATE 8	128/2017
Conditions of Approval (if any):		_	·····		
SEE AT	THEHED COA	1-5			

Proposed Plugged WB

KB: 3137' GL: 3125' Pinnacle State #22
Proposed WBD

Les Peeler 08-18-17 30-015-36216

Sct 36, 22S -28E Eddy Co., New Mexico Herradura Bend; Delaware Field Grid # 246289

Spud: 06/02/08 Completed: 07/10/08

Perf @ 150' & sqz. 70 sxs. to surface

Perf @ 492' & Sqz. 70 sxs. to 342' 9 5/8" (12 1/4" Hole) 36# Csg. to 442' Cmt'd w-330 sxs to surface

Spot 30 sxs. @ 2590' & Tag @ 2440'

WUL + TAC Spot 30 sxs. @ 3645'DV Tool @ 3,595'

5 1/2" (7 7/8" hole) 15.5# csg. to 6,623' Cmt'd w-900 sxs. TOC @ 421' per CBL

WOLD TAGSet CIBP @ 5,858' & spot 30 sxs. on top

PBTD - - CIBP @ 6150' (05-06-09)

Composite Bridge Plug 6,350' (05-06-09)


TD @ 6,623'

Salt @ 2540'

Delaware: 5,958' - 6,060'

6,198' - 6,264' 6,476' - 6,503'

les@peeleroilfield.com



CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact Location of the MARKER (Longitude of Latitude By GPS) will be playioned to NMOCD.