
Submit i Copy To Appropriate District Office	State of New Mexico	Form C-103				
 <u>District I</u> - (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240 	Energy, Minerals and Natural Resources	Revised July 18, 2013 WELL API NO.				
<u>District II</u> – (575) 748-1283 811 S. First St., Artesia, NM 88210	OIL CONSERVATION DIVISION	30-015-35660				
District 111 - (505) 334-6178	1220 South St. Francis Dr.	5. Indicate Type of Lease STATE SFEE				
1000 Rio Brazos Rd., Aztec, NM 87410 District IV - (505) 476-3460	Santa Fe, NM 87505	6. State Oil & Gas Lease No.				
1220 S. St. Francis Dr., Santa Fe, NM 87505						
SUNDRY NOT	7. Lease Name or Unit Agreement Name					
(DO NOT USE THIS FORM FOR PROPO DIFFERENT RESERVOIR. USE "APPL	Jalapeno State Com					
PROPOSALS.)	8. Well Number 1-H					
 Type of Well: Oil Well Name of Operator 	Gas Well 🔲 Other	9. OGRID Number				
COG Operating, LLC		229137				
3. Address of Operator	K 70701	10. Pool name or Wildcat				
600 W. Illinois Ave, Midland, T. 4. Well Location	x /9/01	Santo Nino; Bone Spring				
4. Well Location Unit Letter K	: 2310 feet from the S line and	2310 feet from the Wline				
Section 32	Township 18S Range 30E	NMPM County Eddy				
- march - and -	11. Elevation (Show whether DR, RKB, RT, GR, etc.					
	9176'					
10 01 1						
12. Uneck	Appropriate Box to Indicate Nature of Notice,	Report or Other Data				
		SEQUENT REPORT OF:				
TEMPORARILY ABANDON	I	ILLING OPNS. P AND A				
CLOSED-LOOP SYSTEM						
OTHER: 13 Describe proposed or com	pleted operations. (Clearly state all pertinent details, and	d give pertinent dates including estimated date				
	ork). SEE RULE 19.15.7.14 NMAC. For Multiple Co					
1. Set 5 ½" CIBP @ 6100". C 2. Spot 25 sx cmt @ 3650-35	Circulate hole w/ MLF. Pressure test csg. Spot 25 sx cm (50) (San Andres)	t@6100-6000'. – WOEF THE				
	543-1443'. WOC & Tag (Shoe, Yates).					
4. Perf & Sqz 50 sx cmt @ 1	350-1250'. WOC & Tag (B/Salt)					
	28-Surface'. WOC & Tag. (T/Salt & Shoe) mt to surface, weld on Dry Hole Marker.					
o. Cut on wen nead, verny c	int to surface, weld on Dry Hole Marker.					
.						
Spud Date:	Rig Release Date:					
WELL MUST BE						
I hereby certify that the information	above is true and complete to the best of my knowledge	ge and belief.				
SIGNATURE A Ling i O M	longomerce TITLE agent	DATE 9/5/17				
	A. C. All approximations	iociates.com				
Type or print name Abigael	Montgomery E-mail address:	PHONE: 432-580-116				
For State Use Only						
APPROVED BY: fluit Conditions of Approval (if any):	I flyd TITLE COMPLIANIEL O	OFFICER DATE 9/11/17				
& SEE ATTA	AHED 10A-S					

Contraction of the second se	· · · · · · · · · · · · · · · · · · ·									
Author:	MRM (8/2017)			Description	O.D.	Grade	Weight	Depth	Cmt Sx	тос
Well Name Field	Jalapeno St. Com Santo Nino	Well No. API #:	#1H 30-015-35660	Surface Csg	13.375"	J-55	48	399'	1,083	surface
County State	Eddy New Mexico	Prop #: Zone:	36537 Bone Spring	Inter Csg	9.625"	J-55	36	1,493'	550	surface
Spud Date GL	9/2/2007 3,394'	SHL BHL	2310 FSL & 2310 FWL 330 FSL & 2210 FWL	Prod Csg	5.5"	J-55	17	9,177'	1,275	800'
КВ	18'		Sec 32 T185 R30E	Liner						
isotarianovertititititititi		5	7-1/2" hole 13-3/8" (48#) @ 399' wit TOC @ surface . Perf & Soz 90 sx . Perf & Sqz 50 sx	cmt @ 428-Surf	ace'. W			COG t alt & Shoe) t)	b drilled and co ook over opera ntion Tops	•
2		3	. Perf & Sqz 50 sx	cmt @ 1543-144	3'. WO	C & Ta	g (Shoe,	Base o Yates	of Salt	478' 1,306' 1,500' 2,396'
3	12-1/4" hole Bowers Sand 9-5/8" (36#) @ 1,493' with 550 sks, circ with 96 sks Delaware TOC @ surface Bone Spring									
4		2	2. Spot 25 sx cmt @ .	3650-3550'. (San	Andres	s)				
5										
6		1	,418'-9,050' (Bone Spring . Set 5 ½" CIBP @ .5 sx cmt @ 6100-60) 6100'. Circulate	e hole w	/ MLF. ራ				
7				TVD @ 7,314' PBTD @ 9,129' MD @ 9,176'	5-1/2" D\			1,275 sks stage - 225 sks, I stage - 1,050 s		
8										

٩



32.7030983 -103.9952011

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than **3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3. API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County

(SPECIAL CASES)

AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact