Submit 1 Copy To Appropriate District Office	Blace of New Mexico		Form C-103 Revised July 18, 2013	
<u>District I</u> – (575) 393-6161 1625 N. French Dr., Hobbs, NM 88240	_nergy, Minerals and Natural Resources		WELL API NO.	
<u>District II</u> - (575) 748-1283	OIL CONSERVATION DIVISION		30-015-25018	
811 S. First St., Artesia, NM 88210 <u>District III</u> – (505) 334-6178	1220 South St. Francis Dr.		5. Indicate Type of Lease STATE ☐ FEE	
1000 Rio Brazos Rd., Aztec, NM 87410 District IV – (505) 476-3460	Santa Fe, NM 87505		6. State Oil & Gas Lease No.	
1220 S. St. Francis Dr., Santa Fe, NM 87505			E-135	
SUNDRY NOTICES AND REPORTS ON WELLS			7. Lease Name or Unit Agreement Name	
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH		Cockatoo State		
PROPOSALS.)		8. Well Number 2		
1. Type of Well: Oil Well Gas Well Other			O OCRID Number	
2. Name of Operator COG Operating, LLC			9. OGRID Number 229137	
3. Address of Operator		10. Pool name or Wildcat		
600 W. Illinois Ave, Midland, TX 79701			Artesia; Queen-GRBG-SA	
4. Well Location				
Unit Letter N: 980 feet from the S line and 2310 feet from the W line				
Section 27 Township 17S Range 28E NMPM County EDDY				
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3677' GR				
3077 GR				
12. Check A	Appropriate Box to Indicate N	lature of Notice.	Report or Other Data	
NOTICE OF INTENTION TO: SUE PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒ REMEDIAL WOR			BSEQUENT REPORT OF: RK □ ALTERING CASING □	
TEMPORARILY ABANDON	CHANGE PLANS	COMMENCE DR		
PULL OR ALTER CASING	MULTIPLE COMPL CASING/CEMENT JOB			
DOWNHOLE COMMINGLE				
CLOSED-LOOP SYSTEM				
13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date				
of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of				
proposed completion or recompletion.				
Notify NMOCD 24hrs Before MIRU				
1. Set CIBP @ 2340'. Circulate hole w/ MLF. Pressure test csg. Spot 25 sx cmt @ 2340-2240'. WOC + 7A)				
2. Spot 25 sx cmt @ 850-750'. WOC & Tag				
3. Perf & Sqz 50 sx cmt @ 557-457'. WOC & Tag (Shoe & T/Salt) 4. Spot 25 sx cmt @ 100'-Surface.				
5. Cut off well head, verify cmt to surface, weld on Dry Hole Marker				
 Spot 25 sx cmt @ 100'-Surface. Cut off well head, verify cmt to surface, weld on Dry Hole Marker ARTESIA DISTRICTION 				
			· SigirRICT	
	lugging of well bore only. bond is retained pending receipt	Nov	9 2017	
of C-103 (Subs	equent Report of Well Plugging)			
	found at OCD Web Page under anra-state.ntn.us/oed.	RECI	EVED	
Recording design and the contract of the contr	Na		,	
	D: D 1 D			
Spud Date:	Rig Release D	ate:		
y See Attack	$\overline{\int C \partial A}$	Just Be F	Ingel Botone 11-	29-18
I hereby certify that the information	above is true and complete to the b			
_	A		5·	
SIGNATURED THE	THE DIRECTION OF THE PARTY OF T	2	DATE 11/00	. 1 i
SIGNATURE Alexand TIM	HUGOMORAL TITLE HO	(1) 10=	DATE 1122	<u> </u>
Type or print name Abicioul Me	ontuomery E-mail addres	e bornandas	sociates.com PHONE:432.	-580-716
For State Use Only	1			
APPROVED BY:	TITLE SA	H m-	DATE//-29	ラーノフ
Conditions of Approval (if any):	- IIILL	4	Ditte //- W	'

COG Operating LLC

Lease & Well # API:


Cockatoo State #2 30-015-25018

SA 2034

Elevation - 3677'

KB -

Spud Date - 3/16/1984



Drld 12 1/4" hole, 8 5/8" 24# csg set @ 507', cmtd w/ 350 sx, circ 65 sx

2386' - 2896' - San Andres

Frac w/ 5,739 bbi gel water, 130,000# 20/40 sand, 135,000# 12/20 sand, 60,000# 8/16 sand

PBTD - 3023' TD - 3060'

Drld 7 7/8" hole, 5 1/2" 15.5# csg set @ 3047', cmtd w/ 800 sx, circ 95 sx

32-8011551 104.1650085

COG Operating LLC


Lease & Well # API:

Cockatoo State #2 30-015-25018

Elevation - 3677

KB -

Spud Date - 3/16/1984



4. Spot 25 sx cmt @ 100'- Surface.

Drid 12 1/4" hole, 8 5/8" 24# csg set @ 507', cmtd w/ 350 sx, circ 65 sx

3. Perf & Sqz 50 sx cmt @ 557-457'. WOC & Tag.

2. Spot 25 sx cmt @ 850-750'. WOC & Tag

1. CIBP @ 2340'. Circulate hole w/ MLF. Pressure test csg. Spot 25 sx @ 2340-2240'.

2386' - 2896' - San Andres

Frac w/ 5,739 bbl gel water, 130,000# 20/40 sand, 135,000# 12/20 sand, 60,000# 8/16 sand

PBTD - 3023* TD - 3060*

Drid 7 7/8" hole, 5 1/2" 15.5# csg set @ 3047', cmtd w/ 800 sx, circ 95 sx

52-7011551 104 1650035

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.

- 1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
- 2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
- 3. Trucking companies being used to haul oilfield waste fluids to a disposal commercial or private shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
- 4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
- 5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
- 6. If the well is not plugged within 1
- 7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
- 8. Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.
- 9. Produced water will not be used during any part of the plugging operation.
- 10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
- 11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
- 12. Class 'C' cement will be used above 7500 feet.
- 13. Class 'H' cement will be used below 7500 feet.
- 14. A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged
- 15. All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing

- 16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
- 17. A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.
- 18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, (WOC 4 hrs and tag).
- 19. No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.
- 20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) Potash--- (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.
- 21. If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing

DRY HOLE MARKER REQUIRMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)------AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)