

OCT 08 2018

Submit 1 Copy To Appropriate District Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

State of New Mexico Energy, Minerals and Natural Resources
DISTRICT II-ARTESIA
OIL CONSERVATION DIVISION
1220 South St. Francis Dr.
Santa Fe, NM 87505

Form C-103
Revised July 18, 2013

API NO. 30-015-43990
5. Indicate Type of Lease STATE [ ] FEE [X]
6. State Oil & Gas Lease No. -
7. Lease Name or Unit Agreement Name Willow Lake WC 15
8. Well Number 001H
9. OGRID Number 12361
10. Pool name or Wildcat Purple Sage Wolfcamp Gas Pool
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 2995' GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)
1. Type of Well: Oil Well [ ] Gas Well [X] Other
2. Name of Operator Kaiser-Francis Oil Company
3. Address of Operator P. O. Box 21468, Tulsa, OK 74121-1468
4. Well Location Unit Letter L : 1930 feet from the South line and 220 feet from the East line
Section 14 Township 24S Range 28E NMPM Eddy County

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK [ ] PLUG AND ABANDON [ ]
TEMPORARILY ABANDON [ ] CHANGE PLANS [ ]
PULL OR ALTER CASING [ ] MULTIPLE COMPL [ ]
DOWNHOLE COMMINGLE [ ]
CLOSED-LOOP SYSTEM [ ]
OTHER: Isolate water flow [X]
SUBSEQUENT REPORT OF:
REMEDIAL WORK [ ] ALTERING CASING [ ]
COMMENCE DRILLING OPNS [ ] P AND A [ ]
CASING/CEMENT JOB [ ]
OTHER: [ ]

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

- 1. Perf @ 9500' +/-
2. Set a cmt retainer above the sqz perfs @ 9200'. Attempt to flow the 5 1/2" casing.
3. Sting into the retainer. Sqz 125 sxs cmt below the retainer and spot cmt on top of the retainer via coiled tbg. WOC.
4. Monitor pressure to see if flow has been isolated.
5. Dump bail cmt on top of retainer @ 9200'.
6. If unsuccessful, set retainer @ 8200' & sqz w/125 sxs cmt below retainer and spot cmt on top.
7. If unsuccessful, set retainer @ 7500' & sqz w/125 sxs cmt below retainer and spot cmt on top. Monitor pressure to see if flow has been isolated.

Spud Date: 2/15/18 Rig Release Date: 4/21/18

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE [Signature] TITLE Mgr., Regulatory Compliance DATE 10-8-18

Type or print name Charlotte Van Valkenburg E-mail address: Charlottv@kfoc.net PHONE: 918-491-4314
For State Use Only

APPROVED BY: [Signature] TITLE MGR DATE 10/9/18
Conditions of Approval (if any):