

Submit 1 Copy To Appropriate District Office
 District I - (575) 393-6161
 1625 N. French Dr., Hobbs, NM 88240
 District II - (575) 748-1283
 811 S. First St., Artesia, NM 88210
 District III - (505) 334-6178
 1000 Rio Brazos Rd., Aztec, NM 87410
 District IV - (505) 476-3460
 1220 S. St. Francis Dr., Santa Fe, NM 87505

NM OIL CONSERVATION
 Energy, Minerals and Natural Resources
OCT 11 2019
RECEIVED
 OIL CONSERVATION DIVISION
 1220 South St. Francis Dr.
 Santa Fe, NM 87505

Form C-103
 Revised July 18, 2013

WELL API NO. 30-015-26346
5. Indicate Type of Lease STATE <input type="checkbox"/> FEE <input checked="" type="checkbox"/>
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name South Culebra 23
8. Well Number 11
9. OGRID Number 018890
10. Pool name or Wildcat East Loving (Delaware)
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 2989 GR

SUNDRY NOTICES AND REPORTS ON WELLS
 (DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well Gas Well Other

2. Name of Operator
Chevron USA INC

3. Address of Operator
6301 Deauville BLVD, Midland, TX 79706

4. Well Location
 Unit Letter B : 660 feet from the North line and 2140 feet from the East line
 Section 23 Township 23S Range 28E NMPM County Eddy

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:		SUBSEQUENT REPORT OF:	
PERFORM REMEDIAL WORK <input type="checkbox"/>	PLUG AND ABANDON <input checked="" type="checkbox"/>	REMEDIAL WORK <input type="checkbox"/>	ALTERING CASING <input type="checkbox"/>
TEMPORARILY ABANDON <input type="checkbox"/>	CHANGE PLANS <input type="checkbox"/>	COMMENCE DRILLING OPNS. <input type="checkbox"/>	P AND A <input type="checkbox"/>
PULL OR ALTER CASING <input type="checkbox"/>	MULTIPLE COMPL <input type="checkbox"/>	CASING/CEMENT JOB <input type="checkbox"/>	
DOWNHOLE COMMINGLE <input type="checkbox"/>			
CLOSED-LOOP SYSTEM <input type="checkbox"/>			
OTHER: <input type="checkbox"/>		OTHER: <input type="checkbox"/>	

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

Notify OCD 24 hrs . prior to any work done.

Chevron USA INC respectfully request to abandon this well as follows:

1. Call and notify NMOCD 24 hrs before operations begin.
2. Move in rig and rig up all CMT equipment
3. RIH and set CIBP @ 5700' Spot 25 sx of Class C CMT from 5700' to 5472' (Perfs) - *woc & tag*
4. RIH and set CIBP @ 4700' Pressure test @ 1000 psi for 10 minutes - *woc & tag*
5. Spot 150 sx CL "C" cmt f/ 4700' t/ 3319', ~~do not WOC & tag if casing passed a pressure test~~ (perfs, Cherry Canyon, Brushy Canyon, DV tool)
6. Spot 45 sx of Class C CMT f/ 2668' t/ 2253' (BSalt, Lamar LS, Bell Canyon). - *woc & tag*
7. P&S 65 sx f/ 587' t/ Surface (Shoe, WB).
8. Cut all casings & anchors & remove 3' below grade. Verify cement to surface & weld on dry hole marker as per, NMOCD requirements. Clean location.

** See Attached COA's must be plugged by 10/15/20*
 I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE *Ricky Villanueva* TITLE Well P&A Project Manager DATE 10/9/2019

Type or print name Ricky Villanueva E-mail address: rygg@chevron.com PHONE: 432-488-7448

For State Use Only

APPROVED BY: *[Signature]* TITLE Staff mg DATE 10/15/19
 Conditions of Approval (if any):

[Handwritten mark]

SCB 23-11
Loving East: API #30-015-26346
B-23-23S-28E 660' FNL, 2140' FEL
Eddy County, NM

CURRENT COMPLETION (Last Updated by Y. Li & RJ DeBruin, 7/20/2019)

KB: 3001.5'
 GL: 2989'


TOC @ surf
 (cmt w/ 350 sx
 Class C)
 8 5/8" csg @ 537'

DV Tool @ 3480'

TOC @ surf
 (Stage 2 cmt w/
 1200 sxs PSL C &
 100 sx Class C)

Wellbore diagram is based on most recent information regarding wellbore configuration & equipment that could be found in the Midland Office well files & computer / online databases as of the update date above.

Stage 1
 (cmt w/ 450 sx
 50/50 Pozmix & 200
 sx Class C)
 5 1/2" csg @ 6300'



CASING DETAIL				
Depth	Size	Weight	Grade	Hole
537'	8 5/8"	23#	J-55	12-1/4"
6300'	5 1/2"	15.5#	J-55	7-7/8"

ROD & TUBING DETAIL (from 1/9/2013 Range Well Report)	
Rod Detail :	Tubing Detail :
SMPR--- 1-1/2" x 22'	Tubing Sub---2-7/8" x 10' J-55
7/8" Pony rods--1-(4') 1-(8')	Tubing above TAC---131 jts 2-7/8" J-55
7/8" Sucker rods--90	TAC---5-1/2" x 2-1/2"
3/4" Sucker rods--153	Tubing below TAC---67 jts 2-7/8" J-55
2.5" x 1.5" x 20' x 4" RHBC	S/N-----1.01'X2.5'
Gas Anchor----1.25" x 12'	Perf. Sub-----2-7/8" x 4' J-55
	Mud Joint----2-7/8" x 31'

Brushy Canyon Upper frac'd in '03
 4736' - 4741'
 4751' - 4758'
 4761' - 4779'
 4782' - 4794'
 4798' - 4802'
 142 holes

Brushy Canyon "AA" frac'd in '00
 5764' - 5782'
 5812' - 5826'
 5831' - 5843'
 96 holes total

Brushy Canyon "A" & "B" frac'd in '00, started producing in '04
 5927' - 5937'
 5942' - 5952'
 5954' - 5962'
 5964' - 5968'
 5973' - 5980'
 6002' - 6029'
 146 holes total

Brushy Canyon "C" frac'd in '90
 6116' - 6210' - 100 holes

Spud Date: 4/22/1990
 TD Date: 5/3/1990
 Compl Date: 5/19/1990

PBTD = 6283'
 TD = 6300'

NOTES:
 Red items have no documentation in NMOCD records, but are shown on Range, Vanguard & RockCliff WBDs.

Note: Schematic is not to scale. For display purposes only.

SCB 23-11
Loving East: API #30-015-26346
B-23-23S-28E 660' FNL, 2140' FEL
Eddy County, NM

CURRENT COMPLETION (Last Updated by Y. Li & RJ DeBruin, 7/20/2019)

KB: 3001.5'
 GL: 2989'

TOC @ surf
 (cmt w/ 350 sx Class
 C)
8 5/8" csg @ 537'

CASING DETAIL				
Depth	Size	Weight	Grade	Hole
537'	8 5/8"	23#	J-55	12-1/4"
6300'	5 1/2"	15.5#	J-55	7-7/8"

Well	SOUTH CUEBRA BLUFF 23 #011
API#	3001526346
Group	(CIB)
Formation Top, Depth (MD)	Depth (MD)
T Salt	498
B Salt	2374
Lamar LS	2590
Bell Canyon	2618
Cherry Canyon	3450
Brushy Canyon	4729
Bone Spring	6210
1st Bone Spring	below TD
2nd Bone Spring	
3rd Bone Spring	
Wolfcamp	
Strawn	
Atoka	
Morrow	
Mississippian	
** none of these wells penetrate Capitan Reef**	
	T. salt picked from log and lith

Spot 65 sx of Class C CMT f/ 587' to Surface
 (T Salt, Shoe, WB)

Spot 45 sx of Class C CMT f/ 2668' to 2253'
 (B Salt, Lamar LS, Bell Canyon)

Spot 150 sx of Class C CMT f/ 4700' to 3319'
 Pressure Test @ 1000 psi for 10 minutes
 (Perfs, Cherry Canyon, Brushy Canyon, DV tool)

WOC-Tag

DV Tool @ 3480'

TOC @ surf
 (Stage 2 cmt w/
 1200 sxs PSL C &
 100 sx Class C)

Brushy Canyon Upper
 4736' - 4741' frac'd in '03
 4751' - 4758'
 4761' - 4779'
 4782' - 4794'
 4798' - 4802' 142 holes

Set CIBP @ 5700'
 Spot 25 sx of Class C CMT f/ 5700' to 5472'
 (Perfs, Brushy Canyon)

frac'd in '00

5764' - 5782'
 5812' - 5826'
 5831' - 5843'

96 holes total

Brushy Canyon "A" & "B"

frac'd in '00, started producing in '04

5927' - 5937'
 5942' - 5952'
 5954' - 5962'
 5964' - 5968'
 5973' - 5980'
 6002' - 6029'

146 holes total

Brushy Canyon "C"

frac'd in '90

6116' - 6210' - 100 holes

Spud Date: 4/22/1990
 TD Date: 5/3/1990
 Compl Date: 5/19/1990

NOTES:
 Red items have no documentation in
 NMOCD records, but are shown on
 Range, Vanguard & RockCliff WBDs.

Wellbore diagram is based
 on most recent information
 regarding wellbore
 configuration & equipment
 that could be found in the
 Midland Office well files &
 computer / online databases
 as of the update date above.

Stage 1
 (cmt w/ 450 sx 50/50
 Pozmix & 200 sx
 Class C)
5 1/2" csg @ 6300'

PBTD = 6283'
 TD = 6300'

Note: Schematic is not to scale. For display purposes only.

CONDITIONS FOR PLUGGING AND ABANDONMENT

District II / Artesia N.M.

The following is a guide or checklist in preparation of a plugging program, this is not all inclusive and care must be exercised in establishing special plugging programs in unique and unusual cases, **Notify NMOCD District Office II at (575)-748-1283 at least 24 hours before beginning work.**

1. A notice of intent to plug and abandon a wellbore is required to be approved before plugging operations are conducted. A cement evaluation tool is required in order to ensure isolation of producing formations, protection of water and correlative rights. A cement bond log or other accepted cement evaluation tool is to be provided to the division for evaluation if one has not been previously run or if the well did not have cement circulated to surface during the original casing cementing job or subsequent cementing jobs.
2. Closed loop system is to be used for entire plugging operation. Upon completion, contents of steel pits are to be hauled to a permitted disposal location.
3. Trucking companies being used to haul oilfield waste fluids to a disposal – commercial or private – shall have an approved NMOCD C-133 permit. A copy of this permit shall be available in each truck used to haul waste products. It is the responsibility of the operator as well as the contractor, to verify that this permit is in place prior to performing work. Drivers shall be able to produce a copy upon request of an NMOCD Field inspector.
4. Filing a subsequent C-103 will serve as notification that the well has been plugged.
5. A final C-103 shall be filed (and a site inspection by NMOCD Inspector to determine if the location is satisfactorily cleaned, all equipment, electric poles and trash has been removed to Meet NMOCD standards) before bonding can be released.
6. If the well is not plugged within 1
7. If work has not begun within 1 Year of the approval of this procedure, an extension request must be file stating the reason the well has not been plugged.
8. **Squeeze pressures are not to exceed 500 psi, unless approval is given by NMOCD.**
9. Produced water **will not** be used during any part of the plugging operation.
10. Mud laden fluids must be placed between all cement plugs mixed at 25 sacks per 100 bbls of water.
11. All cement plugs will be a minimum of 100' in length or a minimum of 25 sacks of cement, whichever is greater. 50' of calculated cement excess required for inside casing plugs and 100% calculated cement excess required on outside casing plugs.
12. **Class 'C' cement will be used above 7500 feet.**
13. **Class 'H' cement will be used below 7500 feet.**
14. **A cement plug is required to be set 50' above and 50' below, casing stubs, DV tools, attempted casing cut offs, cement tops outside casing, salt sections and anywhere the casing is perforated, these plugs require a 4 hour WOC and then will be tagged**
15. **All Casing Shoes Will Be Perforated 50' below shoe depth and Attempted to be Squeezed, cement needs to be 50' above and 50' Below Casing Shoe inside the Production Casing**

16. When setting the top out cement plug in production, intermediate and surface casing, wellbores should remain full at least 30 minutes after plugs are set
17. **A CIBP is to be set within 100' of production perforations, capped with 100' of cement, WOC 4 hours and tag.**
18. A CIBP with 35' of cement may be used in lieu of the 100' plug if set with a bailer. This plug will be placed within 100' of the top perforation, **(WOC 4 hrs and tag).**
19. **No more than 3000' is allowed between cement plugs in cased hole and 2000' in open hole.**
20. Some of the Formations to be isolated with cement plugs are: These plugs to be set to isolate formation tops
 - A) Fusselman
 - B) Devonian
 - C) Morrow
 - D) Wolfcamp
 - E) Bone Springs
 - F) Delaware
 - G) Any salt sections
 - H) Abo
 - I) Glorieta
 - J) Yates.
 - K) **Potash---** (In the R-111-P Area (Potash Mine Area), a solid cement plug must be set across the salt section. Fluid used to mix the cement shall be saturated with the salts that are common to the section penetrated and in suitable proportions, not more than 3% calcium chloride (by weight of cement) will be considered the desired mixture whenever possible, **WOC 4 hours and tag, this plug will be 50' below the bottom and 50' above the top of the Formation.**
21. **If cement does not exist behind casing strings at recommended formation depths, the casing can be cut and pulled with plugs set at recommended depths. If casing is not pulled, perforations will be shot and cement squeezed behind casing, WOC and tagged. These plugs will be set 50' below formation bottom to 50' above formation top inside the casing**

DRY HOLE MARKER REQUIREMENTS

The operator shall mark the exact location of the plugged and abandoned well with a steel marker not less than four inches in diameter, 3' below ground level with a plate of at least ¼" welded to the top of the casing and the dry hole marker welded on the plate with the following information welded on the dry hole marker:

1. Operator name 2. Lease and Well Number 3.API Number 4. Unit Letter 5. Quarter Section (feet from the North, South, East or West) 6. Section, Township and Range 7. Plugging Date 8. County (SPECIAL CASES)-----AGRICULTURE OR PRARIE CHICKEN BREEDING AREAS

In these areas, a below ground marker is required with all pertinent information mentioned above on a plate, set 3' below ground level, a picture of the plate will be supplied to NMOCD for record, the exact location of the marker (longitude and latitude by GPS) will be provided to NMOCD (We typically require a current survey to verify the GPS)