

Submit 1 Copy To Appropriate District Office
District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87401
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

RECEIVED

State of New Mexico
Energy, Minerals and Natural Resources

Form C-103
Revised July 18, 2013

NOV 20 2019

OIL CONSERVATION DIVISION

DISTRICT I - ARTESIA

1000 South St. Francis Dr.

Santa Fe, NM 87505

WELL API NO.
30-005-62185

5. Indicate Type of Lease

STATE ☒ FEE ☐

6. State Oil & Gas Lease No.
LG-5230

7. Lease Name or Unit Agreement Name
South Dallas

8. Well Number
1

9. OGRID Number
7377

10. Pool name or Wildcat
Foor Ranch; Wolfcamp (Gas)

SUNDRY NOTICES AND REPORTS ON WELLS

(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)

1. Type of Well: Oil Well ☐ Gas Well ☒ Other

2. Name of Operator
EOG Resources, Inc.

3. Address of Operator
104 South Fourth Street, Artesia, NM 88210

4. Well Location

Unit Letter F : 1980 feet from the North line and 1980 feet from the West line
Section 2 Township 10S Range 26E NMPM Chaves County

11. Elevation (Show whether DR, RKB, RT, GR, etc.)
3843'GR

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:

PERFORM REMEDIAL WORK ☐ PLUG AND ABANDON ☒
TEMPORARILY ABANDON ☐ CHANGE PLANS ☐
PULL OR ALTER CASING ☐ MULTIPLE COMPL ☐
DOWNHOLE COMMINGLE ☐
CLOSED-LOOP SYSTEM ☐
OTHER: ☐

SUBSEQUENT REPORT OF:

REMEDIAL WORK ☐ ALTERING CASING ☐
COMMENCE DRILLING OPNS. ☐ P AND A ☐
CASING/CEMENT JOB ☐
OTHER: ☐

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOG Resources, Inc. plans to plug and abandon this well as follows:

- MIRU all safety equipment as needed. NU BOP. POOH with production equipment.
- Set a CIBP at 5570' with 35' Class "C" cement on top. - WOC + Tag
- Set a CIBP at 4530' with 35' Class "C" cement on top. - WOC + Tag
- Spot a 25 sx Class "C" cement plug from 3856'-3618'. WOC and tag. This will plug Tubbs.
- Perforate at 2378'. Attempt to establish circulation or spot a 33 sx Class "C" cement plug from 2378'-2255'. WOC and tag. This will plug Glorieta.
- Perforate at 1261'. Attempt to establish circulation or spot a 25 sx Class "C" cement plug from 1261'-1023'. WOC and tag. This will plug 8-5/8" shoe and San Andres.
- Perforate at 411'. Attempt to establish circulation or spot a 25 sx Class "C" cement plug from 411'-173'. WOC and tag. This will plug 13-3/8" shoe.
- Spot a 10 sx Class "C" cement plug from 95' up to surface. WOC and tag plug. This will plug the top.
- Cut off wellhead and weld on dry hole marker. Clean location as per regulated.

Wellbore schematics attached

Spud Date:

Rig Release Date:

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Specialist DATE November 18, 2019

Type or print name Tina Huerta E-mail address: tina_huerta@eogresources.com PHONE: 575-748-4168
For State Use Only

APPROVED BY: DENIED TITLE DENIED DATE 11/21/19

Conditions of Approval (if any):