

Submit 1 Copy To Appropriate District Office

RECEIVED State of New Mexico Energy, Minerals and Natural Resources

Form C-103 Revised July 18, 2013

District I - (575) 393-6161
1625 N. French Dr., Hobbs, NM 88240
District II - (575) 748-1283
811 S. First St., Artesia, NM 88210
District III - (505) 334-6178
1000 Rio Brazos Rd., Aztec, NM 87410
District IV - (505) 476-3460
1220 S. St. Francis Dr., Santa Fe, NM 87505

DEC 12 2019 OIL CONSERVATION DIVISION 1220 South St. Francis Dr. Santa Fe, NM 87505

WELL API NO. 30-015-23716
5. Indicate Type of Lease STATE [] FEE [x]
6. State Oil & Gas Lease No.
7. Lease Name or Unit Agreement Name Davis NC Com
8. Well Number 2
9. OGRID Number 7377
10. Pool name or Wildcat Boyd; Morrow
11. Elevation (Show whether DR, RKB, RT, GR, etc.) 3997'GR

SUNDRY NOTICES AND REPORTS ON WELLS
(DO NOT USE THIS FORM FOR PROPOSALS TO DRILL OR TO DEEPEN OR PLUG BACK TO A DIFFERENT RESERVOIR. USE "APPLICATION FOR PERMIT" (FORM C-101) FOR SUCH PROPOSALS.)
1. Type of Well: Oil Well [] Gas Well [x] Other []
2. Name of Operator EOG Resources, Inc.
3. Address of Operator 104 South Fourth Street, Artesia, NM 88210
4. Well Location Unit Letter L : 1980 feet from the South line and 660 feet from the West line Section 11 Township 19S Range 24E NMPM Eddy County

12. Check Appropriate Box to Indicate Nature of Notice, Report or Other Data

NOTICE OF INTENTION TO:
PERFORM REMEDIAL WORK [] PLUG AND ABANDON [x]
TEMPORARILY ABANDON [] CHANGE PLANS []
PULL OR ALTER CASING [] MULTIPLE COMPL []
DOWNHOLE COMMINGLE []
CLOSED-LOOP SYSTEM []
OTHER: []
SUBSEQUENT REPORT OF:
REMEDIAL WORK [] ALTERING CASING []
COMMENCE DRILLING OPNS. [] P AND A []
CASING/CEMENT JOB []
OTHER: []

13. Describe proposed or completed operations. (Clearly state all pertinent details, and give pertinent dates, including estimated date of starting any proposed work). SEE RULE 19.15.7.14 NMAC. For Multiple Completions: Attach wellbore diagram of proposed completion or recompletion.

EOG Resources, Inc. plans to plug and abandon this well as follows:

- 1. MIRU all safety equipment as needed. NU BOP. POOH with production equipment.
2. Set a CIBP at 3642' with 35' Class "C" cement on top.
3. Spot a 25 sx Class "C" cement plug from 3028'-2666'. WOC and tag. This will plug Tubb.
4. Perforate at 1792'. Attempt to establish circulation or spot a 118 sx Class "C" cement plug from 1792'-1358'. WOC and tag. This will plug 8-5/8" shoe and Glorieta.
5. Perforate at 898'. Attempt to establish circulation or spot a 25 sx Class "C" cement plug from 898'-438'. WOC and tag. This will plug 13-3/8" shoe and San Andres.
6. Spot a 10 sx Class "C" cement plug from 145' up to surface. WOC and tag plug. This will plug the top.
7. Cut off wellhead and weld on dry hole marker. Clean location as per regulated.

Wellbore schematics attached

This well was drilled to 10,000' - WBD is incorrect - Missing Paperwork -

Spud Date: []

Rig Release Date: []

I hereby certify that the information above is true and complete to the best of my knowledge and belief.

SIGNATURE Tina Huerta TITLE Regulatory Specialist DATE December 9, 2019

Type or print name Tina Huerta E-mail address: tina.huerta@eogresources.com PHONE: 575-748-4168

For State Use Only

DENIED

DENIED

GC

APPROVED BY: [] TITLE [] DATE 12/23/19

Conditions of Approval (if any):